

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [TJ media](#) /

› [TJ media Wireless Microphone Set User Manual](#)

TJ media TMW100 White Color (TMW100W)

TJ media Wireless Microphone Set User Manual

Model: TMW100 White Color (TMW100W)

INTRODUCTION

Thank you for purchasing the TJ media Wireless Microphone 2pcs Set. This manual provides detailed instructions for setting up, operating, and maintaining your new wireless microphone system. Please read this manual thoroughly before using the product to ensure proper operation and to maximize its lifespan.

The TJ media TMW100 Wireless Microphone system offers high-quality audio transmission with convenient features such as long battery life, automatic pairing, and an LCD display for real-time status monitoring.

WHAT'S IN THE BOX

Please check the contents of your package to ensure all items are present:

- Wireless Microphone (2 EA)
- Charging Dock
- Amp Receiver
- Power Adapter
- Audio Cables
- User Manual (this document)
- Lithium Ion Batteries (1 included, likely pre-installed or for the microphones)

PRODUCT OVERVIEW

Familiarize yourself with the components of your TJ media Wireless Microphone Set.



Figure 1: Complete TJ media Wireless Microphone Set including two microphones, charging dock, and receiver unit.

Microphone (TMW-100M)





Figure 2: Single TJ media Wireless Microphone showing the display and control buttons.

- **Microphone Head:** Captures audio.
- **LCD Display:** Shows battery status, channel, and signal strength.
- **Power/Mute Button:** Turns the microphone on/off and mutes/unmutes.
- **Channel Adjustment Buttons:** Used to change the microphone's operating channel.

Receiver Unit (TMW-100R)



Figure 3: TJ media Wireless Microphone Receiver Unit with display and control buttons.

- **LCD Display:** Shows status for both microphones (MIC1, MIC2) including channel and connection status.
- **MODE Button:** Used to cycle through settings or pairing modes.
- **+/- Buttons:** Adjust volume or navigate settings.

- **Audio Output (XLR):** Connects to an amplifier or sound system.
- **Power Input:** Connects to the power adapter.

Charging Dock (TMW-100C)



Figure 4: TJ media Wireless Microphones placed in the charging dock.

- **Charging Slots:** Two slots for charging the wireless microphones.
- **Charging Indicators:** LEDs or display segments indicating charging status.
- **Power Input:** Connects to the power adapter (can be shared with receiver or separate, depending on model).

SETUP INSTRUCTIONS

1. **Unpack Components:** Carefully remove all items from the packaging.
2. **Connect Receiver Power:** Connect the provided power adapter to the "Power Input" port on the receiver unit (TMW-100R) and plug it into a wall outlet.
3. **Connect Audio Output:** Use the audio cables to connect the receiver's XLR output to the audio input of your amplifier, mixer, or karaoke machine. Ensure a secure connection.
4. **Charge Microphones:**
 - Place both wireless microphones into the charging slots on the charging dock (TMW-100C).
 - Ensure the charging dock is also connected to power.
 - Allow the microphones to fully charge before first use. A full charge can provide up to 50 hours of use.
5. **Power On:**
 - Turn on the receiver unit.

- Press and hold the Power button on each microphone to turn them on.
6. **Automatic Pairing:** The microphones and receiver should automatically pair. The receiver's LCD display will show "MIC1" and "MIC2" with their respective channel numbers and connection status. If pairing fails, refer to the Troubleshooting section.
 7. **Test Audio:** Speak into the microphones to test the audio output through your connected sound system. Adjust volume levels on your amplifier/mixer as needed.

OPERATING INSTRUCTIONS

Microphone Operation

- **Power On/Off:** Press and hold the Power button on the microphone for 3 seconds to turn it on or off.
- **Mute/Unmute:** Briefly press the Power button while the microphone is on to mute or unmute it. The LCD display will indicate the mute status.
- **Check Battery Status:** The microphone's LCD display shows the current battery level. For detailed status, refer to the receiver's display.
- **Change Channel (Advanced):** If experiencing interference, you can manually change the microphone's channel. Consult the Troubleshooting section for detailed steps on channel adjustment and synchronization with the receiver.

Receiver Operation

- **Display Information:** The receiver's LCD display shows the status of both microphones, including their active channels and connection status.
- **Volume Adjustment:** Use the '+' and '-' buttons on the receiver to adjust the output volume of the microphones.
- **Mode Button:** The MODE button can be used for advanced settings or re-pairing if necessary. Refer to the Troubleshooting section for re-pairing procedures.
- **Distance Control Function:** This feature helps avoid channel interference. Ensure the receiver is placed in an optimal location, away from other wireless devices.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the microphones, receiver, and charging dock. Do not use liquid cleaners or abrasive materials.
- **Battery Care:**
 - Always fully charge the microphones before extended storage.
 - Recharge the microphones regularly, even if not in use, to maintain battery health.
 - Avoid exposing batteries to extreme temperatures.
- **Storage:** Store the product in a cool, dry place away from direct sunlight and excessive dust.
- **Handling:** Handle the microphones and receiver with care. Avoid dropping them or subjecting them to strong impacts.

TROUBLESHOOTING

If you encounter any issues with your TJ media Wireless Microphone Set, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
No sound from microphone.	Microphone is off. Microphone is muted. Low microphone battery. Receiver is off. Microphone not paired with receiver. Audio cables not connected properly. Amplifier/mixer volume too low.	Turn on microphone. Unmute microphone. Charge microphone. Turn on receiver. Re-pair microphone and receiver (see below). Check and secure all audio cable connections. Increase volume on amplifier/mixer.
Interference or static.	Other wireless devices nearby. Operating too far from receiver. Low microphone battery.	Change microphone/receiver channel. Move closer to the receiver. Charge microphone. Ensure receiver is not obstructed.
Microphone not charging.	Charging dock not powered. Microphone not seated correctly.	Ensure charging dock is plugged in. Re-seat microphone firmly in the dock.

Re-pairing Microphones and Receiver

If your microphones lose connection or fail to pair automatically:

1. Ensure both the receiver and microphones are powered on.
2. On the receiver, press and hold the "MODE" button until the display indicates a pairing mode (e.g., "PAIR" or flashing channel numbers).
3. On the microphone you wish to pair, press and hold its "Channel Adjustment" button (or a combination as indicated in the microphone's specific instructions, if different from general power button).
4. The microphone and receiver displays should show a successful pairing confirmation. Repeat for the second microphone if necessary.

SPECIFICATIONS

Feature	Detail
Model Name	TMW100W
Microphone Form Factor	Handheld
Power Source	Battery Powered
Battery Type	Lithium Ion (1 included per microphone)
Battery Life	Up to 50 hours per charge
Number of Channels	2
Connectivity Technology	Wireless (XLR output on receiver)
Polar Pattern	Omnidirectional
Color	White

Feature	Detail
Compatible Devices	Karaoke Machine, Amplifiers, Mixers
Special Features	Convenient microphone Battery status check, LCD display microphone state, Automatic pairing, Distance control function to avoid channel interference.

WARRANTY AND SUPPORT

This product comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions. For technical support, service, or warranty claims, please contact TJ media customer service through their official website or the retailer from whom you purchased the product.

Note: No official product videos from the seller were available for embedding in this manual.



© 2024 TJ media. All rights reserved.


Related Documents - TMW100 White Color (TMW100W)

<p>EPSON</p> <p>Epson Edge Print Operation Guide</p> 	<p>Epson Edge Print Operation Guide</p> <p>Comprehensive operation guide for Epson Edge Print software, covering printing procedures, job settings, color management, troubleshooting, and advanced features for professional printing applications.</p>
<p>Owners Manual</p>  <p>HV-3C</p>  <p>HV-3D</p> <p>High Voltage Microphone Preamplifiers Millennia Audio & Media's Passion</p>	<p>Millennia HV-3C & HV-3D High Voltage Microphone Preamplifier Owner's Manual</p> <p>Comprehensive owner's manual for the Millennia HV-3C and HV-3D High Voltage Microphone Preamplifiers, detailing features, specifications, safety guidelines, and operational instructions for professional audio applications.</p>
 <p>Audio Enhancement BEAM Quick Start Guide</p>	<p>Audio Enhancement BEAM Quick Start Guide: Setup and Operation</p> <p>A concise guide to setting up and operating the Audio Enhancement BEAM system, covering front and rear panel features, tone and volume controls, microphone pairing, and Bluetooth connectivity.</p>
<p>Rinnai</p> <p>Linear 1000 Burn Media Installation</p> 	<p>Rinnai Linear 1000 Burn Media Installation Guide</p> <p>Comprehensive guide for installing burn media for the Rinnai Linear 1000 fireplace, covering both FlameTech log sets and modern media.</p>



[JOBY Wavo Pro Wireless Microphone System User Manual and Guide](#)

Comprehensive user manual for the JOBY Wavo Pro and Wavo Pro1 wireless microphone systems. This guide covers features, operation, charging, Bluetooth connectivity, troubleshooting, and regulatory information for professional audio recording.



[Verizon Fios TV Media Server and Client Setup Guide](#)

Instructions for setting up the Verizon Fios TV Video Media Server (VMS1100) and Media Client (IPC1100), including connection options and remote programming.