

[Manuals.plus](#) /

› [Pagani Design](#) /

› Pagani Design PD-1644 Men's Quartz Chronograph Watch Instruction Manual

## Pagani Design PD-1644

# Pagani Design PD-1644 Men's Quartz Chronograph Watch Instruction Manual

Model: PD-1644 | Brand: Pagani Design

## 1. INTRODUCTION

---

Thank you for choosing the Pagani Design PD-1644 Quartz Chronograph Watch. This manual provides essential information for the proper setup, operation, and maintenance of your timepiece. Please read these instructions carefully to ensure optimal performance and longevity of your watch.

## 2. PRODUCT OVERVIEW

---

The Pagani Design PD-1644 is a sophisticated men's quartz chronograph watch, engineered for precision and durability. It features a reliable Japanese Seiko VK63 quartz movement, ensuring accurate timekeeping with minimal error. The watch is constructed with a robust stainless steel case and bracelet, complemented by a scratch-resistant synthetic sapphire crystal dial window.

Key features include a luminous dial for visibility in low light, a date display, and a multi-function chronograph with three independent sub-dials capable of measuring hours, minutes, and seconds. With a water resistance rating of 100 meters (10 ATM), it is suitable for swimming and short showers, but not for diving or snorkeling.



Image 2.1: Front view of the Pagani Design PD-1644 watch, highlighting its rose gold case, black dial, and chronograph sub-dials.

### 3. COMPONENTS IDENTIFICATION

---

Familiarize yourself with the main components of your Pagani Design PD-1644 watch:

- **Crown:** Used for setting time and date.
- **Pushers (A & B):** Used to operate the chronograph functions.
- **Main Dial:** Displays hours, minutes, and seconds.
- **Sub-dials:** Chronograph hour, minute, and second counters.
- **Date Window:** Displays the current date.
- **Bezel:** Fixed tachymeter bezel for measuring speed.
- **Strap/Bracelet:** Stainless steel bracelet with a deployant buckle.



Image 3.1: Diagram illustrating watch dimensions and key features. Please note that while the image shows 'PD-1664', the instructions apply to the PD-1644 model.

## 4. SETUP INSTRUCTIONS

### 4.1. Setting the Time

1. Pull the crown out to the second click position.
2. Rotate the crown to move the hour and minute hands to the desired time. Ensure AM/PM is correctly set if your watch has a 24-hour indicator or if setting the date.
3. Push the crown back to the normal position to start the watch.

### 4.2. Setting the Date

1. Pull the crown out to the first click position.
2. Rotate the crown to adjust the date. Avoid setting the date between 9 PM and 3 AM, as this is when the date change mechanism is active and could be damaged.
3. Push the crown back to the normal position.

### 4.3. Chronograph Hand Zero Reset

If the chronograph hands do not return to the zero position after reset, they may need calibration:

1. Pull the crown out to the second click position.
2. Press Pusher A (top pusher) to adjust the chronograph second hand to the zero position.
3. Press Pusher B (bottom pusher) to adjust the chronograph minute and hour hands to the zero position.
4. Once all chronograph hands are at zero, push the crown back to the normal position.

## 5. OPERATING INSTRUCTIONS

---

### 5.1. Using the Chronograph

The chronograph function allows you to measure elapsed time.

- **Start:** Press Pusher A to start the chronograph.
- **Stop:** Press Pusher A again to stop the chronograph.
- **Reset:** After stopping, press Pusher B to reset all chronograph hands to the zero position.

### 5.2. Water Resistance

Your Pagani Design PD-1644 watch has a water resistance rating of 100 meters (10 ATM). This means it is suitable for:

- Daily use, including hand washing and splashes.
- Swimming in shallow water.
- Short showers.

It is **not** suitable for:

- Diving or snorkeling.
- Hot water activities (e.g., hot tubs, saunas), as steam can penetrate seals.
- Operating the crown or pushers while the watch is wet or submerged.

Prolonged contact with water may reduce the lifespan of the watch.

## 6. MAINTENANCE

---

### 6.1. Cleaning

To maintain the appearance and hygiene of your watch, regular cleaning is recommended. Use a soft, microfiber cleaning cloth to gently wipe the watch case and stainless steel bracelet. For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying.

### 6.2. Battery Replacement

As a quartz watch, the PD-1644 is powered by a battery. When the battery runs low, the second hand may start to move in two-second intervals (End-of-Life indicator). It is recommended to have the battery replaced by a qualified watch technician to ensure proper sealing and water resistance are maintained.

### 6.3. Storage

When not in use, store your watch in a cool, dry place, away from direct sunlight, extreme temperatures, and strong magnetic fields. The original gift box provides excellent protection.

## 7. TROUBLESHOOTING

---

If you encounter any issues with your watch, please refer to the following common problems and solutions:

- **Watch Not Running:** Check if the crown is pushed in completely. If it is, the battery may need

replacement.

- **Incorrect Time/Date:** Refer to Section 4 for instructions on setting the time and date.
- **Chronograph Hands Not Resetting to Zero:** Refer to Section 4.3 for chronograph hand zero reset instructions.
- **Condensation Under Crystal:** This may indicate a loss of water resistance. Avoid further water exposure and seek professional service immediately.

For issues not covered here, or if problems persist, please contact customer support or a professional watch repair service.

## 8. SPECIFICATIONS

---

<b>Model Number</b>	PD-1644
<b>Movement</b>	Japanese Seiko VK63 Quartz
<b>Case Material</b>	Stainless Steel
<b>Case Diameter</b>	40 mm (1.57 inches)
<b>Case Thickness</b>	12 mm (0.47 inches)
<b>Band Material</b>	Stainless Steel (or Rubber strap, depending on variant)
<b>Band Width</b>	20 mm
<b>Band Length</b>	220 mm (8.66 inches)
<b>Dial Window Material</b>	Synthetic Sapphire Crystal
<b>Water Resistance</b>	100 meters (10 ATM)
<b>Special Features</b>	Chronograph, Date Display, Luminous Dial

## 9. WARRANTY AND SUPPORT

---

### 9.1. Warranty Information

This product is covered by a seller's warranty. Please refer to your purchase documentation or contact the seller directly for specific terms and conditions of the warranty, including coverage period and claim procedures.

### 9.2. Customer Support

For any questions, technical assistance, or service requests regarding your Pagani Design PD-1644 watch, please contact the retailer or the official Pagani Design customer support channels. Keep your purchase receipt and model number handy for faster service.