

[Manuals.plus](#) /

› [DL-pro](#) /

› DL-pro Dryer Lint Filter User Manual

DL-pro 00656033

DL-pro Dryer Lint Filter Instruction Manual

Model: 00656033, 656033, JGJNV110

PRODUCT OVERVIEW

This DL-pro lint filter is a high-quality replacement part designed to ensure optimal performance of your tumble dryer. A functional lint filter is crucial for efficient drying and to prevent damage to your appliance.



Image: The DL-pro lint filter, shown from two angles, highlighting its design and components.

SPECIFICATIONS

Feature	Detail
Length	320 mm
Width	180 mm
Height	78 mm
Material	Plastic
Color	White

Holder Dimensions (L/W/H)	81 x 320 x 185 mm (closed) / 370 mm (unfolded)
Weight	400 grams



**PASSEND FÜR
SUITABLE FOR**

BOSCH
Seire 4, 6, 8,
SelfCleaning,
Avantixx 7, 8

SIEMENS
IQ300, IQ390, IQ500, IQ700,
IQ790, IQ800, IQ890

Balay, Constructa,
Gaggenau, Koenic,
Neff, Novamatic,
Pitsos, Profilo





Maße: 72 mm × 310 mm × 180 mm (geschlossen) / 350 mm (aufgeklappt)
Maße Halter: 81 mm × 320 mm × 185 mm (geschlossen) / 370 mm (aufgeklappt)

Dimensions: 72 mm × 310 mm × 180 mm (closed) / 350 mm (opened)
Holder dimensions: 81 mm × 320 mm × 185 mm (closed) / 370 mm (unfolded)

Image: Visual representation of the lint filter's dimensions and a list of compatible dryer models.

COMPATIBILITY

This lint filter is compatible with a wide range of tumble dryer models from various brands. Please compare your existing filter with the images and specifications provided to ensure a correct fit. Compatible brands and series include:

- **Bosch:** Serie 4, Serie 6, Serie 8, Avantixx 7, Avantixx 8, EcoAvantixx 7, EcoMaxx 7, Edition 25, Energy, Exxcel 7, Maxx 7, Maxx 8, selfcleaningCondenser, WINNER series.
- **Siemens:** IQ300, IQ390, IQ500, IQ590, IQ700, IQ790, IQ800, IQ890, EcoLogixx 7, EcoLogixx 8, iSensoric, Logixx 7, Logixx 8, Logixx 9, SC series.
- **Other Compatible Brands:** Balay, Constructa, Neff.

- **Part Numbers:** 00656033, 656033.

If your specific appliance model is not listed, please refer to the dimensions and images to verify compatibility or contact the manufacturer for assistance.

INSTALLATION AND REPLACEMENT

Replacing your dryer's lint filter is a straightforward process. Always ensure the dryer is unplugged from the power outlet before attempting any maintenance or part replacement.

1. **Locate the Filter:** The lint filter is typically located inside the dryer door opening, at the bottom of the drum.
2. **Remove Old Filter:** Grasp the handle or edges of the old filter and pull it straight out. It may require a gentle tug if lint has accumulated around it.
3. **Insert New Filter:** Align the new DL-pro lint filter with the slot. Gently push it into place until it sits securely and flush with the dryer opening. Ensure there are no gaps.




Image: A hand demonstrating the easy insertion of the lint filter into a dryer, illustrating the "Easy Application" process.

MAINTENANCE AND CLEANING

Regular cleaning of your lint filter is essential for the safety and efficiency of your dryer. A clogged filter can restrict airflow, increase drying time, and pose a fire hazard.

- **After Every Load:** Remove and clean the lint filter after every drying cycle. Simply pull off any accumulated lint by hand.
- **Monthly Deep Clean:** At least once a month, or more frequently if you use fabric softener sheets, wash the filter with warm, soapy water. Use a soft brush to remove any residue that may be clogging the mesh.
- **Rinse Thoroughly:** Rinse the filter thoroughly under running water to remove all soap residue.
- **Dry Completely:** Allow the filter to air dry completely before reinserting it into the dryer. Do not use the dryer with a wet filter.

TROUBLESHOOTING

If you experience issues with your dryer after replacing the lint filter, consider the following:

- **Dryer Not Drying Efficiently:**
 - Ensure the filter is clean and free of lint.
 - Check that the filter is fully seated and not obstructing airflow.
 - Verify that the dryer's exhaust vent is not clogged.
- **Filter Not Fitting Correctly:**
 - Double-check the model numbers and dimensions against your dryer's specifications.
 - Ensure no debris is in the filter slot preventing proper seating.

For persistent issues, consult your dryer's main instruction manual or contact a qualified appliance technician.

SUPPORT AND CONTACT

For further assistance or inquiries regarding your DL-pro lint filter, please refer to the official DL-pro website or contact their customer support. When contacting support, please have your product model number (00656033 or JGJNV110) and dryer model information ready.



Image: The DL-pro brand logo, representing the manufacturer of this product.

© 2025 DL-pro. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B08HR46589>

More documents and user manuals: **<https://manuals.plus/>**