

[Manuals.plus](#) /

› [MohMus](#) /

› MohMus Premium Microfiber Vacuum Cleaner Bags for Rowenta Compact Power RO 3953, RO 3953 EA - User Manual

MohMus Rowenta Compact Power RO 3953, RO 3953 EA, Silence Force 4A, RO64, ZR200520, ZR200540, ZR200720, ZR200740, ZR200920, ZR2

MohMus Premium Microfiber Vacuum Cleaner Bags

For Rowenta Compact Power RO 3953, RO 3953 EA, and compatible models

INTRODUCTION

Thank you for choosing MohMus Premium Microfiber Vacuum Cleaner Bags. These high-quality, multi-layer bags are designed to provide optimal filtration and maintain strong suction power for your compatible vacuum cleaner. This manual provides essential information for the proper installation, use, and maintenance of your new vacuum bags.

COMPATIBILITY


These MohMus vacuum cleaner bags are 100% compatible with the following models:

- **Rowenta Compact Power:** RO 3953, RO 3953 EA
- **Rowenta Silence Force 4A:** RO64, ZR200520, ZR200540, ZR200720, ZR200740, ZR200920, ZR200940, ZR 200720
- **Compatible with Swirl / Handy-bag:** R 39 / R39

Manufacturer names and references are used for compatibility reference only. These parts are not associated with the original manufacturer's parts.

SETUP: INSTALLING YOUR VACUUM BAG

1. **Power Off and Unplug:** Before attempting any installation or maintenance, ensure your vacuum cleaner is turned off and unplugged from the power outlet to prevent accidental startup.
2. **Open Vacuum Compartment:** Locate and open the dust bag compartment on your vacuum cleaner. This usually involves releasing a latch or pressing a button. Refer to your vacuum cleaner's original manual if you are unsure.
3. **Remove Old Bag (if applicable):** Carefully remove the full dust bag. Most vacuum bags have a closing mechanism or flap to prevent dust from escaping during removal. Dispose of the old bag responsibly.
4. **Insert New Bag:** Take a new MohMus microfiber vacuum bag. Align the bag's collar with the bag holder in your vacuum cleaner. Push firmly until the bag is securely seated. Ensure there are no gaps where dust could escape.
5. **Close Compartment:** Close the dust bag compartment securely. Make sure it latches properly.
6. **Check for Proper Fit:** Before operating, visually inspect that the bag is correctly installed and the compartment is fully closed.



Unsere Staubsaugerbeutel bestehen aus mehrlagigem Mikrovließ

Our vacuum cleaner dust bags are made of multi layer microfibre

Image 1: Illustration of the multi-layer microfiber construction of the vacuum bags, designed for enhanced filtration and durability.

OPERATING INSTRUCTIONS

Once the new vacuum bag is correctly installed, you can resume normal operation of your vacuum cleaner. These premium microfiber bags are designed to:

- Maintain high suction power throughout the bag's lifespan.
- Provide optimal filtration of fine dust particles, contributing to cleaner air.
- Offer robust construction to prevent tearing and dust leakage.



Unsere Staubsaugerbeutel sind aus sehr reißfestem Mikrovlies

Our vacuum cleaner dust bags are made of strong microfibres

Image 2: Detail showing the strong, tear-resistant microfiber material used in the vacuum bags, ensuring durability during use.

MAINTENANCE: WHEN TO REPLACE YOUR VACUUM BAG

Regular replacement of your vacuum bag is crucial for maintaining your vacuum cleaner's performance and ensuring effective dust collection. Replace the bag when:

- The "bag full" indicator on your vacuum cleaner illuminates.
- Suction power noticeably decreases, even if the indicator is not yet active.
- The bag appears visibly full or heavy when you open the compartment.

Do not attempt to empty and reuse disposable vacuum bags, as this can compromise filtration and damage your vacuum cleaner.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Reduced Suction Power	Bag is full or nearly full.	Replace the vacuum bag with a new one.
Reduced Suction Power	Bag not installed correctly.	Re-open the compartment and ensure the bag collar is securely seated in the holder.
Dust escaping from vacuum	Bag not installed correctly or compartment not closed.	Check bag installation and ensure the dust bag compartment is fully latched.
Bag does not fit	Incorrect bag model for your vacuum cleaner.	Verify your vacuum cleaner model against the compatibility list provided in this manual.

SPECIFICATIONS

- **Brand:** MohMus
- **Material:** Premium Multi-layer Microfiber
- **Quantity:** 10 Vacuum Cleaner Bags per pack
- **Compatibility:** Specifically designed for Rowenta Compact Power RO 3953, RO 3953 EA, and other listed compatible models (e.g., Rowenta Silence Force 4A series, Swirl / Handy-bag R 39 / R39).
- **Features:** High suction power, optimal fine dust filtration, tear-resistant.

WARRANTY AND SUPPORT

Information regarding specific warranty terms or direct support contacts for MohMus products is not available in this document. For any product-related inquiries or support, please refer to the retailer where the product was purchased or check the official MohMus website if available.

© 2023 MohMus. All rights reserved. This document is for informational purposes only.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B08HR7TY5S>

More documents and user manuals: <https://manuals.plus/>