

[Manuals.plus](#) /

› [DAEWOO](#) /

› Daewoo L43B7500QN 43-inch Full HD Smart TV User Manual

DAEWOO L43B7500QN

Daewoo L43B7500QN 43-inch Full HD Smart TV User Manual

Model: L43B7500QN

1. INTRODUCTION

This user manual provides essential information for the safe and efficient operation of your Daewoo L43B7500QN 43-inch Full HD Smart TV. Please read this manual thoroughly before using the television and retain it for future reference. It covers setup, operation, maintenance, and troubleshooting to ensure you get the most out of your new device.



Image 1.1: Front view of the Daewoo L43B7500QN 43-inch Full HD Smart TV.

2. SAFETY INFORMATION

Observe the following safety precautions to prevent fire, electric shock, or damage to the television.

- **Power Source:** Connect the TV only to an AC power outlet with the correct voltage as indicated on the TV's label.
- **Ventilation:** Ensure adequate ventilation around the TV. Do not block ventilation openings. Avoid placing the TV on beds, sofas, rugs, or similar surfaces that may block the vents.
- **Liquid Exposure:** Do not expose the TV to rain or moisture. Do not place objects filled with liquids, such as vases, on the TV.
- **Cleaning:** Unplug the TV from the power outlet before cleaning. Use a soft, dry cloth. Do not use liquid cleaners or aerosol cleaners.
- **Placement:** Place the TV on a stable, level surface to prevent it from falling. Keep the TV away from direct sunlight, heat sources, and strong magnetic fields.
- **Servicing:** Do not attempt to service this product yourself. Refer all servicing to qualified service personnel.

3. PACKAGE CONTENTS

Please check that all items are present upon unpacking:

- Daewoo L43B7500QN 43-inch Full HD Smart TV
- Remote Control
- Power Cord
- TV Stand (2 pieces)
- Screws for TV Stand
- User Manual (this document)

4. SETUP

4.1 Attaching the TV Stand

1. Carefully place the TV face-down on a soft, clean surface to prevent screen damage.
2. Align each stand piece with the corresponding slots on the bottom of the TV.
3. Secure each stand piece with the provided screws. Ensure they are tightened firmly.

4.2 Connecting Power

Plug the power cord into the TV's power input, then plug the other end into a wall outlet.

4.3 Connecting External Devices

Your TV features multiple ports for connecting external devices:

- **HDMI Ports:** For high-definition devices like Blu-ray players, game consoles, or set-top boxes.
- **USB Ports:** For connecting USB storage devices to play media files.
- **Ethernet Port:** For a wired internet connection.
- **Antenna/Cable Input:** For connecting an antenna or cable TV signal.

4.4 Initial Setup Wizard

Upon first power-on, the TV will guide you through an initial setup process:

1. **Language Selection:** Choose your preferred language.
2. **Network Connection:** Connect to your Wi-Fi network or use a wired Ethernet connection.
3. **Channel Scan:** Scan for available digital or analog channels.
4. **Time Zone:** Set your local time zone.

5. OPERATING

5.1 Remote Control Overview

The remote control allows you to access all TV functions. Familiarize yourself with the buttons for power, volume, channel, navigation, and smart TV access.

5.2 Basic Functions

- **Power On/Off:** Press the **POWER** button.
- **Volume Adjustment:** Use the **VOL +/-** buttons.
- **Channel Change:** Use the **CH +/-** buttons.
- **Mute:** Press the **MUTE** button to silence the audio.

5.3 Smart TV Features (Android OS)

Your Daewoo Smart TV runs on Android OS, providing access to a wide range of applications and streaming services.

- **Home Screen:** Press the **HOME** button to access the main Smart TV interface.
- **App Access:** Navigate through the app icons to launch pre-installed applications or download new ones from the app store.
- **Internet Browsing:** Use the built-in web browser to surf the internet.
- **Settings:** Access system settings to configure network, display, sound, and other preferences.

5.4 Input Source Selection

To switch between connected devices (e.g., HDMI 1, USB, TV tuner), press the **SOURCE** or **INPUT** button on your remote control and select the desired input.

6. MAINTENANCE

6.1 Cleaning the TV

- **Screen:** Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, slightly dampen the cloth with water or a specialized screen cleaner (do not spray directly onto the screen).
- **Cabinet:** Wipe the TV cabinet with a soft, dry cloth.
- **Important:** Always unplug the TV before cleaning. Avoid using abrasive cleaners, waxes, or solvents.

6.2 Software Updates

Periodically check for software updates through the TV's settings menu to ensure optimal performance and access to the latest features. Updates can be performed via Wi-Fi or Ethernet connection.

7. TROUBLESHOOTING

If you encounter issues with your TV, refer to the following common problems and solutions:

Problem	Possible Solution
No power	Check if the power cord is securely plugged into the TV and the wall outlet. Ensure the wall outlet is functional.
No picture, but sound is present	Verify the correct input source is selected. Check external device connections.
No sound, but picture is present	Check the volume level and ensure the TV is not muted. Verify audio cable connections for external devices.
Remote control not working	Replace the batteries in the remote control. Ensure there are no obstructions between the remote and the TV's IR sensor.
Cannot connect to Wi-Fi	Ensure your Wi-Fi router is on and working. Re-enter the Wi-Fi password. Try restarting both the TV and the router.

If the problem persists after trying these solutions, please contact customer support.

8. SPECIFICATIONS

Feature	Detail
Brand	DAEWOO
Model	L43B7500QN
Screen Size	43 Inches (110 cm)
Display Technology	LED
Resolution	1080p (Full HD)
Refresh Rate	60 Hz
Operating System	Android
Aspect Ratio	16:9
Connectivity	Ethernet, Bluetooth (for remote)
Mounting Type	Table Mount (Stand included)
Dimensions (with stand)	103 x 14 x 62 cm (approx.)
Weight	21 kg (approx.)
Model Year	2019

9. WARRANTY AND SUPPORT

Your Daewoo L43B7500QN TV is covered by a manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions, including the warranty period and coverage details. For technical support, service, or warranty claims, please contact Daewoo customer service through the contact information provided in your warranty documentation or on the official Daewoo website. Keep your purchase receipt as proof of purchase.

© 2023 DAEWOO. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B08HRB4NRF>

More documents and user manuals: <https://manuals.plus/>