

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [jumper](#) /

> [Jumper EZbook X3 Windows 10 Laptop Instruction Manual](#)

jumper X3 office

Jumper EZbook X3 Windows 10 Laptop Instruction Manual

Model: EZbook X3 Office | Brand: Jumper

1. PRODUCT OVERVIEW

The Jumper EZbook X3 is a lightweight and portable laptop designed for everyday computing tasks, online education, and basic productivity. It features a 13.3-inch display and comes pre-installed with Windows 10, offering a familiar and versatile operating environment. The device is equipped with 4GB of DDR3L RAM and 64GB of eMMC storage, with options for storage expansion.



Figure 1: Jumper EZbook X3 laptop with Windows desktop.



Figure 2: Jumper Tech brand illustration.

2. SETUP

Follow these steps for initial setup of your Jumper EZbook X3 laptop:

1. **Unboxing:** Carefully remove the laptop and all accessories from the packaging.
2. **Initial Charge:** Connect the power adapter to the DC-in port on the side of the laptop and plug it into a power outlet. Allow the device to charge fully before first use.
3. **Power On:** Press the power button located on the keyboard to turn on the laptop.
4. **Windows 10 Setup:** Follow the on-screen prompts to complete the Windows 10 initial setup, including language selection, network connection, and user account creation.
5. **Microsoft 365 Activation:** The laptop includes a 1-year Microsoft 365 Personal subscription. Activate it within 6 months of Windows activation. A credit card may be required, and subscription fees apply after the first year unless canceled.

Your browser does not support the video tag.

Video 1: Official Jumper Tech video demonstrating the Windows 10 laptop with Office 365. This video highlights the laptop's features and its pre-installed software.

3. OPERATING INSTRUCTIONS

Familiarize yourself with the key components and ports of your Jumper EZbook X3.

Keyboard and Trackpad

The laptop features a full-sized keyboard for comfortable typing. The integrated trackpad supports multi-touch gestures for navigation. While the keyboard offers good key travel, the trackpad's click functionality may require precise positioning.



Figure 3: User interacting with the keyboard and trackpad of the Jumper EZbook X3.

Ports and Connectivity

The EZbook X3 offers essential ports for connectivity and expansion:

- **USB 3.0 Ports:** Two USB 3.0 ports are available for connecting peripherals and external storage.
- **HDMI Output:** A mini HDMI port allows connection to external monitors or displays.
- **TF Card Slot:** Expand storage with a TF (microSD) card, supporting up to 256GB.
- **3.5mm Headphone Jack:** For audio output to headphones or external speakers.
- **DC-in Port:** For connecting the power adapter.



Figure 4: Side view of the Jumper EZbook X3 highlighting available ports.

Your browser does not support the video tag.

Video 2: A short video showcasing the lightweight and thin design of the Jumper EZbook X3, demonstrating its portability.

4. MAINTENANCE

To ensure optimal performance and longevity of your Jumper EZbook X3, regular maintenance is recommended:

- **Software Updates:** Regularly check for and install Windows updates to keep your operating system secure and up-to-date.
- **Driver Updates:** Ensure all device drivers are current for best hardware compatibility and performance.
- **Physical Cleaning:** Use a soft, dry cloth to clean the screen and exterior. Avoid abrasive cleaners. Keep the keyboard free of dust and debris.
- **Storage Management:** Periodically review and manage your storage to free up space, especially on the 64GB eMMC drive. Consider using the mSATA slot for additional storage.

5. TROUBLESHOOTING

If you encounter issues with your Jumper EZbook X3, consider the following troubleshooting steps:

- **Slow Performance:** If the laptop feels sluggish, check for background applications consuming resources. Ensure sufficient free storage space and consider upgrading storage via the mSATA slot.
- **Battery Life:** For optimal battery life, adjust screen brightness and close unnecessary applications. The advertised battery life is around 6 hours for general use.
- **Display Issues:** If the screen appears dim or has color inaccuracies, check display settings in Windows. The IPS FHD display offers good viewing angles but may have a cooler color temperature.
- **Connectivity Problems:** Ensure Wi-Fi is enabled and connected to a stable network. For external devices, verify correct port usage and driver installation.
- **Power On Failure:** If the laptop does not power on, ensure it is properly charged and the power adapter is

functioning correctly.

6. SPECIFICATIONS

Key technical specifications for the Jumper EZbook X3 laptop:


Feature	Specification
Standing Screen Display Size	11 Inches
Screen Resolution	1280 x 800 pixels
Max Screen Resolution	1080*1020 Lines Per Inch
Processor	1.2 GHz Celeron 3865U
RAM	4 GB DDR3L
Hard Drive	36 GB HDD (eMMC 64GB Flash Memory)
Graphics Coprocessor	500 (Integrated Intel Graphics)
Operating System	Windows 10
Item Weight	2.7 pounds
Product Dimensions	12.4 x 8.1 x 0.71 inches
Color	BLACK SLIVE



IPS FHD



1920x1080



Narrow Bezel



Figure 5: Display features of the Jumper EZbook X3.

Free Office 1 Year



Figure 6: Jumper EZbook X3 with Microsoft Office 365 on screen.

7. WARRANTY AND SUPPORT

For any product-related issues or support, please refer to the following information:

- **Warranty Period:** Information regarding the warranty period is available upon contacting support.
- **After-sales Service:** If you have any problems with the products, please feel free to contact us. We are always here to provide help!
- **Contact Us:** Find your order and click "Get Product Support." We will assist you within 24 hours.
- **Jumper Support Phone Number:** 4008333331
- **Support Hours:** Monday to Saturday 9:00-18:30 (except statutory holidays)
- **Website:** Online support