

[Manuals.plus](#) /

› [edding](#) /

› edding 5000 Acrylic Marker Broad - Neon Colours Instruction Manual

edding 4-5000-5

edding 5000 Acrylic Marker Broad - Neon Colours

Brand: edding | **Model:** 4-5000-5

INTRODUCTION

The edding 5000 acrylic paint markers offer a modern and convenient way to apply acrylic paint. Designed for ease of use, these markers feature a valve system that ensures a consistent and even flow of paint directly onto your chosen surface. This allows for spontaneous creativity and precise application, making them suitable for various artistic projects. This set includes 5 acrylic markers in vibrant neon colors: traffic-white, black, neon-yellow, neon-orange, and neon-pink. The broad chisel nib allows for both thick lines and the coloring of larger areas, while the narrow edge can be used for finer strokes. The water-based ink is waterproof, pigmented, opaque, lightfast, and permanent, providing a matt finish once dry.



Image: The front packaging of the edding 5000 acrylic marker broad set, highlighting the neon colors and key features.


SETUP AND FIRST USE

Before using your edding 5000 acrylic marker for the first time, it must be activated to ensure proper ink flow. Follow these steps:

1. **Shake Vigorously:** With the cap still on, shake the marker vigorously. This helps to mix the pigment and prepare the ink for flow.
2. **Remove Cap:** Carefully remove the cap from the marker.
3. **Prime the Nib:** With the nib facing down, place the marker on a piece of test paper. Carefully press down on the paper a few times until the ink visibly fills the tip. Ensure you pump along the entire length of the slanted chisel nib, not just on

the point.

4. **Ready for Use:** Once the ink has filled the tip, the marker is ready for your creative projects.




Images: Demonstrations of shaking the marker, priming the nib, and making a broad stroke.

OPERATING THE MARKERS

The edding 5000 markers are versatile and can be used on various surfaces, including canvas, wood, and paper. Their broad chisel nib allows for different stroke widths:

- **Broad Edge:** Use the broad edge of the nib for drawing thicker lines and efficiently coloring larger areas.
- **Narrow Edge:** The narrow edge of the nib is ideal for creating thinner lines and adding fine details.

Colors can be blended or layered to achieve desired effects. These acrylic markers also complement edding 5200 permanent spray products; once the spray paint is dry, you can draw over it with the acrylic pens. The color palettes of both product types are designed to be coordinated.



MAINTENANCE AND STORAGE

To ensure the longevity and optimal performance of your edding 5000 acrylic markers, please follow these maintenance and storage guidelines:

- **Cap Storage:** The cap can be conveniently stored on the end of the marker while in use.
- **Horizontal Storage:** Always store the markers horizontally to prevent the nib from drying out or ink from pooling at one end.
- **Room Temperature:** Store the markers at room temperature, ideally between 5-30 °C (41-86 °F), to maintain ink consistency.
- **Replacement Nibs:** Replacement tips are available for purchase, extending the life of your markers.



Image: A display of the edding 5000 acrylic markers, illustrating their design and nib type.

TROUBLESHOOTING

The edding 5000 acrylic markers are designed for reliable performance. Most common issues can be resolved by ensuring the marker is properly activated as described in the "Setup and First Use" section. If the ink flow is inconsistent or the marker appears dry, re-shake the marker vigorously with the cap on, then re-prime the nib by pressing it down on a test surface until ink flows consistently.

For any persistent issues not resolved by these steps, please refer to the manufacturer's official support channels.

SPECIFICATIONS

Feature	Detail
Brand	edding
Item Model Number	4-5000-5
Color	28: Set of 5 - Multicoloured (Traffic-white, black, neon-yellow, neon-orange, neon-pink)
Point Type	Chisel
Line Size	5-10mm
Ink Type	Acrylic, Permanent, Water-based, Opaque, Lightfast, Waterproof
Finish	Matt
Item Weight	14.5 ounces
Product Dimensions	1.26 x 6.38 x 7.48 inches
Country of Origin	Germany

WARRANTY AND SUPPORT

For information regarding product warranty, returns, or technical support, please refer to the official edding website or contact their customer service directly. Details can typically be found on the product packaging or the manufacturer's official online resources.

You can visit the [edding Store on Amazon](#) for more products and information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question