

[manuals.plus](#) /

› [KRUPS](#) /

› [Krups Nescafé Dolce Gusto Piccolo XS Capsule Coffee Machine User Manual](#)

KRUPS KP1A3BKA

Krups Nescafé Dolce Gusto Piccolo XS Capsule Coffee Machine

USER MANUAL

1. Introduction and Overview

The Krups Nescafé Dolce Gusto Piccolo XS is a compact and versatile capsule coffee machine designed for preparing a wide range of hot and cold beverages. Featuring a 15-bar high-pressure pump, it ensures optimal extraction for rich flavors. Its intuitive design and automatic shut-off after one minute of inactivity contribute to ease of use and energy efficiency.



Figure 1: Overall view of the Krups Nescafé Dolce Gusto Piccolo XS coffee machine.

FORMAT ULTRA-COMPACT



Figure 2: Compact dimensions of the Piccolo XS machine.

+ DE 45 CHOIX DE BOISSONS



Figure 3: The machine supports a wide variety of Nescafé Dolce Gusto beverages.

2. Setup

- 1. Unpacking:** Carefully remove all packaging materials from the machine and its components.
- 2. Rinsing:** Before first use, fill the water tank with fresh, clean water. Run two cycles with water only (no capsule) to clean the internal system.
- 3. Water Tank:** The removable 0.8-liter water tank is located at the back of the machine. Fill it with fresh, clean water.
- 4. Power Connection:** Plug the machine into a suitable power outlet.

3. Operating Instructions

- 1. Power On:** Press the power button. The indicator light will turn green when the machine is ready for use.
- 2. Insert Capsule:** Lift the locking handle, pull out the capsule holder, insert a Nescafé Dolce Gusto capsule, and push the holder back into place. Lower the locking handle until it clicks.

UN CAFÉ FRAIS, RICHE EN ARÔMES



Figure 4: Inserting a Nescafé Dolce Gusto capsule.

3. **Select Beverage Temperature:** Use the manual lever to select either hot (red position) or cold (blue position) water, depending on your desired beverage.



Figure 5: Operating the manual lever for hot or cold beverages.

4. **Brewing:** Move the lever to the desired position (hot or cold). The machine will begin dispensing water through the capsule.
5. **Stop Brewing:** Manually return the lever to the central position to stop the water flow when your cup is filled to the desired level.
6. **Adjust Drip Tray:** The drip tray can be adjusted to different heights to accommodate various cup sizes.

4. Maintenance

- **Exterior Cleaning:** Regularly wipe the exterior of the machine with a damp, soft cloth. Do not use abrasive cleaners.
- **Water Tank Cleaning:** Remove the water tank, wash it with mild detergent, and rinse thoroughly.
- **Capsule Holder Cleaning:** After each use, remove and rinse the capsule holder under running water.
- **Descaling:** Descale the machine every 3-4 months, or as indicated by the machine's behavior (e.g., slower flow, reduced temperature). Use a Nescafé Dolce Gusto descaling kit or a suitable descaling solution. Follow the descaling product instructions carefully.

5. Troubleshooting

- **No Water Flow:**

- Ensure the water tank is filled correctly and properly seated.
- Verify the capsule is inserted correctly and the locking handle is fully lowered.
- Check for blockages in the needle (refer to descaling instructions for cleaning).

- **Machine Not Turning On:**

- Confirm the power cord is securely plugged into both the machine and a working wall outlet.
- Check the power switch.

- **Coffee Not Hot Enough:**

- Pre-heat your cup with hot water before brewing.
- Ensure the machine has fully heated up (the indicator light should be green).

- **Leaking:**

- Check if the water tank is correctly positioned and sealed.
- Ensure the capsule holder is properly closed and the capsule is not damaged.

6. Specifications

Brand	KRUPS
Model Number	KP1A3BKA
Color	Black
Dimensions (L x W x H)	28 x 14 x 27 cm
Weight	2 Kilograms
Power	1500 Watts
Voltage	220 Volts
Material	Plastic
Water Tank Capacity	0.8 Liters (removable)
Pressure	15 bars
Special Features	Removable tank, Automatic shut-off (1 minute inactivity), Thermoblock system, Hot & Cold function

7. Warranty and Support

This product comes with a standard manufacturer's warranty. Please refer to the warranty card included in the packaging for specific terms and conditions regarding coverage and duration.

For technical support, spare parts, or further assistance, please contact KRUPS customer service or visit their official website. Contact details can typically be found in the product packaging or on the KRUPS website.

8. Product Videos

No official product videos were available in the provided product data to embed in this manual.