

Poolcandy PC3025TR

Poolcandy Tube Runner Motorized Pool Tube Instruction Manual

Model: Motorized Tube Runner (PC3025TR)

Brand: Poolcandy

INTRODUCTION

Welcome to the Poolcandy Tube Runner Motorized Pool Tube. This deluxe inflatable float is designed to provide effortless movement and relaxation in pools and lakes. Featuring a powerful battery-powered motor and 360-degree control, it offers a unique water experience for adults, teens, and kids. Please read this manual thoroughly before use to ensure safe and optimal operation.

IMPORTANT SAFETY INFORMATION


- Adult supervision is required for children using this product.
- Do not exceed the maximum weight limit of **250 pounds**.
- Ensure the 3-blade propeller is fully enclosed behind its protective safety grill before and during use.
- Keep the battery compartment dry. Always remove batteries when the float is not in use or before long-term storage to prevent corrosion and damage.
- This product is intended for use in calm water environments such as pools and lakes. Do not use in strong currents, open ocean, or areas with heavy boat traffic.
- Inspect the float and motor unit for any damage or leaks before each use. Do not use if damaged.
- This is not a life-saving device. Users should be proficient swimmers.

PRODUCT COMPONENTS

Your Poolcandy Tube Runner includes the following main components:

- Inflatable Tube Runner float (48" diameter, 40 MM Heavy Duty PVC)
- Motor unit with 3-blade propeller

- Control joystick



This image highlights the main features of the Tube Runner, including the large backrest, grip handles, convenient cup holder, and the 66W 360-degree thrust motor. The float is constructed from 40 MM Heavy Duty PVC.

SETUP GUIDE

1. Inflation

Locate the air valves on the inflatable tube. Use a standard air pump (not included) to inflate the float until it is firm to the touch but not overinflated. Ensure all valves are securely closed after inflation.

2. Battery Installation

The Tube Runner motor requires **6 D-cell batteries** (not included).

1. Locate the battery compartment on the motor unit.
2. Carefully open the compartment.
3. Insert 6 D-cell batteries, ensuring correct polarity (+ / -) as indicated inside the compartment.
4. Securely close the battery compartment cover to prevent water ingress.



This image demonstrates the correct way to install the 6 D-cell batteries into the motor unit. Proper battery installation and a secure seal are crucial for operation and to prevent water damage.

3. Motor Attachment

Insert the motor unit into the designated opening on the underside of the float. Ensure it is securely fastened and the propeller is positioned correctly beneath the float. The control joystick should be easily accessible from the seating area.

Your browser does not support the video tag.

Official product video demonstrating the setup and use of the Poolcandy Tube Runner. This video provides a visual guide on how to set up the Tube Runner, including inflation, battery installation, and attaching the motor. It also shows the float in action, highlighting its features and ease of use.

OPERATING INSTRUCTIONS

Getting Started

Once the Tube Runner is inflated and the motor is installed, carefully place it in the water. Sit comfortably in the center of the

float.


Control

The Tube Runner is controlled by a single joystick, offering intuitive 360-degree movement:

- Push the joystick **forward** to move forward.
- Pull the joystick **backward** to move in reverse.
- Move the joystick **left or right** to turn in those directions.
- The 360-degree control allows for full maneuverability, including spinning in place.



This image shows a user comfortably seated on the Tube Runner, holding the control joystick. The float is designed for easy navigation and relaxation in the water.



This image illustrates the motor's position beneath the float and emphasizes its ability to provide full 360-degree movement, allowing for versatile navigation in the water.

CARE AND MAINTENANCE

- **Cleaning:** After each use, rinse the float and motor unit with fresh water to remove chlorine, salt, or debris.
- **Drying:** Thoroughly dry all components, especially the motor and battery compartment, before storage. Water ingress into the battery compartment can cause damage.
- **Battery Care:** Always remove batteries from the motor unit when the float is not in use or before long-term storage. This prevents corrosion and extends battery life.
- **Storage:** Store the deflated float and motor in a cool, dry place away from direct sunlight and extreme temperatures. Avoid folding the float tightly to prevent creases or damage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Motor not working	Dead or improperly installed batteries	Replace batteries with fresh D-cells, ensuring correct polarity.
Motor not working	Water in battery compartment / corrosion	Open compartment, dry thoroughly. Check for corrosion on terminals; clean if necessary. Ensure compartment is sealed properly after battery installation.
Motor not working	Propeller obstructed	Carefully check the propeller for any debris (weeds, hair, etc.) and remove.
Float losing air	Improperly sealed valve	Ensure all air valves are securely closed.
Float losing air	Puncture or leak	Locate the leak (e.g., using soapy water) and repair with a vinyl repair kit (often included or sold separately).

PRODUCT SPECIFICATIONS

Feature	Detail
Size	Large
Color	blue
Brand	Poolcandy
Material	Polyvinyl Chloride
Product Dimensions	48"L x 48"W
Item Weight	8.7 Pounds
Age Range (Description)	Adult, Teen
UPC	810048540976
Manufacturer	B&D Group
Weight Limit	250 Pounds
Model Name	Motorized Tube Runner

Feature	Detail
Part Number	PC3025TR
Battery Requirement	6 D Batteries

WARRANTY INFORMATION

The Poolcandy Tube Runner Motorized Pool Lounger comes with a **One-Year warranty** provided by B&D Group. This warranty covers manufacturing defects and ensures confidence in your purchase. For warranty claims or detailed terms, please refer to the customer support contact information below.

CUSTOMER SUPPORT

For further assistance, questions, or troubleshooting not covered in this manual, please contact Poolcandy customer support:

Website: www.poolcandy.net

Email: support@poolcandy.net