

## Logitech MX Master 3

# Logitech MX Master 3 Advanced Bluetooth Mouse for Mac

Model: MX Master 3

## INTRODUCTION

---

The Logitech MX Master 3 Advanced Bluetooth Mouse for Mac is designed for optimal performance and comfort, specifically tailored for macOS and iPad compatibility. It features a quiet click, precise tracking on various surfaces including glass, and an ultrafast MagSpeed scroll wheel for efficient navigation. This manual provides essential information for setting up, operating, and maintaining your device.

## WHAT'S IN THE BOX

---

- 1 x Logitech MX Master 3 Advanced Bluetooth Mouse for Mac
- 1 x USB-C to USB-C Charging Cable

*Note: This 'for Mac' version is designed for Bluetooth connectivity and typically does not include a USB receiver dongle.*

## SETUP

---

1. **Charge the Mouse:** Connect the included USB-C charging cable to the mouse and a power source. The LED indicator will show charging status.
2. **Power On:** Locate the power switch on the bottom of the mouse and slide it to the ON position.
3. **Pair with Device:**
  - On the bottom of the mouse, press the Easy-Switch button (labeled 1, 2, or 3) to select an available channel. The corresponding LED will blink rapidly.
  - On your Mac or iPad, go to Bluetooth settings and select "MX Master 3 for Mac" from the list of available devices to pair.
  - For detailed setup instructions and software downloads, visit [MXsetup.logi.com](https://www.logitech.com/uk/en/support/mx-master-3-for-mac).



Image: The Logitech MX Master 3 Advanced Bluetooth Mouse for Mac shown in its retail packaging. The mouse is dark grey with silver accents, featuring a sculpted ergonomic design, a main scroll wheel, a thumb scroll wheel, and multiple programmable buttons.

## OPERATING INSTRUCTIONS

---

The MX Master 3 for Mac offers intuitive controls and advanced features to enhance your workflow:

- **MagSpeed Scroll Wheel:** The main scroll wheel provides two modes: hyper-fast scrolling for long documents and pixel-precise scrolling for detailed work. The mouse intelligently switches between these modes based on your scrolling speed, or you can manually switch using the function button.
- **Thumb Scroll Wheel:** Located on the side, this wheel allows for horizontal scrolling, useful for navigating spreadsheets or video timelines.
- **Thumb Buttons:** Two customizable buttons are positioned near the thumb rest for easy access to forward/back navigation or other assigned functions.
- **Gesture Button:** The thumb rest itself acts as a gesture button. Hold it down and move the mouse in different directions to activate macOS gestures like switching desktops, opening Mission Control, or displaying Launchpad.
- **Easy-Switch Button:** On the bottom of the mouse, this button allows you to quickly switch between up to three paired devices (e.g., Mac, iPad).

## CUSTOMIZATION

---

Unlock the full potential of your MX Master 3 for Mac by customizing its buttons and gestures using the Logitech Options software. This software allows you to:

- Assign specific functions to each button and gesture.
- Create app-specific profiles, so your mouse behaves differently in various applications (e.g., different shortcuts for Photoshop vs. a web browser).
- Adjust tracking speed (DPI) and scrolling sensitivity.

Visit [www.logitech.com/options](http://www.logitech.com/options) to download the software.

## MAINTENANCE

---

To ensure the longevity and optimal performance of your mouse, follow these maintenance tips:

- **Cleaning:** Use a soft, lint-free cloth to wipe the mouse surface. For stubborn dirt, slightly dampen the cloth with water. Avoid harsh chemicals or abrasive materials.
- **Sensor:** Keep the optical sensor on the bottom of the mouse clean and free from dust or debris for accurate tracking.
- **Battery:** Charge the mouse regularly. Avoid completely draining the battery frequently to prolong its lifespan.
- **Storage:** When not in use for extended periods, turn off the mouse to conserve battery life.

## TROUBLESHOOTING

---

If you encounter issues with your MX Master 3 for Mac, try the following:

- **Mouse Not Responding:**
  - Ensure the mouse is powered on.
  - Check the battery level and charge if necessary.
  - Verify Bluetooth is enabled on your Mac/iPad and the mouse is paired to the correct channel (1, 2, or 3).
  - Try re-pairing the mouse with your device.
- **Erratic Cursor Movement:**
  - Clean the optical sensor on the bottom of the mouse.
  - Ensure you are using the mouse on a suitable surface. While it tracks on glass, extreme textures or highly reflective surfaces might affect performance.
- **Customizations Not Working:** Ensure the Logitech Options software is installed and running on your Mac.

For further assistance, refer to the Logitech support website.

## SPECIFICATIONS

---

<b>Product Dimensions</b>	4.92 x 3.32 x 2.01 inches
<b>Item Weight</b>	5 ounces
<b>Item Model Number</b>	910-005693-cr
<b>Batteries</b>	1 Lithium Polymer battery required (included)
<b>Manufacturer</b>	Logitech
<b>Brand</b>	Logitech
<b>Color</b>	Space Grey
<b>Connectivity Technology</b>	Bluetooth
<b>Special Feature</b>	Wireless

<b>Movement Detection Technology</b>	Optical (Darkfield 4000 DPI sensor)
--------------------------------------	-------------------------------------

## WARRANTY AND SUPPORT

---

Your Logitech MX Master 3 Advanced Bluetooth Mouse for Mac is covered by Logitech's standard manufacturer warranty. For specific warranty details, registration, and technical support, please visit the official Logitech support website:

[Logitech Support](#)

You can also find FAQs, troubleshooting guides, and driver downloads on their website.