

manuals.plus /

› [Sandisk](#) /

› [SanDisk 32GB 3-Pack Ultra USB 3.0 Flash Drive SDCZ48-032G-GAM46T Instruction Manual](#)

Sandisk SDCZ48-032G-GAM46T

SanDisk 32GB 3-Pack Ultra USB 3.0 Flash Drive Instruction Manual

Model: SDCZ48-032G-GAM46T | Brand: SanDisk

1. INTRODUCTION

Thank you for choosing the SanDisk Ultra USB 3.0 Flash Drive. This high-speed USB 3.0 flash drive is designed for fast data transfer, allowing you to move videos, photos, and files efficiently. It offers reliable storage and features like password protection to keep your private files secure. This manual provides essential information on setting up, operating, maintaining, and troubleshooting your flash drive.

**Bis zu 5-mal schnellere Datenübertragungen
als mit herkömmlichen USB-2.0-Laufwerken^{1B}**



^{1B}USB-3.0-Anschluss erforderlich. Basierend auf unternehmensinternen Tests; die Leistung kann je nach Hostgerät geringer sein. 1 MB = 1.000.000 Byte.

Image 1: SanDisk Ultra USB 3.0 Flash Drive, showcasing its compact design.

2. SETUP

2.1 System Requirements

- USB 3.0 port for optimal performance (backward compatible with USB 2.0).
- Compatible with Windows 7, Windows 8, Windows 10, and macOS v10.9+ (software download required for Mac for password protection).

2.2 Connecting the Flash Drive

1. Locate an available USB port on your computer. For best performance, use a USB 3.0 port (often identified by a blue insert).
2. Slide the connector out from the drive casing.
3. Insert the SanDisk Ultra USB 3.0 Flash Drive firmly into the USB port.
4. Your computer should automatically detect the drive. A new drive letter will appear in 'My Computer' (Windows) or on the desktop (macOS).

Kompatibel mit USB 3.0, abwärtskompatibel mit USB 2.0




Image 2: A hand inserting the SanDisk Ultra USB 3.0 Flash Drive into a laptop's USB port, demonstrating its compatibility with USB 3.0 and backward compatibility with USB 2.0.

3. OPERATING THE FLASH DRIVE

3.1 Transferring Files

To transfer files to or from your SanDisk Ultra USB 3.0 Flash Drive:

1. Open the drive from 'My Computer' (Windows) or the desktop (macOS).
2. Drag and drop files or folders from your computer to the flash drive, or vice versa.
3. For faster transfers, ensure you are using a USB 3.0 port. Transfer speeds can be up to 10 times faster than standard USB 2.0 drives, with read speeds up to 130MB/s.



Image 3: Visual representation of files being transferred quickly from a laptop to the SanDisk Ultra USB 3.0 Flash Drive, highlighting its high-speed transfer capabilities.

3.2 Password Protection

The SanDisk Ultra USB 3.0 Flash Drive supports secure file encryption and password protection using 128-bit AES encryption. This feature requires software installation (SanDisk PrivateAccess™) which is supported by Windows 7, Windows 8, Windows 10, and macOS v10.9+ (software download required for Mac). Refer to the included software documentation for detailed instructions on setting up password protection.

4. MAINTENANCE

4.1 Protecting the Connector

The drive features a retractable design to protect the USB connector when not in use. Always retract the connector before storing the drive to prevent dust and physical damage.



Einziehbares Design schützt den Stecker

Image 4: Close-up of the SanDisk Ultra USB 3.0 Flash Drive showing its retractable connector, designed to protect the USB plug from damage and debris.

4.2 Safe Removal

Always safely eject the flash drive from your computer before physically removing it to prevent data corruption. On Windows, use the 'Safely Remove Hardware' icon in the system tray. On macOS, drag the drive icon to the Trash or use the 'Eject' option.

4.3 Data Recovery

The SanDisk Ultra USB 3.0 Flash Drive includes a one-year offer for RescuePRO Deluxe data recovery software. This software can help recover accidentally deleted files. Registration is required, and terms and conditions apply. Visit the SanDisk website for more details and to download the software.



Image 5: A laptop screen showing the RescuePRO Deluxe software interface, illustrating its function for convenient file recovery.

5. TROUBLESHOOTING

5.1 Drive Not Detected

- Try inserting the drive into a different USB port on your computer.
- Test the drive on another computer to rule out a computer-specific issue.
- Ensure the drive's connector is fully extended and free of debris.
- Check your computer's Device Manager (Windows) or Disk Utility (macOS) to see if the drive is recognized but not assigned a drive letter.

5.2 Slow Transfer Speeds

- Ensure you are connected to a USB 3.0 port. USB 2.0 ports will result in slower speeds.
- Avoid transferring many small files simultaneously; compressing them into a single archive can improve speed.
- Close other applications that might be using system resources or accessing the drive.

5.3 Data Corruption

- Always use the 'Safely Remove Hardware' or 'Eject' function before disconnecting the drive.
- If data corruption occurs, try using the RescuePRO Deluxe software (if applicable) to recover files.
- Consider reformatting the drive if issues persist, but be aware this will erase all data.

6. SPECIFICATIONS

| Feature | Detail |
|-------------------------|-----------------------------------|
| Brand | Sandisk |
| Model Name | SanDisk Ultra USB 3.0 Flash Drive |
| Model Number | SDCZ48-032G-GAM46T |
| Memory Storage Capacity | 32 GB (Pack of 3) |
| Hardware Interface | USB 3.0 |

| Feature | Detail |
|--------------------|------------------------------------|
| Read Speed | Up to 130 Megabytes Per Second |
| Write Speed | 40 MB per second |
| Special Feature | Lightweight, Retractable Connector |
| Compatible Devices | Desktop Computer, Laptop |
| Color | Black |
| Item Weight | 27.22 g |

7. WARRANTY

The SanDisk Ultra USB 3.0 Flash Drive comes with a **5-year Manufacturer Warranty**. Please retain your proof of purchase for warranty claims. For full details on warranty coverage and terms, please visit the official SanDisk website or contact customer support.

8. SUPPORT

For further assistance, technical support, or to access additional resources, please visit the official SanDisk support website:

- **SanDisk Support Website:** www.sandisk.com/support
- **Product Page:** [Amazon Product Page](#)

You may also find helpful information and FAQs on the SanDisk brand store on Amazon: [Visit the SanDisk Store](#)