

[Manuals.plus](#) /

› [Zerodis](#) /

› Zerodis Replacement Main Brush for Cecotec Conga 3490 4090 Robot Vacuum Cleaners

Zerodis Conga 3490 4090

Zerodis Replacement Main Brush User Manual

Model: For Cecotec Conga 3490 4090 and compatible robot vacuums

1. INTRODUCTION

Thank you for choosing the Zerodis Replacement Main Brush. This product is designed to restore the cleaning efficiency of your compatible robot vacuum cleaner, specifically models like the Cecotec Conga 3490 and 4090. Regular replacement of the main brush is crucial for maintaining optimal performance, ensuring effective dirt, dust, and debris collection from various floor surfaces.



Image: Top view of the Zerodis Replacement Main Brush, showcasing its design and bristles.

2. PRODUCT FEATURES

- **Effective Cleaning:** Designed to efficiently remove dirt, dust, and trash from corners and edges, including pet hair and human hair.
- **Optimal Performance:** Helps maintain your robot vacuum's best cleaning performance by ensuring consistent contact with the floor.
- **Easy Installation:** Features a user-friendly design that allows for quick and tool-free replacement as part of routine maintenance.
- **Durable Construction:** Made from high-strength, environmentally friendly Acrylonitrile Butadiene Styrene (ABS) material for long-lasting use.



Made of high quality material, durable.

Easy to remove dirt, dust and trash in corners and edges effectively.



Image: The Zerodis main brush in the foreground, with a robot vacuum cleaner operating on a hard floor in the background, illustrating its function in dirt removal.

3. SETUP AND INSTALLATION

Replacing the main brush is a simple process that does not require any special tools. Follow these steps to install your new Zerodis main brush:

1. Turn off your robot vacuum cleaner and place it upside down on a clean, flat surface.
2. Locate the main brush compartment, usually secured by a cover or latch.
3. Open the compartment and carefully remove the old main brush. Note its orientation for correct installation of the new brush.
4. Insert the new Zerodis main brush into the compartment, ensuring that its ends align correctly with the designated slots or bearings.
5. Close the main brush compartment cover securely.
6. Flip your robot vacuum back over and power it on.



Image: Detailed view of the ends of the Zerodis Main Brush, showing the connection points for easy installation into the vacuum cleaner.

4. OPERATING

Once installed, the Zerodis Replacement Main Brush operates automatically as part of your robot vacuum cleaner's normal cleaning cycle. The brush's design ensures optimal contact with various floor types, including hard floors, tiles, and carpets, to effectively sweep debris into the vacuum's suction path. No additional user intervention is required for the brush's operation after installation.



Image: The Zerodis Main Brush positioned next to a robot vacuum cleaner on a tiled floor, demonstrating its intended use and compatibility.

5. MAINTENANCE

To ensure your robot vacuum continues to operate at its best, regular maintenance of the main brush is recommended. This includes:

- **Regular Cleaning:** Periodically remove the main brush and clean any tangled hair or debris from the bristles and ends. This prevents blockages and maintains effective sweeping.
- **Replacement Frequency:** It is recommended to replace the main brush every 2 to 3 months, depending on your usage frequency and the amount of debris collected. Timely replacement ensures consistent cleaning performance and prolongs the lifespan of your vacuum cleaner.

6. TROUBLESHOOTING

If you experience issues after replacing the main brush, consider the following:

- **Brush Not Spinning:** Ensure the brush is correctly installed and seated in its compartment. Check for any obstructions or tangled debris preventing rotation.

- **Reduced Cleaning Performance:** If the vacuum's cleaning performance is still poor after replacement, verify that the brush is clean and free of excessive wear. Ensure the vacuum's suction path is clear.
- **Unusual Noises:** A new brush should not cause unusual noises. Re-check installation to ensure no parts are misaligned or loose.

7. SPECIFICATIONS

Attribute	Detail
Brand	Zerodis
Item Type	Main Brush
Material	Acrylonitrile Butadiene Styrene (ABS)
Color	Blue
Length	Approx. 19cm / 7.5in
Weight	Approx. 50g / 1.8oz (1.76 ounces)
Compatibility	Cecotec Conga 3490, 4090, and compatible robot vacuums
Specific Uses	Floor, Kitchen
Surface Recommendation	Floor, Tile, Metal, Plastic, Carpet, Ceramic, Wood



Image: Side view of the Zerodis Main Brush, indicating its approximate length of 19cm (7.5 inches).

8. WARRANTY AND SUPPORT

For any questions or support regarding your Zerodis Replacement Main Brush, please refer to the seller's return policy or contact customer service through the platform where the purchase was made. Zerodis is committed to providing quality household products and customer satisfaction.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B08HV9FHDC>

More documents and user manuals: **<https://manuals.plus/>**