VOTON V-1527I

VOTON V-1527I Matte Black Waterfall Bathroom Faucet Instruction Manual

1. Introduction

This manual provides detailed instructions for the installation, operation, maintenance, and troubleshooting of your new VOTON V-1527I Matte Black Waterfall Bathroom Faucet. Please read this manual thoroughly before installation and retain it for future reference. Proper installation and care will ensure optimal performance and longevity of your faucet.



Image 1.1: The VOTON V-1527I Matte Black Waterfall Bathroom Faucet, shown with its accompanying pop-up drain.

2. Safety Information

- Always turn off the main water supply before beginning any installation or repair work.
- Wear appropriate personal protective equipment, such as safety glasses, during installation.
- Ensure all connections are tight to prevent leaks. Do not overtighten.
- If you are unsure about any part of the installation process, consult a qualified plumber.
- Keep small parts away from children.

3. Package Contents

Verify that all components are present before beginning installation:

- Bathroom Faucet (x1)
- Deck Plate (x1) - for 3-hole sinks
- Pop-Up Drain (x1)
- Installation Hardware (nuts, washers, gaskets)

- Water Supply Lines (x2) - 23.6 inches long

4. Specifications

Feature	Specification
Brand	VOTON
Model Name	V-1527I
Finish Type	Matte Black
Material	Stainless Steel
Mounting Type	Deck Mount
Number of Handles	1 (Single Handle)
Hole Count	1 (Compatible with 3-hole sinks using deck plate)
Maximum Flow Rate	1.18 Gallons Per Minute (GPM)
Spout Height	4.7 Inches
Spout Reach	4.2 Inches
Hose Length	24 Inches
Product Dimensions	6.6"D x 1.8"W x 7.5"H
Item Weight	2.86 pounds



Image 4.1: Detailed dimensions and sink hole compatibility for the VOTON V-1527I faucet.

5. Installation Instructions

5.1. Pre-Installation

1. Turn off the main water supply to the bathroom.
2. Remove your old faucet and clean the sink area thoroughly.
3. Ensure the mounting surface is clean and dry.

5.2. Faucet Installation

1. If your sink has three holes, place the deck plate (if included and desired) over the sink holes.
2. Insert the faucet body through the center hole (and deck plate, if used).
3. From underneath the sink, secure the faucet using the provided rubber washer, metal washer, and mounting nut. Tighten securely but do not overtighten.

5.3. Water Supply Line Connection

1. Connect the hot and cold water supply lines to the corresponding inlets on the faucet body. The lines are

typically marked (red for hot, blue for cold).

2. Connect the other ends of the supply lines to your hot and cold water shut-off valves. Hand-tighten first, then use a wrench for a final quarter-turn.

5.4. Pop-Up Drain Installation

1. Apply a bead of plumber's putty or silicone sealant around the underside of the drain flange.
2. Insert the drain flange into the sink drain hole.
3. From underneath the sink, place the rubber gasket, then the friction washer, and finally tighten the mounting nut onto the drain body.
4. Connect the P-trap to the bottom of the pop-up drain.



Image 5.1: Components and function of the pop-up drain with integrated strainer.

5.5. Final Checks

1. Slowly turn on the main water supply.
2. Check all connections for leaks. Tighten any leaking connections as necessary.
3. Remove the aerator (if applicable) and flush the faucet for a few minutes to clear any debris from the water lines. Reinstall the aerator.

Video 5.1: An overview of the VOTON Bathroom Sink Faucet, demonstrating its waterfall flow and installation process.

6. Operating Instructions

The VOTON V-1527I faucet features a single handle for controlling both water flow and temperature:

- **To Turn On/Off:** Lift the handle upwards to turn on the water. Push the handle downwards to turn off the water.
- **To Adjust Water Flow:** The further you lift the handle, the greater the water flow.
- **To Adjust Temperature:** Move the handle to the left for hot water and to the right for cold water. The middle position provides mixed water.



Image 6.1: The faucet delivering a stable waterfall flow, designed to be splash-free.



Image 6.2: The faucet is designed for quiet operation, enhancing user comfort.

7. Maintenance and Care

To maintain the finish and performance of your VOTON faucet, follow these guidelines:

- **Cleaning:** Clean the faucet regularly with a soft, damp cloth. Avoid abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the matte black finish.
- **Water Spots:** To prevent water spots, wipe the faucet dry after each use.
- **Ceramic Cartridge:** The faucet is equipped with a durable ceramic cartridge, tested for 500,000 cycles. No regular maintenance is required for the cartridge.
- **Pop-Up Drain:** The pop-up drain includes a built-in strainer to collect hair and debris. Periodically remove and clean the strainer to ensure proper drainage.



Image 7.1: The faucet features a thickened electroplating process for enhanced durability, anti-rust, no peeling paint, and anti-corrosion properties.

8. Troubleshooting

Problem	Possible Cause	Solution
Low Water Flow	Aerator clogged with debris; partially closed shut-off valves; kinked supply lines.	Clean or replace aerator; fully open shut-off valves; straighten supply lines.
Leaks from Faucet Base	Mounting nut loose; worn gasket.	Tighten mounting nut; replace gasket.
Leaks from Supply Lines	Loose connections; damaged O-rings.	Tighten connections; replace O-rings.
Water Temperature Not Adjusting	Hot/cold supply lines reversed or blocked.	Check supply line connections; ensure no blockages.

9. Warranty and Support

The VOTON V-1527I faucet comes with a limited warranty. For specific warranty details, claims, or technical support, please refer to the warranty card included with your product or contact VOTON customer service directly. VOTON is committed to providing high-quality products and responsive customer service.

© 2023 VOTON. All rights reserved.