

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Phomemo](#) /

› [Phomemo D30 Portable Label Maker Machine User Manual](#)

Phomemo D30-PK-1PK-C-3RG

Phomemo D30 Portable Label Maker Machine User Manual

Your compact and versatile solution for organized labeling at home, office, or school.

1. INTRODUCTION

The Phomemo D30 is a portable, handheld Bluetooth mini label printer designed for ease of use and versatility. Utilizing direct thermal technology, it offers inkless printing, eliminating the need for ink, toner, or ribbons. This device supports both continuous and pre-cut label tapes, providing superior print clarity and fast processing for various labeling needs.



The Phomemo D30 Label Maker Machine, showcasing its compact design and label output.

2. WHAT'S IN THE BOX

Upon unboxing your Phomemo D30 Label Maker Machine, please ensure all the following components are present:

- 1 x D30 Label Maker Machine
- 1 x Charging Cord (Micro USB)
- 1 x User Manual
- 80 Pieces 12x40mm Pre-cut Labels Tapes - Black on White (starter roll)



All items included in the Phomemo D30 Label Maker Machine package.

3. SETUP

3.1. Charging the Device

Before initial use, fully charge your Phomemo D30 Label Maker using the provided Micro USB charging cord. The device features a built-in durable and rechargeable battery for extended use.

3.2. Loading Labels

1. Open the label compartment by gently pressing the release button or sliding the cover.
2. Remove any protective stickers from the label roll.
3. Insert the label roll into the compartment, ensuring the label side faces upwards and the leading edge extends slightly out of the printer slot.
4. Close the compartment cover securely.

3.3. App Installation and Connection

The Phomemo D30 operates via a dedicated mobile application. Follow these steps to get started:

1. Download the "Print Master" app from your smartphone's app store (available for Android and iOS).
 2. Ensure Bluetooth is enabled on your smartphone.
 3. Turn on the Phomemo D30 by pressing and holding the power button for 3 seconds. The indicator light will turn green.
 4. Open the "Print Master" app and follow the on-screen prompts to connect to your D30 printer via Bluetooth.
-

4. OPERATING INSTRUCTIONS

The "Print Master" app provides a user-friendly interface for creating and printing labels.

4.1. Creating Labels

The app offers multiple creative functions and convenient label templates:

- **Text:** Input custom text with various fonts.
- **Icons & Frames:** Choose from over 1000 symbols and 110+ frames to personalize your labels.
- **Barcodes & QR Codes:** Generate and print barcodes or QR codes directly from the app.
- **Images:** Insert images onto your labels.
- **Templates:** Utilize pre-designed templates for quick and easy label creation.



The "Print Master" app interface for label creation.

Phomemo D30

Bluetooth Label Maker

T
Text

♥
Icon

🕒
Time

📐
Border

📄
ID code

📶
QR code

📅
Form

🖼️
Picture

—
Line

📏
Shape

📊
Excel

📷
Scan

1000+
PATTERNS
Label Template

30+ Fonts

100+ Label tapes

Phomemo D30

100+ types of label tapes

Clothing APP feature

Candy

Peach 2/6/2022

Dear Emily Merry Christmas

Mom's gift

Happy Birthday

Overview of creative functions available in the Phomemo D30 app.

4.2. Printing Labels

Once your label design is complete in the app, select the "Print" option. The D30 will quickly print your label using its thermal printing technology. The device supports both pre-cut and continuous label types.

Printing Both Pre-cut Labels and Continuous Labels




The Phomemo D30 supports both pre-cut and continuous label printing.

5. APPLICATIONS AND USAGE

The Phomemo D30 Label Maker is highly versatile and can be used for a wide range of organization and labeling tasks:

- **Home Organization:** Labeling food containers, storage bins, spice jars, and personal items.
- **Office & Business Use:** File management, cable identification, price tags, and general office organization.
- **School & Classroom:** Labeling school supplies, kids' items, name tags, and educational projects.

Work



Labeling applications for home organization.



The Phomemo D30 is ideal for school and classroom labeling.

Wide Applications

| Kindergarten Name Tag | Family Category Labels | Elder Reminder Label | Shop Item Tag |
|-------------------------------------|------------------------|----------------------|---------------|
| | | | |
| David's Pen Olivia's Pen | | | |

Wide range of applications for the Phomemo D30 Label Maker.

6. MAINTENANCE

To ensure the longevity and optimal performance of your Phomemo D30 Label Maker, follow these maintenance guidelines:

- **Cleaning:** Regularly wipe the exterior of the device with a soft, dry cloth. For the print head, use a cotton swab lightly dampened with rubbing alcohol, ensuring the device is off and disconnected from power. Allow to dry completely before use.
 - **Storage:** Store the label maker in a cool, dry place away from direct sunlight and extreme temperatures.
 - **Label Rolls:** Keep unused label rolls in their original packaging to protect them from dust and moisture.
-

7. TROUBLESHOOTING

If you encounter issues with your Phomemo D30, try the following solutions:

- **Printer Not Connecting:**
 - Ensure Bluetooth is enabled on your smartphone and the printer is turned on.
 - Restart both the printer and your smartphone.
 - Verify the "Print Master" app is updated to the latest version.
 - **Poor Print Quality:**
 - Check if the label roll is inserted correctly and the label side is facing up.
 - Clean the print head as described in the Maintenance section.
 - Ensure the label tape is compatible with the D30 model.
 - **Labels Not Feeding:**
 - Open the compartment and ensure the label roll is properly seated and not jammed.
 - Pull the leading edge of the label tape slightly to ensure it's aligned with the print mechanism.
-

8. SPECIFICATIONS

| Feature | Detail |
|-------------------------|------------------------------|
| Brand | Phomemo |
| Model Name | D30 |
| Item Model Number | D30-PK-1PK-C-3RG |
| Connectivity Technology | Bluetooth (Wireless) |
| Printing Technology | Thermal |
| Printer Output | Monochrome (Black text only) |
| Resolution | 203 x 203 DPI |





| | |
|--------------------|--|
| Maximum Media Size | 1.57 x 5.9 inches (40 x 150 mm) |
| Power Source | 1 Lithium Polymer battery (included), USB Rechargeable |
| Item Weight | 5.6 ounces (160 Grams) |
| Product Dimensions | 1.14"D x 2.95"W x 5.17"H |
| Compatible Devices | Smartphones, Tablet (Android, iOS) |
| UPC | 788703522509 |

9. WARRANTY AND SUPPORT













The Phomemo D30 Label Maker Machine comes with a limited warranty. For detailed warranty information, support, or further assistance, please refer to the official User Guide included in your package or visit the Phomemo official website.

You can also access the User Guide PDF [here](#).

Related Documents - D30-PK-1PK-C-3RG

| | |
|---|---|
| <p>Quick Start Guide D30</p>  <p>English</p> | <p>Phomemo D30 Label Maker Quick Start Guide</p> <p>A quick start guide for the Phomemo D30 portable thermal label maker, covering unboxing, setup, app connection, paper roll replacement, and charging instructions.</p> |
| <p>Quick Start Guide D30</p>  <p>English</p> | <p>Phomemo D30 Label Maker Quick Start Guide</p> <p>A quick start guide for the Phomemo D30 Label Maker, covering product introduction, getting started, replacing the paper roll, connection methods, charging, and button/indicator light instructions.</p> |
| <p>Instruction D30 Product Instruction</p>  <p>Please read this instruction carefully before using this product and keep it properly. For more detailed information, please check the official website: www.phomemo.com</p>  <p>Operation guide QR code</p> <p>⚠️ Please scan the QR code to get the printer operation guide.</p> <p>Table of Contents</p> <p>01 Packing List 02 Parts Introduction & Nameplate & Paper Roll and Indicator Light 03 App Downloaded Method 04 Start Guide</p> | |



| Function | Description |
|---|---|
|  | Click to insert text. Use can edit the text size, spacing and select various fonts. |
|  | Click function, click to insert all kinds of data scales. |
|  | Click border, function, and choose various data borders to decorate your chart. |
|  | Click to insert the picture you want to add and print. |
|  | Insert data and specific font. |
|  | Click to insert the data to identify. It can quickly identify the information content in the QR code. |
|  | Click to insert a QR code. It can quickly identify the information content to be added. This is a one-dimensional code that can automatically generate a QR code. |
|  | Click to insert a QR code. Enter the information to be added, and the QR code can be automatically generated, and the layout can be adjusted. |
|  | Insert a link. User can choose a dashed line or a solid line. |
|  | Click to insert round or square shapes. |
|  | Support Table input, therefore quickly generating a list that can be printed. |
|  | Click to recognize text in the picture. |



| | |
|----------------------------|--|
| Product name | Sewall Label Printer |
| Product model | Q38 |
| Printing technology | Thermal printing |
| Effective printing width | 12-cm |
| Supported consumables | Print on paper, black mark paper, continuous paper |
| Printing density | Light, standard, dark |
| Printing resolution | 283 dpi |
| Print head service life | 50 km |
| Communication interface | Bluetooth 4.2 |
| Product size | 131.5*75.5*29 mm (5.2*3.0*1.2 inch) |
| Power input | 5V=2A |
| Power supply method | Micro USB Lithium battery |
| Supported operating system | Android iOS |

10. Daily Cleaning



11. Solutions for Common Problems

Not centered, misplaced, offset, skewed, etc.

Please check Whether the paper roll is correctly placed in the machine?
Please make sure that the label is placed in the machine with printing side facing left. If it is placed incorrectly (inversed), printing will fail.

Please check Whether to select the corresponding label size and pattern in the App?
Whether the matching label size and pattern have been selected in the App. Please confirm the size and pattern on the label packaging, and select the matching template in the App.

Please check After the machine is turned on, whether to click the power button to allow the machine to calibrate and position the label. When installing or replacing label paper roll for the first time, the user needs to click the power button to print a blank label so that the print head can identify the position of the label.

Printing blurry

Please Check Whether the power of machine is sufficient.
On the "Profile" page, click "Printer" to view the specific power level. If the remaining power of printer is less than 10%, you can charge it for at least half an hour before use.



There is foreign matter or glue on the print head. Please use a cotton swab dip with a little alcohol to gently wipe the dirt on the print head. Do not turn on the machine immediately after wiping. After the alcohol is evaporated and dry, double-click the power button to print the self-check page after turning on the machine to check the effect.

Printer cannot be connected

 The status of the printer is on, and the mobile phone blazes out

Please check Is the device connection performed in App?
This product needs to perform the device connection in App.

Comprehensive instruction manual for the Phomemo D30 Small Label Printer, covering setup, app download, paper installation, printer connection, printing guides (Lite and Creation modes), product specifications, daily cleaning, and troubleshooting common issues.

Comprehensive user guide for Phomemo portable thermal printers, including models like M02S, D30, and Q30S. Learn about product features, power indicators, battery safety, app download, Bluetooth connection, and paper replacement. Discover official Phomemo consumables.

