LEGO 10273

LEGO Icons Haunted House Building Set 10273 Instruction Manual

Brand: LEGO | Model: 10273

Introduction

This manual provides detailed instructions and information for the assembly, operation, and maintenance of your LEGO Icons Haunted House Building Set 10273. This impressive 3,231-piece set is designed for adults and families who appreciate intricate design and a thrilling building experience. Explore the detailed interior, interactive features, and the 10 unique minifigures included in this creative kit.



Image: The complete LEGO Icons Haunted House Building Set 10273, showcasing its intricate design and scale.

Setup and Assembly

The LEGO Icons Haunted House Building Set 10273 contains 3,231 pieces. Follow the step-by-step instructions provided in the included building guide. It is recommended to sort pieces by color and type before beginning assembly to ensure a smooth building process. The set features hinged sides, allowing the house to open up for easy access to the detailed interior during and after construction.

- **Piece Count:** 3,231 LEGO building elements.
- **Minifigures:** Includes 10 unique minifigures, adding character and storytelling possibilities to your haunted house.
- **Packaging:** This product comes in Frustration-Free Packaging.

Your browser does not support the video tag.

Video: A 360-degree view of the LEGO Haunted House Building Kit, highlighting its exterior details.

Carefully follow the numbered bags and corresponding steps in the instruction manual. Ensure all connections are secure to maintain the structural integrity of the model. The hinged design allows for dynamic display and play options.



Image: The LEGO Icons Haunted House 10273 opened up, revealing its detailed interior and minifigures interacting within the structure.

Operating Interactive Features

The LEGO Icons Haunted House 10273 includes several interactive features designed to enhance the experience:

- **Free-Fall Ride:** The house features a working free-fall ride.
- **Automatic Doors:** Discover automatic doors at the top of the tower for a spooky effect.
- **Light Bricks:** Integrated light bricks illuminate various parts of the house (batteries included).
- **Powered Up Integration (Optional):** To control the lift via the Powered Up app, motorize your model by adding 1 x 88009 and 2 x 88008 Powered Up components (sold separately).

Your browser does not support the video tag.

Video: An official overview of the LEGO Creator Expert 10273 set, showcasing its features and details.

Ensure all moving parts are assembled correctly as per the instructions to guarantee smooth operation of the free-fall ride and automatic doors.

Maintenance

To keep your LEGO Icons Haunted House in optimal condition:

- **Cleaning:** Use a soft, dry cloth or a soft brush to gently remove dust. For stubborn dirt, a slightly damp cloth can be used, but avoid excessive moisture. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the model in a cool, dry place away from direct sunlight to prevent discoloration or warping of the plastic elements.
- **Battery Replacement:** If the light bricks dim or stop working, replace the batteries as indicated in the specific light brick instructions.

Troubleshooting

- **Missing Pieces:** If you discover any missing pieces during assembly, please contact LEGO Customer Service directly.
- **Assembly Difficulties:** If you encounter difficulties during assembly, carefully re-examine the instruction manual for the specific step. Ensure all pieces are correctly oriented and firmly connected.
- **Interactive Feature Malfunction:** Check that all gears and connecting elements for the free-fall ride and automatic doors are correctly installed and free from obstruction. For Powered Up features, ensure batteries are charged and the app connection is stable.

Specifications

Feature	Detail
Brand	LEGO
Model Name	Haunted House 10273
Model Number	6303666
Number of Pieces	3231
Item Dimensions (L x W x H)	18.9 x 22.91 x 4.88 inches
Item Weight	11.3 Pounds
Material Type	Plastic
Age Range Description	Adult (Manufacturer Minimum Age: 3 months, Maximum Age: 100 months)
Included Components	LEGO Building Elements

Warranty and Support

LEGO products are manufactured to high-quality standards. If you experience any issues with your set, such as missing or defective parts, please contact LEGO Customer Service. Information regarding warranty and support can typically be found on the official LEGO website or through the contact details provided in the product packaging.

For direct assistance, visit www.lego.com/service or refer to the contact information included with your product.

© 2026 LEGO Group. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question