

[Manuals.plus](#) /

› [Simple Trending](#) /

› Simple Trending 4-Tier Stackable Shoe Rack User Manual

Simple Trending 4-Tier

Simple Trending 4-Tier Stackable Shoe Rack User Manual

Model: 4-Tier | Brand: Simple Trending

1. INTRODUCTION

This manual provides instructions for the assembly, use, and maintenance of your Simple Trending 4-Tier Stackable Shoe Rack. This versatile storage solution is designed to help organize footwear and other items efficiently within your home.



Image 1.1: The Simple Trending 4-Tier Stackable Shoe Rack. This image displays the assembled white wire grid shoe rack from a front-facing perspective, showcasing its four tiers.

2. SAFETY INFORMATION

- Ensure all components are securely fastened during assembly to prevent instability.
- Do not overload the shelves. Distribute weight evenly to maintain balance.
- Keep small parts away from children during assembly.
- Avoid climbing on or hanging from the rack.
- Place the rack on a flat, stable surface.

3. PACKAGE CONTENTS

Please verify that all components listed below are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- 4 x Wire Grid Shelves
- 2 x Side Frames (U-shaped)
- 4 x Metal Connectors (for stacking)
- Assembly Hardware (e.g., screws, clips)

4. ASSEMBLY INSTRUCTIONS

The Simple Trending 4-Tier Stackable Shoe Rack features a simple structure designed for easy assembly. No specialized tools are typically required.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface.
2. **Attach Side Frames:** Connect the wire grid shelves to the U-shaped side frames. Ensure the shelves are oriented correctly and all connection points align.
3. **Secure Connections:** Use the provided hardware (if any, typically screws or clips) to firmly secure each shelf to the side frames. Hand-tighten initially, then ensure all connections are snug.
4. **Verify Stability:** Once assembled, gently shake the rack to ensure it is stable and all parts are properly connected.



Image 4.1: Detail illustrating the expandable and adjustable design. This image highlights how multiple units can be connected horizontally and how connection points are used for stacking.

5. CONFIGURATION OPTIONS

Your Simple Trending shoe rack is designed to be both stackable and expandable, allowing you to customize your storage solution to fit your space and needs.

5.1 Stacking Multiple Units

To create a taller storage unit, you can stack two or more 4-tier racks vertically. Use the included metal connectors to securely join the top of one rack to the bottom of another. This can create an 8-tier or even 12-tier unit.

5.2 Expanding Horizontally

For wider storage, multiple racks can be placed side-by-side. While no specific connectors are provided for horizontal bridging, the design allows for seamless placement next to each other to create a continuous storage area.



Image 5.1: Example configurations showing multiple 4-tier racks stacked vertically to form a taller unit and placed horizontally to create a wider storage system.




Image 5.2: Visual guide demonstrating various combination possibilities, including stacking two units to create an 8-tier rack and arranging multiple units for extended storage.

6. MAINTENANCE

To maintain the appearance and longevity of your shoe rack, follow these simple care instructions:

- **Cleaning:** Wipe the rack with a dry cloth to remove dust and dirt. Avoid abrasive cleaners or harsh chemicals, which may damage the powder-coated finish.
- **Inspection:** Periodically check all connections to ensure they remain tight and secure.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Rack is wobbly or unstable.	Loose connections; uneven surface.	Ensure all screws and connectors are tightened. Place the rack on a flat, level surface.

Problem	Possible Cause	Solution
Parts do not fit together.	Incorrect orientation of parts; manufacturing defect.	Review assembly instructions to ensure correct part orientation. If parts are defective, contact customer support.
Missing components.	Packaging error.	Refer to the "Package Contents" section and contact customer support for replacement parts.

8. SPECIFICATIONS

- Brand:** Simple Trending
- Model:** 4-Tier Stackable Shoe Rack
- Color:** White
- Material:** Metal
- Finish Type:** Powder Coated
- Number of Shelves:** 4
- Product Dimensions (L x W x H):**26.8" x 11.5" x 25.5" (68.1 cm x 29.2 cm x 64.8 cm)
- Item Weight:** 6.3 pounds (2.86 kg)
- Special Feature:** Expandable and Stackable (not individual shelf height adjustable)
- Assembly Required:** Yes

FOR PLACING

BEST SUITABLE SIZE

Multiple functions




Image 8.1: Dimensional drawing of the 4-tier shoe rack, indicating its length, width, and height.

9. WARRANTY AND SUPPORT

For warranty information, product support, or to inquire about replacement parts, please contact Simple Trending customer service directly or refer to the retailer's return policy where the product was purchased.

You can also visit the official Simple Trending store for more products and information [Simple Trending Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question