

Plantronics CS510-XD

Plantronics CS510-XD Wireless Headset System User Manual

Model: CS510-XD

[Overview](#)

[Setup](#)

[Operation](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty & Support](#)

1. PRODUCT OVERVIEW

This manual provides instructions for the Plantronics CS510-XD Wireless Headset System. This system is designed for business communication, offering wireless connectivity and a noise-canceling microphone.

Important Compatibility Note: The CS510-XD series is not cross-compatible with the standard CS510 or C052 models. Headsets from the XD series cannot be used with charging bases of non-XD variants, and vice-versa.



Figure 1: Plantronics CS510-XD Wireless Headset System. The image shows the over-ear headset docked in its charging base. Red text annotations point to "red XD here" on the headset and a "CS500XD EXTREME DENSITY" label on the base, indicating the specific XD

Package Contents:

- Plantronics CS510-XD Headset
- Plantronics CS510-XD Charging Base
- Protective Case
- Headset Advisor Wipe (included in bundle)
- Power Adapter
- Telephone Interface Cable

2. SETUP INSTRUCTIONS

2.1 Connecting the Base

1. Connect the power adapter to the charging base and plug it into a power outlet.
2. Connect the telephone interface cable from the charging base to your desk phone's headset port or handset port, depending on your phone model. Consult your phone's manual for specific port locations.

2.2 Charging the Headset

Place the headset into the charging cradle on the base. The charging indicator light on the base will illuminate to confirm proper connection and charging. Allow the headset to charge for at least 20 minutes before first use, or until fully charged for optimal battery life.

2.3 Initial Pairing (if required)

The headset and base are typically pre-paired. If pairing is required, place the headset in the charging cradle. Press and hold the pairing button on the base until the indicator light flashes. Then, press and hold the call control button on the headset until its indicator light flashes. Release both buttons. The lights will become solid when pairing is successful.

3. OPERATING THE HEADSET

3.1 Basic Call Functions

- **Answering/Ending a Call:** Press the Call Control button on the headset.
- **Volume Adjustment:** Use the Volume Up (+) and Volume Down (-) buttons on the headset.
- **Mute/Unmute:** Press the Mute button on the headset.

3.2 Special Features

- **Conference Calling:** Up to four CS510-XD headsets can be conferenced on a single charging base. To add a guest headset, place the guest headset into the primary headset's charging cradle. The primary headset's indicator light will flash. Press the Call Control button on the primary headset to accept the guest.
- **Noise-Canceling Microphone:** The integrated microphone is designed to reduce background noise for clearer communication.

4. MAINTENANCE

4.1 Cleaning

Regularly clean the headset and base with a soft, dry cloth. For hygienic cleaning of the headset, use the provided Headset Advisor Wipe or a similar non-abrasive, alcohol-free wipe. Avoid using harsh chemicals or submerging any part of the device in liquid.

4.2 Battery Care

To maximize battery life, fully charge the headset before initial use. Store the headset in its charging cradle when not in use to ensure it is always ready. Avoid exposing the battery to extreme temperatures.

5. TROUBLESHOOTING

Problem	Possible Cause	Solution
No dial tone/No audio	Incorrect cable connection, headset not charged, headset not paired.	Ensure all cables are securely connected to the base and phone. Verify the headset is fully charged. Re-pair the headset with the base (refer to Section 2.3).
Poor audio quality	Low battery, interference, microphone position.	Charge the headset. Move the base away from other electronic devices that may cause interference. Adjust the microphone boom to be approximately two finger-widths from your mouth.
Headset not charging	Improper placement, power issue.	Ensure the headset is correctly seated in the charging cradle. Check that the power adapter is securely connected to the base and a working power outlet.
Cannot conference headsets	Incompatible models, incorrect procedure.	Ensure all headsets are CS510-XD models. Non-XD models are not compatible. Follow the conference calling procedure in Section 3.2 carefully.

6. SPECIFICATIONS

Model Name	CS510-XD
Brand	Plantronics
Connectivity Technology	Wireless
Wireless Communication Technology	Bluetooth
Earpiece Shape	Over-ear
Form Factor	Over Ear
Control Method	Touch

Special Features	Conference up to 4 headsets on a single charging base, Noise canceling microphone
Compatible Devices	Telephones, Computers, Gaming Consoles
Material	Plastic
UPC	811723032458
ASIN	B08J2QPRVV

7. WARRANTY AND SUPPORT

This Plantronics CS510-XD Wireless Headset System is sold as a *Renewed* product. Warranty coverage for renewed products typically differs from new products. Please refer to the specific warranty terms provided by the seller (HBTphoneguy) or the Amazon Renewed program at the time of purchase for details regarding coverage, duration, and claims process.

For technical support or further assistance, please contact the seller or refer to the official Plantronics (now Poly) support resources online.

© 2026 Plantronics CS510-XD User Manual. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

