

[Manuals.plus](#) /

› [PERFASCIN](#) /

› PERFASCIN SE-R0295 Remote Control User Manual for Toshiba DVD/VCR

PERFASCIN SE-R0295

PERFASCIN SE-R0295 Remote Control User Manual

Model: SE-R0295

1. INTRODUCTION

Thank you for choosing the PERFASCIN SE-R0295 Remote Control. This remote is designed as a direct replacement for the original Toshiba SE-R0295 remote, offering seamless compatibility with various Toshiba DVD/VCR combo units. It requires no programming or setup; simply insert batteries and begin use.

This manual provides essential information on setting up, operating, and maintaining your new remote control.

2. SAFETY INFORMATION

Please read and understand the following safety precautions before using the remote control:

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Remove batteries if the remote control will not be used for an extended period to prevent leakage.
- Keep batteries out of reach of children.
- Dispose of used batteries properly according to local regulations.
- Avoid exposing the remote control to direct sunlight, heat sources, or excessive moisture.

3. PACKAGE CONTENTS

Your package should contain the following item:

- 1 x PERFASCIN SE-R0295 Remote Control

Note: AAA batteries are not included and must be purchased separately.

4. SETUP

4.1. Battery Installation

To install batteries in your remote control, follow these steps:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch and lift to open the compartment.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Image: Front and back view of the PERFASCIN SE-R0295 Remote Control, highlighting the battery compartment.

Your remote control is now ready for use. No additional programming is required.

5. OPERATING INSTRUCTIONS

The PERFASCIN SE-R0295 remote control operates via infrared (IR) technology. Ensure a clear line of sight between the remote control and your Toshiba DVD/VCR unit for optimal performance.

5.1. Basic Operation

- **Power On/Off:** Press the **POWER** button to turn your Toshiba DVD/VCR unit on or off.
- **Function Buttons:** Use the dedicated buttons for DVD and VCR functions (e.g., Play, Pause, Stop, Rewind, Fast Forward, Record, Channel, Volume, Menu, etc.) as you would with the original remote.
- **Range:** The remote has a maximum operating range of approximately 10 meters (33 feet).

5.2. Compatible Models

This remote control is compatible with the following Toshiba DVD/VCR models:

- D-VR610
- D-VR610KU
- D-VR620
- D-VR620KU
- D-KVR20
- D-KVR20U
- D-KVR2K0
- D-KVR60
- D-KVR60KU
- DVR610
- DVR610KU
- DVR620
- DVR620KU
- DKVR20
- DKVR20U
- DKVR2K0
- DKVR60
- DKVR60KU

6. MAINTENANCE

6.1. Cleaning

To clean your remote control, gently wipe it with a soft, dry cloth. Do not use liquid cleaners, abrasive pads, or chemical solvents, as these may damage the remote's surface or internal components.

6.2. Battery Replacement

Replace batteries when the remote's performance degrades or if it stops responding. Refer to Section 4.1 for battery installation instructions. Always replace both batteries at the same time with new AAA batteries.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Remote control is not working.	Dead or incorrectly inserted batteries. No clear line of sight to the DVD/VCR unit. Remote control is damaged.	Replace batteries with new AAA batteries, ensuring correct polarity. Ensure no objects are blocking the path between the remote and the DVD/VCR unit. Point the remote directly at the DVD/VCR unit's IR sensor. If issues persist, contact customer support.
Limited operating range.	Weak batteries. Interference from other electronic devices.	Replace batteries. Move away from other electronic devices that might cause interference.

8. SPECIFICATIONS

Feature	Detail
Brand	PERFASCIN
Model Number	SE-R0295
Connectivity Technology	Infrared (IR)
Special Feature	No Programming Required
Compatible Devices	Toshiba DVD/VCR Players (Specific models listed in Section 5.2)
Maximum Number of Supported Devices	1 (Dedicated to compatible Toshiba DVD/VCR units)
Controller Type	Button Control
Maximum Range	10 Meters (approx. 33 feet)
Batteries Required	2 x AAA batteries (not included)
Item Weight	0.15 Kilograms

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided with your purchase or contact the seller directly through the platform where the product was purchased. Please have your order number and product model (SE-R0295) ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B08J45SSPX>

More documents and user manuals: <https://manuals.plus/>