

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Avita](#) /

› [Avita Magus II 10.1-inch HD Tablet with Detachable Keyboard User Manual](#)

## Avita Magus II WT9M10 C44

# Avita Magus II 10.1-inch HD Tablet with Detachable Keyboard User Manual

Model: WT9M10 C44

## INTRODUCTION

This manual provides essential instructions for the setup, operation, maintenance, and troubleshooting of your Avita Magus II 10.1-inch HD Tablet with Detachable Keyboard. Please read this guide thoroughly to ensure proper use and to maximize your device's performance and longevity.

## PACKAGE CONTENTS

- Avita Magus II 10.1-inch HD Tablet
- Detachable Keyboard
- Power Adapter (12V charger)

## SETUP

### 1. Initial Charging

Before first use, connect the tablet to the provided 12V power adapter. The charging port is located on the tablet. Ensure the tablet is fully charged for optimal battery calibration.

### 2. Attaching the Detachable Keyboard

Align the tablet with the magnetic connector on the keyboard folio. The tablet will securely snap into place, establishing the connection between the tablet and the keyboard. The folio also features a stand to support the tablet in a laptop configuration.



Image: The Avita Magus II tablet being detached from its keyboard folio. The tablet connects magnetically to the keyboard base.

### 3. Powering On

Press and hold the power button located on the tablet's side until the Avita logo appears on the screen. Follow the on-screen prompts to complete the initial Windows 10 setup.

### 4. Windows 10 S Mode

Your Avita Magus II comes with Windows 10 Home in S mode, which enhances security and performance by exclusively using apps from the Microsoft Store. If you need to install applications from outside the Microsoft Store, you can switch out of S mode. This is a one-way process for most users. To switch, go to **Settings > Update & Security > Activation** and follow the instructions to switch to full Windows 10 Home.

## OPERATING THE DEVICE

### 1. Touchscreen Operation

The 10.1-inch HD display supports multi-touch gestures. Use your fingers to navigate, tap, swipe, and pinch-to-zoom. When the keyboard is detached, an on-screen keyboard will automatically appear for text input.

# ULTRA VERSATILE

Experience portable computing freedom with the MAGUS 2-in-1.



Touchscreen



10.1" HD Display



Windows 10 S

Image: The Avita Magus II tablet in laptop mode, illustrating its touchscreen capability, 10.1-inch HD display, and Windows 10 S operating system.

## 2. Using the Keyboard and Trackpad

The detachable keyboard provides a traditional typing experience. The integrated trackpad allows for precise cursor control. Standard keyboard shortcuts and trackpad gestures are supported by Windows 10.

## 3. Connectivity Ports

- **USB 3.0 Port:** Connect external devices such as USB drives, mice, or printers.
- **Mini HDMI Port:** Connect to an external display or projector using a mini HDMI to HDMI cable (sold separately).
- **MicroSD Card Slot:** Expand storage capacity up to 128GB using a microSD card.
- **3.5mm Headphone Jack:** Connect headphones or external speakers.

## 4. Wireless Connections

- **Wi-Fi:** Connect to wireless networks for internet access. Access Wi-Fi settings via the Windows Action Center or Settings app.
- **Bluetooth:** Pair with Bluetooth-enabled devices such as headphones, speakers, or other peripherals. Access

Bluetooth settings via the Windows Action Center or Settings app.

## 5. Audio Control

The tablet features stereo speakers. Volume control is managed through the Windows operating system via the on-screen speaker icon in the taskbar or using the dedicated volume keys on the detachable keyboard.

# MAINTENANCE

---

## 1. Cleaning the Device

- Use a soft, lint-free cloth to clean the screen and exterior surfaces.
- For stubborn marks, slightly dampen the cloth with water or a screen-safe cleaning solution. Avoid harsh chemicals or abrasive materials.
- Ensure no liquid enters ports or openings.

## 2. Handling and Storage

- Avoid dropping the device or exposing it to extreme temperatures.
- When transporting, ensure the tablet is securely closed within its folio to protect the screen and keyboard.
- The folio material provides protection but is not designed for heavy stress; avoid picking up the entire unit by the tablet alone when in laptop mode.

## 3. Software Updates

Regularly check for and install Windows updates to ensure your system has the latest security patches and performance improvements. Go to **Settings > Update & Security > Windows Update**.

# TROUBLESHOOTING

---

## 1. Device Not Powering On

- Ensure the device is charged. Connect the power adapter and wait a few minutes before attempting to power on again.
- If the battery is completely depleted, it may take longer to show signs of charging.

## 2. Wi-Fi Connectivity Issues

- Check if Wi-Fi is enabled in Windows settings.
- Restart your router and the tablet.
- Ensure you are within range of a Wi-Fi network and have the correct password.

## 3. Touchpad or Keyboard Not Responding

- Ensure the tablet is correctly seated and connected to the keyboard's magnetic dock.
- Restart the tablet.
- Check Windows Device Manager for any driver issues related to the keyboard or touchpad.

## 4. Slow Performance

- Close unnecessary applications running in the background.
- Ensure Windows is up to date.
- Consider freeing up storage space on the 64GB drive, potentially by moving files to a microSD card or cloud storage.

## SPECIFICATIONS



# BETTER PERFORMANCE

Intel® Celeron® with 2.6GHz boost

64GB SSD Storage

4GB DDR4 RAM

Bluetooth 4.2™

USB 3.0 x 1 | mini-HDMI x 1 |

microSD x 1 | Headphone Jack

Image: The Avita Magus II tablet with a list of its key performance specifications.

Feature	Detail
Model Number	WT9M10 C44-BK
Display Size	10.1 Inches
Screen Resolution	1280 x 800 (HD)
Processor	Intel Celeron N4000 (1.1 GHz, up to 2.6 GHz burst)
RAM	4 GB
Storage	64 GB eMMC (Solid State Drive)
Graphics	Intel UHD Graphics 600 (Integrated)

Feature	Detail
Operating System	Windows 10 Home (S Mode)
Wireless Connectivity	Wi-Fi, Bluetooth
Ports	1x USB 3.0, 1x Mini HDMI, 1x MicroSD Card Slot (up to 128GB), 1x 3.5mm Headphone Jack
Battery Life	Approximately 6 hours (average usage)
Item Weight	3.67 pounds (tablet with keyboard)

## WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation included with your purchase or visit the official Avita support website. Keep your proof of purchase for warranty claims.