

[Manuals.plus](#) /

› [KINDIARY](#) /

› KINDIARY Crab Bath Bubble Maker (Model 1-JU29NA06) Instruction Manual

KINDIARY 1-JU29NA06

KINDIARY Crab Bath Bubble Maker Instruction Manual

Model: 1-JU29NA06

Brand: KINDIARY

1. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before use and retain for future reference. This product is intended for use by children aged 18 months and above, under adult supervision. Individuals with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, should be supervised or instructed on safe use and understand potential hazards.

- Children must not play with the appliance.
- Cleaning and user maintenance should not be performed by children without supervision.
- **Do not submerge the crab bubble maker in water.** The battery compartment is not waterproof, and submersion will cause the device to malfunction.
- Ensure batteries are new and installed correctly for optimal performance.
- Always check that the bubble mixture reaches the marked 'Start Line' and maintains a ratio of at least 1:5 (baby wash to water) for proper bubble production.
- Verify the nozzle is clean to prevent weak or absent bubbles.

2. PRODUCT OVERVIEW

The KINDIARY Crab Bath Bubble Maker is a delightful, automatic, battery-operated bath toy designed to create colorful bubbles, enhancing bath time for babies, toddlers, and preschoolers. Made from durable, BPA-free plastics, this toy encourages imagination, curiosity, and fine motor skills, making it a safe and engaging addition to any child's bath routine.



Image: The KINDIARY Crab Bath Bubble Maker attached to a bathtub wall, generating a continuous stream of bubbles. A child is shown reaching for the bubbles, indicating the toy's engaging nature. The image highlights the phrase "Make Bath Time More Fun" and notes that "Bubble effect varies by soap. For best results, please use bubble bath soap."

Video: An official product video from Atlasonix showcasing the Bath Bubble Machine. The video provides a brief overview of the toy's functionality and its ability to create bubbles for bath time entertainment.

3. SETUP INSTRUCTIONS

Follow these steps to set up your KINDIARY Crab Bath Bubble Maker:

1. **Install Batteries:** Open the battery compartment (located on the back of the crab) using a screwdriver. Insert the required Alkaline batteries, ensuring correct polarity. Close the compartment securely.
2. **Attach Suction Base:** The bubble maker features a unique detachable suction base. Clean the desired surface on your bathtub wall (ceramic tile, glass, or bathtub surface) and attach the suction base firmly by pressing it against the surface.
3. **Mount the Crab:** Slide the crab bubble maker onto the attached suction base until it clicks securely into place.




Image: A visual guide illustrating the four key steps for setting up the KINDIARY Crab Bath Bubble Maker. Step 1 shows attaching and pressing the suction base. Step 2 demonstrates installing the crab onto the suction base. Step 3 details pouring the bubble mixture until it reaches the 'Start Line'. Step 4 instructs to press the ON/OFF button to activate bubble blowing.

4. OPERATING INSTRUCTIONS

Enjoy a bubbly bath time with these simple operating steps:

- 1. Prepare Bubble Mixture:** Fill the container with approximately 2 cups of bubble mixture. For best results, use a ratio of 1:5 or higher between baby wash and water, and stir evenly.
- 2. Pour Mixture:** Pour the prepared mixture through the crab claws or directly into the container until it reaches the 'Start Line' indicated inside the crab's mouth.
- 3. Activate Bubbles:** Press the ON/OFF button (typically located on the crab's face or top). The device has two settings: one that plays music along with bubbles, and another that produces bubbles without music. Press once for music and bubbles, press again for bubbles only, and a third press to turn off.

Add Your Own Mixture

1:5 or great ratio of baby wash to water



About 2 cups to reach the "Start line"

Image: A two-panel image demonstrating how to prepare and add the bubble mixture to the KINDIARY Crab Bath Bubble Maker. The first panel shows adding baby wash to a measuring cup, and the second shows stirring the mixture and pouring it into the crab's mouth, indicating the 'Start Line'.

Video: An official product video from Love Sunshine demonstrating the Gigilli Rechargeable Crab Baby Bath Toy. The video shows the process of adding water and soap to the toy and then activating it to produce bubbles, illustrating its operation.

To replenish the mixture during bath time, you can pour additional solution directly through the crab's claws without detaching the unit.

The Fun Will Not Stop

Replenish the mixture through the crab claws



Image: A child's hand pouring bubble mixture into one of the crab's claws, demonstrating the ease of refilling the toy without interruption to bath time fun. The image emphasizes that "The Fun Will Not Stop" and shows a child playing with the bubbles.

5. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your bubble maker:

- **Cleaning:** After each use, wipe the unit with a dry cloth. Do not rinse under running water or submerge.
- **Nozzle Care:** Regularly check the bubble nozzle for any blockages and ensure it is clean. A clogged nozzle can lead to weak or absent bubble production.

6. TROUBLESHOOTING

If you encounter issues with your KINDIARY Crab Bath Bubble Maker, please refer to the following common solutions:

- **Weak or Absent Bubbles:**
 - Check if the batteries are new and installed correctly.

- Ensure the bubble mixture reaches the marked 'Start Line' inside the crab's mouth.
- Verify that the ratio of baby wash to water is at least 1:5 and stirred evenly.
- Inspect the bubble nozzle for any blockages and clean if necessary.

- **Device Not Turning On:**

- Confirm that the batteries are correctly inserted and have sufficient charge.
- Ensure the battery compartment is securely closed.

7. SPECIFICATIONS

Product Dimensions	7.8 x 3.9 x 8.5 inches
Item Weight	14.9 ounces
Manufacturer	KINDIARY
Item Model Number	1-JU29NA06
Batteries Required	Yes
Battery Type	Alkaline
Included Components	Crab Bath Bubble Maker



Included in Package



Image: The KINDIARY Crab Bath Bubble Maker shown alongside its retail packaging, a measuring cup, and the separate suction base. Dimensions of the crab unit are overlaid on the image, indicating its size as 21.4cm (8.4in) wide and 16cm (6.3in) tall.

8. SUPPORT

Should you encounter any product issues or find that any accessories are missing, please do not hesitate to contact KINDIARY customer support for assistance.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question