

[Manuals.plus](#) /

> [Eono](#) /

> Eono by Amazon Bluetooth Speaker User Manual

Eono Bongo Pint

Eono by Amazon Bluetooth Speaker User Manual

Model: Bongo Pint

1. PRODUCT OVERVIEW

The Eono by Amazon Bluetooth Speaker, model Bongo Pint, is a compact and portable audio device designed for high-quality sound on the go. Despite its small size, it delivers powerful audio with deep bass, enhanced by HARMAN audio technology and a two-band equalizer. It offers seamless wireless streaming via Bluetooth 5.0 and includes a built-in microphone for hands-free operation and voice assistant access.



Figure 1.1: Front view of the Eono Bongo Pint Bluetooth Speaker.

Key Features:

- **Compact and Ultra-Portable:** Small design for easy transport.
- **Bluetooth 5.0:** Ensures stable and seamless wireless streaming.
- **HARMAN Audio Technology:** Delivers immersive sound with enhanced bass.
- **Two-Band Equalizer:** Triple-press the power button to amplify treble and bass.
- **Long Battery Life:** Up to 5 hours of playtime on a single charge.
- **Durable Design:** Constructed with durable fabric and a robust rubber casing, suitable for outdoor use.
- **Built-in Microphone:** For hands-free calls and voice assistant access (Google Now, Siri).

2. SETUP GUIDE

2.1. Charging the Speaker

Before first use, fully charge your Eono Bongo Pint speaker. Use the included USB charging cable to connect the speaker to a USB power source (e.g., computer USB port, USB wall adapter).

- Locate the micro-USB charging port on the side of the speaker.
- Insert the small end of the USB cable into the speaker's charging port.
- Connect the larger end of the USB cable to a powered USB port.
- The charging indicator light will illuminate during charging and turn off when fully charged.



Figure 2.1: Side view of the speaker showing the micro-USB charging port.

2.2. Bluetooth Pairing

To connect your speaker to a device (smartphone, tablet, etc.) via Bluetooth:

1. **Power On:** Press and hold the power button (located on the bottom of the speaker) for a few seconds until you hear an audible prompt or see an indicator light.
2. **Pairing Mode:** The speaker will automatically enter Bluetooth pairing mode, indicated by a flashing light or specific

audio cue.

3. **Enable Bluetooth on Your Device:** Go to the Bluetooth settings on your smartphone or tablet.
4. **Select Speaker:** Look for "Eono Bongo Pint" or a similar name in the list of available devices and select it to pair.
5. **Connection Confirmation:** Once successfully paired, you will hear a confirmation sound from the speaker, and the indicator light will change to a solid color.

The speaker will automatically attempt to reconnect to the last paired device when powered on.

3. OPERATING INSTRUCTIONS

3.1. Power On/Off

- **To Power On:** Press and hold the power button (located on the bottom) for approximately 2-3 seconds.
- **To Power Off:** Press and hold the power button for approximately 2-3 seconds. The speaker may also automatically power off after a period of inactivity to conserve battery.



Figure 3.1: Bottom view of the speaker, highlighting the power button.

3.2. Audio Playback

Once connected via Bluetooth, you can control audio playback directly from your paired device. The speaker's volume is typically controlled by your connected device's volume settings.

3.3. Two-Band Equalizer Mode

To activate the two-band equalizer mode, which amplifies both treble and bass for an optimized listening experience:

- **Activate EQ:** Quickly press the power button **three times**. You may hear an audio cue indicating the mode change.
- **Deactivate EQ:** Repeat the action (three quick presses of the power button) to return to the standard audio profile.

3.4. Voice Assistant Access

The speaker features a built-in microphone and can connect to your phone's voice assistant (Google Now, Siri) for hands-free control.

- **Activate Voice Assistant:** Press the power button **once** to activate your phone's voice assistant.
- You can then use voice commands to check the weather, get updates, or start your favorite playlist.

4. MAINTENANCE

4.1. Cleaning

- Use a soft, dry cloth to wipe the exterior of the speaker.
- Do not use abrasive cleaners, alcohol, or chemical solvents, as these may damage the surface.

4.2. Battery Care

- To prolong battery life, avoid fully discharging the speaker frequently.
- Charge the speaker regularly, even if not in use for extended periods.
- Store the speaker in a cool, dry place when not in use.

4.3. Water Resistance

The Eono Bongo Pint speaker is designed to be water-resistant, making it suitable for outdoor adventures. However, it is not fully waterproof and should not be submerged in water. Avoid exposing the charging port to moisture when not in use.

5. TROUBLESHOOTING

If you encounter issues with your Eono Bongo Pint speaker, refer to the following common problems and solutions:

- **No Power:**
Solution: Ensure the speaker is fully charged. Connect it to a power source using the provided USB cable and allow it to charge for at least 30 minutes before attempting to power on again.
- **Cannot Connect via Bluetooth:**
Solution:
 - a. Ensure the speaker is in pairing mode (flashing indicator light).
 - b. Make sure Bluetooth is enabled on your device and it is within range (typically 10 meters or 33 feet).

- c. Forget the device from your phone's Bluetooth settings and try pairing again.
- d. Restart both the speaker and your Bluetooth device.

- **No Sound or Low Volume:**

Solution:

- a. Increase the volume on both the speaker (via your connected device) and the audio source.
- b. Ensure the speaker is properly connected to your device.
- c. Check if the audio source is playing.

- **Short Battery Life:**

Solution:

- a. Ensure the speaker is fully charged before use.
- b. Battery life can vary based on volume level and audio content. Using the speaker at maximum volume will reduce playtime.
- c. Ensure the charging cable and power adapter are functioning correctly.

6. TECHNICAL SPECIFICATIONS

Feature	Specification
Model Name	Bongo Pint
Brand	Eono
Connectivity Technology	Bluetooth 5.0
Compatible Devices	Smartphone
Speaker Type	Bluetooth
Audio Output Mode	Stereo
Maximum Speaker Output Power	50 Watts
Power Source	Battery Powered
Battery Life	Up to 5 hours
Control Method	Voice
Color	Black
Material	Silver (referring to internal components/accents)
Product Dimensions (L x W x H)	5.51 x 5.51 x 2.31 cm (2.17 x 2.17 x 0.91 inches)
Item Weight	68.02 grams (2.4 ounces)
Waterproof	True (Water-resistant)
Included Components	1 Eono Bluetooth Speaker



Figure 6.1: Size comparison of the Eono Bongo Pint speaker.

7. SAFETY INFORMATION

- Do not expose the speaker to extreme temperatures (hot or cold).
- Avoid dropping or subjecting the speaker to strong impacts.
- Keep the speaker away from direct sunlight, heat sources, and open flames.
- Do not attempt to disassemble, repair, or modify the speaker yourself. This will void the warranty and may cause damage or injury.
- Use only the provided charging cable or a certified equivalent.
- Keep out of reach of children and pets.
- Dispose of the speaker and its battery responsibly according to local regulations. Do not dispose of with household waste.

8. WARRANTY AND SUPPORT

This product is manufactured by Eono. For warranty information and customer support, please refer to the documentation included with your purchase or visit the official Eono support website.

Please note that spare parts for this product are currently unavailable as per manufacturer specifications.

For further assistance, you may also contact Amazon customer service through your purchase history.