

[Manuals.plus](#) /

› [Imetec](#) /

› Imetec CaldoPlaid Velvet Square Heated Blanket User Manual

Imetec 16775

Imetec CaldoPlaid Velvet Square Heated Blanket User Manual

Model: 16775

[Introduction](#)

[Safety Warnings](#)

[Setup](#)

[Operating Instructions](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty & Support](#)

1. INTRODUCTION

The Imetec CaldoPlaid Velvet Square is a soft, electrically heated blanket designed for comfort and warmth. It features Adapto technology for rapid heating and consistent temperature control, making it suitable for use on a sofa or bed. This manual provides essential information for the safe and effective use, maintenance, and care of your heated blanket.



Image 1.1: The Imetec CaldoPlaid Velvet Square heated blanket.

2. SAFETY WARNINGS

Please read all safety instructions carefully before using the Imetec CaldoPlaid Velvet Square heated blanket. Failure to follow these instructions may result in electric shock, fire, or injury.

- **Do not fall asleep with the heated blanket switched on.** Prolonged use while sleeping can lead to overheating.
- Do not use the blanket on wet or damp skin. Ensure the blanket and your body are dry before use.
- Keep the blanket away from flammable materials.
- Ensure the power cord is not trapped or pinched, which could damage the wiring.
- The blanket is equipped with the **Electro Block safety system**, which includes electronic control and a self-diagnosis function at every power-on. This system is designed to verify the efficiency and safety of all components and will intervene promptly by switching off the blanket in case of anomalies.
- Do not use the blanket if it is folded, creased, or bunched up, as this can cause localized overheating.

- Do not insert pins or other sharp objects into the blanket.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Always disconnect the blanket from the power supply when not in use or before cleaning.

3. SETUP

Before first use, unpack the heated blanket and ensure all components are present and undamaged.

1. **Unpack:** Carefully remove the blanket and its control unit from the packaging. Retain packaging for future storage or transport.
2. **Inspect:** Check the blanket and power cord for any visible damage. Do not use if any damage is detected.
3. **Connect Control Unit:** Ensure the control unit is securely plugged into the blanket's connector.
4. **Placement:** Lay the blanket flat on your sofa or bed. Ensure it is not folded or creased during use.
5. **Power Connection:** Plug the power cord into a suitable electrical outlet (230V).



Image 3.1: Proper placement of the heated blanket on a sofa.

4. OPERATING INSTRUCTIONS

The Imetec CaldoPlaid Velvet Square features a digital control unit with 6 temperature settings and an auto-off timer for personalized comfort and safety.

1. **Power On:** Press the power button on the control unit to turn on the blanket. The LED display will illuminate.
2. **Select Temperature:** Use the temperature selection buttons (usually marked with numbers 1-6) to choose your desired heat level. Level 1 is the lowest heat, and Level 6 is the highest. The blanket features rapid heating to quickly reach your selected temperature.
3. **Set Timer:** The blanket includes an auto-off timer. Press the timer button to cycle through the available settings: 1 hour, 3 hours, or 9 hours. The blanket will automatically switch off after the selected duration.
4. **LED Display:** The digital LED display automatically adjusts its light intensity for comfortable viewing in various lighting conditions.
5. **Power Off:** To turn off the blanket manually, press the power button again. Always unplug the blanket from the wall socket

when not in use.



Image 4.1: Digital control unit with 6 temperature settings and auto-off timer.

The patented Adapto technology ensures high performance in terms of speed and comfort, maintaining a constant and comfortable temperature.

5. MAINTENANCE

Proper maintenance ensures the longevity and safe operation of your Imetec CaldoPlaid Velvet Square heated blanket.

Cleaning Instructions

1. **Disconnect Power:** Always unplug the blanket from the electrical outlet and disconnect the control unit from the blanket before cleaning.
2. **Remove Control Unit:** The control unit is removable to allow for washing of the blanket. Carefully detach it from the blanket.

3. **Washing:** The blanket can be washed by hand or in a washing machine at 30°C (86°F). Use a mild detergent. Do not bleach.
4. **Drying:** Do not tumble dry. Allow the blanket to air dry completely before reattaching the control unit and using it again. Ensure no moisture remains in the fabric or connectors.
5. **Ironing:** Do not iron the blanket.
6. **Dry Cleaning:** Do not dry clean.



Image 5.1: The heated blanket is machine washable at 30°C after detaching the control unit.

Storage

When not in use, especially during warmer months, store the blanket in a cool, dry place. Ensure it is clean and completely dry before folding and storing. Do not place heavy objects on top of the folded blanket, as this could damage the internal heating elements.

6. TROUBLESHOOTING

If you encounter any issues with your Imetec CaldoPlaid Velvet Square, please refer to the following common troubleshooting steps:

- **Blanket not heating:**
 - Ensure the power cord is securely plugged into both the wall outlet and the blanket's control unit.
 - Check if the wall outlet is functioning by plugging in another appliance.
 - Verify that the control unit is switched on and a temperature setting has been selected.
 - The Electro Block safety system may have activated. Unplug the blanket, wait a few minutes, and plug it back in. If the issue persists, contact customer support.
- **Control unit display not working:**
 - Ensure the blanket is properly connected to power and switched on.
 - If the display remains off, try unplugging and re-plugging the unit.
- **Blanket feels too hot or not hot enough:**
 - Adjust the temperature setting on the control unit. Remember there are 6 levels of heat.
 - Ensure the blanket is laid flat and not folded or bunched, which can concentrate heat.

If these steps do not resolve the issue, please contact Imetec customer support for further assistance. Do not attempt to repair the blanket yourself.

7. SPECIFICATIONS

Feature	Detail
Model Name	Imetec CaldoPlaid Velvet Square
Model Number	16775
Dimensions (LxWxH)	150 x 95 x 0.5 cm (approximately 59 x 37.4 x 0.2 inches)
Weight	1.37 kg (approximately 3 lbs)
Material	Polyester
Color	Grey
Power	150 Watts
Voltage	230 Volts
Temperature Settings	6 levels
Auto-off Timer	1, 3, or 9 hours
Special Features	Adapto Technology, Electro Block Safety System, Removable Control, Machine Washable at 30°C

8. WARRANTY & SUPPORT

Warranty Information

Your Imetec CaldoPlaid Velvet Square heated blanket is covered by a manufacturer's warranty against defects in materials and workmanship. Please refer to the warranty card included with your product for specific terms, conditions, and duration of coverage. Keep your proof of purchase for warranty claims.

Customer Support

For technical assistance, troubleshooting not covered in this manual, or warranty service, please contact Imetec customer support. Contact details can typically be found on the Imetec official website or on the product packaging. When contacting support, please have your product model number (16775) and date of purchase ready.

© 2024 Imetec. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question