

Minnie Minnie Typo Kalle

Product Instruction Manual

Minnie Car Seat - Model: Minnie Typo Kalle

1. INTRODUCTION

This manual provides essential information for the safe and proper use, installation, and maintenance of your **Minnie Car Seat**. Please read this manual thoroughly before first use and keep it for future reference.

This car seat is designed for children weighing from 9 kg to 36 kg, covering Group 1/2/3. It is manufactured by Team Tex, a leading European producer of child restraint systems.

2. SAFETY INFORMATION

WARNING: Use under adult supervision.

Always ensure the car seat is correctly installed and the child is properly secured according to the instructions provided in this manual. Failure to follow these instructions can result in serious injury or death.

- Never leave a child unattended in the car seat.
- Ensure all harness straps are snug and not twisted.
- Do not use the car seat if it has been involved in an accident, even if there is no visible damage.
- Refer to your vehicle's owner's manual for specific car seat installation guidelines.

3. PRODUCT OVERVIEW



Figure 3.1: Front view of the Minnie Car Seat. The car seat is predominantly black with pink trim along the base and a prominent Minnie Mouse character headrest. It features a 5-point harness system with shoulder pads and a crotch protector. The headrest is adjustable, and the seat includes a back and seat reducer cushion.

The Minnie Car Seat is a versatile child restraint system designed to grow with your child. Key features include:

- Shoulder pads for comfort.
- Back and seat reducer cushion for smaller children.
- Crotch protector.
- 5-point safety harness.
- Adjustable shoulder strap adjuster.
- 3 positions for safety harness height adjustment.
- Multi-position adjustable headrest.

4. SETUP AND INSTALLATION

4.1. Installation for Group 1 (9 kg to 18 kg)

For children weighing between 9 kg and 18 kg, the car seat must be secured to the vehicle using the vehicle's seat belt. The child must use the car seat's own 5-point safety harness.

1. Place the car seat on the vehicle's seat, facing forward.
2. Route the vehicle's 3-point seat belt through the designated belt paths on the car seat. Refer to the labels on the car seat for correct routing.
3. Buckle the vehicle's seat belt and pull it tight to remove any slack, ensuring the car seat is firmly secured and does not move more than 1 inch side-to-side or front-to-back at the belt path.
4. Place the child in the car seat and fasten the 5-point harness. Adjust the shoulder straps to be at or slightly above the child's shoulders.
5. Tighten the harness straps until snug against the child's body, ensuring you cannot pinch any slack at the collarbone.

4.2. Installation for Group 2 and 3 (15 kg to 36 kg)

For children weighing between 15 kg and 36 kg, the car seat is used without its internal 5-point safety harness. The child is secured directly by the vehicle's 3-point seat belt.

1. Remove the car seat's internal 5-point harness system. Consult the car seat's labels or specific instructions for harness removal.
2. Place the car seat on the vehicle's seat, facing forward.
3. Place the child in the car seat.
4. Route the vehicle's 3-point seat belt across the child and through the designated belt guides on the car seat. The lap belt should be low on the child's hips, touching the tops of the thighs, and the shoulder belt should lie across the middle of the child's shoulder and chest.
5. Buckle the vehicle's seat belt and pull it tight to remove any slack.

5. OPERATING INSTRUCTIONS

5.1. Adjusting the Headrest

The headrest is adjustable to multiple positions to accommodate your child's growth. To adjust, locate the adjustment lever (usually at the back or top of the headrest), squeeze or pull it, and slide the headrest up or down to the desired height. Ensure the headrest is locked into position before use.

5.2. Adjusting the 5-Point Harness (Group 1)

The 5-point harness has 3 positions for height adjustment at the shoulders. To adjust the harness height:

1. Unthread the harness straps from the back of the car seat.
2. Re-thread the straps through the harness slots that are at or just above your child's shoulders.
3. Ensure the straps are not twisted and are securely re-attached to the splitter plate at the back of the seat.

To tighten or loosen the harness, use the harness adjuster strap located at the front of the seat. Press the release button (if applicable) and pull the harness straps to loosen, or pull the adjuster strap to tighten.

6. CARE AND MAINTENANCE

Regular cleaning and maintenance will prolong the life of your car seat.

- **Fabric Covers:** The fabric covers, including shoulder pads, reducer cushion, and crotch protector, can typically be removed for cleaning. Refer to the care labels on the fabric for specific washing instructions. Generally, machine

wash on a delicate cycle with cold water and mild detergent, or hand wash. Air dry only; do not tumble dry.

- **Harness Straps:** Wipe harness straps with a damp cloth. Do not machine wash or submerge harness straps in water, as this can weaken the webbing.
- **Plastic Parts:** Wipe plastic parts with a damp cloth and mild soap. Do not use abrasive cleaners or solvents.
- **Buckle:** Periodically check the buckle for debris. Clean with a damp cloth.

Inspect the car seat regularly for any signs of wear, damage, or missing parts. If any damage is found, discontinue use and contact customer support.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Car seat is loose after installation.	Vehicle seat belt not tightened sufficiently.	Re-route and re-tighten the vehicle seat belt. Ensure less than 1 inch of movement at the belt path.
Harness straps are difficult to adjust.	Straps may be twisted or buckle may have debris.	Check for twists in the harness straps. Clean the buckle mechanism. Ensure the harness adjuster is fully released.
Child's head falls forward when sleeping.	Headrest not adjusted correctly or child is too small for forward-facing.	Adjust the headrest to provide proper support. Ensure the child meets the minimum weight and height requirements for forward-facing.

8. SPECIFICATIONS

Feature	Detail
Product Name	Minnie Car Seat
Model Number	Minnie Typo Kalle
Brand	Minnie (Manufactured by Team Tex)
Weight Group	Group 1/2/3 (9 kg to 36 kg)
Recommended Age	12 months - 11 years
Material	Plastic
Color	Pink
Installation Type	Vehicle Seat Belt
Orientation	Forward-facing
Product Dimensions	44 x 26.5 x 68 cm; 4.42 kg
ASIN	B08J9C1R1B
EAN	7898965893095

9. WARRANTY AND SUPPORT

Specific warranty information for this product is not provided in the available documentation. Please retain your proof of purchase for any warranty claims.

For technical support, spare parts, or further assistance, please contact the manufacturer, Team Tex, or the retailer where the product was purchased. Contact details may be found on the product packaging or the manufacturer's official website.

© 2023 Team Tex. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question