

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [ORTAL](#) /

› [ORTAL Replacement Remote Control User Manual for Fujitsu Air Conditioner AR-DB7](#)

ORTAL Replacement Remote Control for Fujitsu AR-DB7

ORTAL Replacement Remote Control User Manual

FOR FUJITSU AIR CONDITIONER MODEL AR-DB7

1. Introduction

This manual provides detailed instructions for the setup, operation, and maintenance of your ORTAL replacement remote control for Fujitsu AR-DB7 air conditioners. Please read this manual thoroughly before using the remote control to ensure proper function and longevity.



Image 1: Front view of the ORTAL Replacement Remote Control. This image displays the remote control's front face, showing the LCD screen, power button, mode selection, temperature adjustment, fan speed, timer, and other function buttons.

2. Setup

2.1 Battery Installation

The remote control requires two AAA batteries (included). Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch and lift to open.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Image 2: Rear view of the ORTAL Replacement Remote Control, showing the battery compartment. This image illustrates the location and mechanism for opening the battery cover to insert or replace batteries.

2.2 Initial Power-On

After installing the batteries, the remote control should power on automatically, displaying the current time and temperature settings on the LCD screen. No pairing is typically required for this infrared remote control; it should function directly with compatible Fujitsu AR-DB7 air conditioner models.

3. Operating Instructions

This section describes the primary functions and buttons of your remote control.

Remote Control Button Functions

Button Name	Function
START/STOP	Turns the air conditioner ON or OFF.
MODE	Cycles through operating modes: Cool, Dry, Fan, Heat (if applicable), Auto.
TEMP ▲/▼	Adjusts the desired temperature setting.
FAN	Adjusts fan speed: Auto, Low, Medium, High.
SWING LOUVER	Controls the vertical swing of the air conditioner's louver.

Button Name	Function
AIR FLOW DIRECTION	Adjusts the horizontal airflow direction.
TIMER	Sets the ON/OFF timer for the air conditioner. Refer to your air conditioner's manual for specific timer functions.
SLEEP	Activates or deactivates sleep mode, which adjusts temperature for comfortable sleep.
CLOCK	Sets the current time on the remote control's display.

Note: Some functions may vary depending on your specific Fujitsu AR-DB7 air conditioner model. Always point the remote control directly at the air conditioner's receiver for optimal performance. The maximum effective range is approximately 10 meters.

4. Maintenance

4.1 Cleaning

To clean the remote control, wipe it gently with a soft, dry cloth. Do not use liquid cleaners, abrasive materials, or chemical solvents, as these can damage the remote's surface or internal components.

4.2 Battery Replacement

Replace batteries when the display becomes dim or the remote control's response becomes sluggish. Always replace both batteries simultaneously with new AAA batteries of the same type (Zinc-carbon recommended). Remove batteries if the remote control will not be used for an extended period to prevent leakage.

5. Troubleshooting

- **Remote not responding:**

- Check if the batteries are correctly installed with the correct polarity.
- Replace old batteries with new ones.
- Ensure there are no obstructions between the remote control and the air conditioner's receiver.
- Verify that the remote control is within the effective operating range (approx. 10 meters).

- **Display is dim or blank:**

- Batteries are low; replace them.

- **Air conditioner not performing desired function:**

- Ensure the correct mode is selected on the remote control.
- Confirm that the air conditioner itself is powered on and functioning correctly.
- Some advanced functions might require specific settings on the air conditioner unit itself. Refer to your air conditioner's user manual.

6. Specifications

Brand: ORTAL

Compatible Devices: Fujitsu Air Conditioner (Model AR-DB7)

Connectivity Technology: Infrared

Controller Type: Button Control

Special Feature: Ergonomic design

Maximum Range: 10 Meters

Batteries: 2 x AAA (included)

Battery Composition: Zinc-carbon

7. Warranty and Support

Information regarding specific warranty terms or direct support contacts for this ORTAL replacement remote control is not available in this manual. Please refer to the retailer or your purchase documentation for warranty details and customer support options.

© 2023 ORTAL. All rights reserved.

Related Documents - Replacement Remote Control for Fujitsu AR-DB7

	<p><u>Ortal Traditional Series Installation and Operation Manual</u></p> <p>Comprehensive guide for the installation and operation of Ortal Traditional Series fireplaces (TR 90, TR 110), covering safety, product specs, installation, venting, gas, electrical, media, operation, and maintenance.</p>
	<p><u>ORTAL Gas Fireplace Installation and Operation Manual: Models, Safety, and Maintenance Guide</u></p> <p>This comprehensive manual from ORTAL Heating Solutions Ltd. provides detailed instructions for the installation, operation, and maintenance of ORTAL gas fireplaces. Covers safety warnings, product specifications, clearances, gas and electrical information, venting, and warranty details.</p>
	<p><u>Ortal Gas Fireplace Inserts Installation Manual</u></p> <p>Comprehensive installation manual for Ortal gas fireplace inserts, detailing safe installation, operation, and maintenance procedures. Includes troubleshooting and technical specifications.</p>
	<p><u>Ortal Wilderness Traditional Series Installation and Operation Manual</u></p> <p>Comprehensive guide for the installation and operation of Ortal Wilderness Traditional Series fireplaces, covering safety, product information, installation steps, building around the fireplace, venting, gas, electrical, firelog setups, and maintenance.</p>

<p>RECALL NOTICE Ortal USA</p> <p>TR90 and TR110 Direct Vent Gas Fireplaces</p> <p>Only units sold prior to February 2020 are included in this recall program.</p> <p></p> <p>Ortal is providing a recall program that includes Ortal TR90 and TR110 fireplaces that were sold and installed prior to February 2020. Once the level of risk of overheating insulation is determined, Ortal will provide a free retrofit. This recall is for Ortal TR90 and TR110 fireplaces only as the recall would not be a safety hazard. Ortal is not responsible for any damage or cost associated with the removal or replacement of the insulation or the cost of the inspection. Ortal will be responsible for the cost of the retrofit, which will be installed at no cost to the consumer.</p> <p>Customers should immediately stop using their TR90 and TR110 and contact their authorized Ortal dealer or distributor. If you are not sure if your fireplace is included, contact Ortal directly for inspection and resolution. If a customer is only interested in a</p> <p>818-238-7000 or visit their web site at www.ortalusa.com</p> <p><small>Print date April 8, 2022. In accordance with the U.S. Consumer Product Safety Commission.</small></p>	<p><u>Ortal TR90 and TR110 Direct Vent Gas Fireplace Recall Notice</u></p> <p>Recall notice for Ortal TR90 and TR110 Direct Vent Gas Fireplaces sold prior to February 2020 due to overheating risk. Consumers should stop use and contact Ortal for a free retrofit. Includes contact information and website.</p>
 <p>ORTAL®</p>	<p><u>Ortal Gas Fireplaces: Contemporary Design & Innovation</u></p> <p>Explore Ortal's collection of high-quality contemporary gas fireplaces, featuring innovative designs, advanced technology, and a commitment to environmental friendliness. Discover models inspired by nature and designed for modern living.</p>