

[Manuals.plus](#) /

> [E-YOOSO](#) /

> E-YOOSO K600 Mechanical Keyboard User Manual

## E-YOOSO K-600

# E-YOOSO K600 Mechanical Keyboard User Manual

## INTRODUCTION

This manual provides detailed instructions for the E-YOOSO K600 Mechanical Keyboard. The K600 is a full-size 104-key USB wired mechanical keyboard featuring Outemu Blue Switches, designed for both typing and gaming. It includes customizable rainbow LED backlighting and is built for durability and responsive performance.



Image: E-YOOSO K600 Mechanical Keyboard highlighting its key features.

## SETUP

The E-YOOSO K600 Mechanical Keyboard is designed for simple plug-and-play operation, requiring no additional driver software for basic functionality.

1. **Unpack the Keyboard:** Carefully remove the keyboard and its USB cable from the packaging.
2. **Connect to Computer:** Plug the USB cable of the keyboard into an available USB 2.0 port on your desktop computer, laptop, or compatible gaming console (Xbox, PS4).
3. **System Recognition:** Your operating system (Windows XP/7/8/10/VISTA, Mac OS X) will automatically detect and configure the keyboard.
4. **Begin Use:** The keyboard is now ready for typing and gaming.



Image: Connecting the USB cable for plug-and-play setup.

## OPERATING INSTRUCTIONS

---

### Backlight Modes

The K600 keyboard features rainbow LED backlighting with multiple modes and customization options.

- **Change Backlight Mode:** Press the **[FN] + [INS]** keys simultaneously to cycle through 9 different themed backlight modes.
- **Adjust Brightness:** Use **[FN] + [↑]** (Up Arrow) to increase brightness and **[FN] + [↓]** (Down Arrow) to decrease brightness.
- **Customizable Modes:** The keyboard supports 2 customizable backlight modes. Press **[FN] + [9]** or **[FN] + [0]** to access these modes. Each row of the keyboard is backlit in a fixed color, and switching the backlight mode changes the LED flashing pattern.



Image: Keyboard showcasing its 9 distinct backlight modes.

## N-Key Rollover

The K600 features N-key rollover, which means the keyboard can accurately register multiple key presses simultaneously. This is particularly beneficial for fast typing and complex gaming commands, ensuring every input is recognized without ghosting or missed keys.

## Blue Switches

The keyboard is equipped with Outemu Blue Switches, known for their distinct clicky sound and tactile feedback.

This provides a satisfying typing experience with a clear actuation point.



Image: Detailed view of the Outemu Blue Switches.

## Compatibility

The E-YOOSO K600 Mechanical Keyboard is compatible with a wide range of operating systems and devices:

- **Operating Systems:** Windows XP/7/8/10/VISTA, Mac OS X.
- **Devices:** Desktops, Laptops, MacBook, Xbox, and PS4.



## MAINTENANCE

---

Proper maintenance ensures the longevity and optimal performance of your E-YOOSO K600 Mechanical Keyboard.

- **General Cleaning:** Regularly wipe the keyboard surface with a soft, damp cloth. For dust and debris between keys, use compressed air.
- **Keycap Removal and Cleaning:** The K600 features removable keycaps. Use the included keycap puller to carefully remove keycaps for deeper cleaning or switch replacement. Clean the keycaps with mild soap and water, ensuring they are completely dry before reattaching.
- **Switch Replacement:** If a switch malfunctions, you can replace it using the included spare switches. Gently pull the keycap off, then use a switch puller (not included, but often comes with spare switches or can be purchased separately) to remove the faulty switch and insert a new one.



Image: Removable keycaps and switches for easy maintenance.

## TROUBLESHOOTING

---

If you encounter issues with your E-YOOSO K600 Mechanical Keyboard, refer to the following common problems and solutions:

- **Keyboard Not Responding:**
  - Ensure the USB cable is securely plugged into both the keyboard and the computer's USB port.
  - Try plugging the keyboard into a different USB port on your computer.
  - Restart your computer.
- **Keys Not Registering or Double-Registering:**
  - This can sometimes be caused by debris under the keycap or a faulty switch. Remove the affected keycap using the keycap puller and clean the area with compressed air.
  - If cleaning does not resolve the issue, consider replacing the switch with one of the included spare switches.
- **Backlight Not Working or Incorrectly Displaying:**
  - Ensure the keyboard is properly connected.
  - Cycle through backlight modes using **[FN] + [INS]**.
  - Adjust brightness using **[FN] + [↑]** or **[FN] + [↓]**.

## SPECIFICATIONS

---

Detailed technical specifications for the E-YOOSO K600 Mechanical Keyboard:

<b>Feature</b>	<b>Detail</b>
Brand	E-YOOSO
Model Number	K-600
Connectivity Technology	USB Wired
Number of Keys	104
Switch Type	Blue Switches (Outemu)
Backlight	Rainbow LED, 9 Modes
Key Rollover	N-Key Rollover
Compatible Operating Systems	Windows XP/7/8/10/VISTA, Mac OS X
Product Dimensions (L x W x H)	17.32" x 5.71" x 1.18"
Item Weight	1.81 Pounds
Material	Acrylonitrile Butadiene Styrene, Steel

# ERGONOMIC DESIGN

Make your typing and gaming more comfortable

Sturdy Keyboard Body




Image: Ergonomic design features of the keyboard, including adjustable feet.

## WARRANTY AND SUPPORT

---

E-YOOSO is committed to providing quality products and customer satisfaction.

- **Warranty:** All E-YOOSO keyboards come with a lifetime warranty service.
- **Customer Support:** If you have any questions, concerns, or require assistance with your E-YOOSO K600 Mechanical Keyboard, please do not hesitate to contact our customer support. Refer to the product packaging or the official E-YOOSO website for specific contact information.