## AILINKE B08JG35ZN3

# AILINKE Ultrasonic Cool Mist Humidifier Instruction Manual

Model: B08JG35ZN3
Brand: AILINKE

## 1. Product Overview

The AILINKE Ultrasonic Cool Mist Humidifier is designed to provide efficient humidification for large areas up to 1000 sq.ft. It features an 800ml/h mist output, suitable for various environments including homes, offices, greenhouses, and warehouses. This unit operates with ultrasonic technology, producing a cool mist to maintain desired humidity levels. It is compatible with standard water jugs (2-5 gallons) with a 2.16-inch (5.5cm) neck opening.




Image: The AILINKE humidifier in a household setting, demonstrating its use in a living space.




Image: The humidifier positioned among indoor plants, highlighting its suitability for maintaining plant health.

## 2. Safety Information

- Read all instructions thoroughly before operating the humidifier.
- Keep the humidifier out of reach of children and pets.
- Always place the humidifier on a firm, flat, water-resistant surface.
- Do not immerse the main body of the humidifier in water or other liquids.
- Ensure the power cord is not damaged and is properly plugged into a suitable electrical outlet.
- Do not block the mist outlet or air intake during operation.
- Use only clean, cool tap water or distilled water. Do not add essential oils directly into the water reservoir or base.
- Unplug the unit before cleaning, refilling, or moving.

## 3. Product Components

Familiarize yourself with the main components of your AILINKE humidifier:





Image: Exploded diagram showing the Mist Nozzle, Mist Tube, Mist Tube Connection, Cover, Sink (A), Main Body (B), Hose (C), Element Filter (D), and Water Bottle Container (E).

- **Mist Nozzle:** Directs the mist output.
- **Mist Tube:** Extends the mist output upwards.
- **Mist Tube Connection:** Connects the mist tube to the main body.
- **Cover:** Top cover of the main unit.
- **Sink (A):** The internal water basin where mist is generated.
- **Main Body (B):** Contains the control panel and internal electronics.
- **Hose (C):** Connects the main body to the element filter and draws water.

- **Element Filter (D):** Filters water before it enters the main unit.
- **Water Bottle Container (E):** User-supplied water jug (not included).

## 4. Setup Instructions

Follow these steps to set up your humidifier for first use:

1. **Choose a Water Jug:** Select a water jug (2-5 gallons) with a neck opening of approximately 2.16 inches (5.5 cm). Ensure the jug is clean.





Image: Visual guide on selecting the correct water jug with an appropriate neck size for secure fitting.

2. **Assemble the Hose and Filter:** Connect the hose (C) to the element filter (D). Ensure a secure connection.



Image: A close-up of hands connecting the transparent hose to the white element filter.

3. **Insert Filter into Jug:** Insert the element filter (D) with the attached hose into the bottom of your chosen water bottle

container (E).

4. **Connect Hose to Main Body:** Insert the other end of the hose (C) into the designated inlet in the sink (A) of the main body (B).



Image: A hand inserting the hose into the water sink area of the humidifier's main body.

5. **Attach Main Body to Jug:** Place the main body (B) securely onto the neck of the water bottle container (E). Ensure it sits firmly.



Image: Underside view of the humidifier showing the hose and filter correctly installed and ready to connect to a water jug.

6. **Attach Mist Tube and Nozzle:** Connect the mist tube to the main body, then attach the mist nozzle to the top of the mist tube.
7. **Power On:** Plug the power cord into a standard electrical outlet. The unit is now ready for operation.

Your browser does not support the video tag.

Video: A detailed guide on the assembly and initial setup of the AILINKE humidifier.

## 5. Operating Instructions

The humidifier can be controlled via its touch panel or the included remote control.

### Power On/Off

- Press the power button on the control panel or remote to turn the unit on or off.

### Adjusting Mist Levels

- The humidifier offers 3 mist levels. Press the mist level button to cycle through low, medium, and high settings.

### Customized Humidity Setting

- Use the humidity setting button to set your desired humidity level between 40% and 80%. The unit will automatically maintain this level.

### Timer Function

- Activate the timer function to set the humidifier to operate for a specific duration, from 1 to 12 hours. The unit will automatically shut off once the timer expires.

### Sleep Mode

- Engage Sleep Mode for quiet operation (noise level ≤35dB) and dimmed display lights, ideal for nighttime use.




Image: The humidifier operating in sleep mode, indicating its low noise level suitable for a bedroom environment.

### Auto Shut-off Protection

- The humidifier is equipped with an auto shut-off feature that activates when the water level is low, preventing damage to the unit.




Image: An icon illustrating the auto shut-off protection feature, which activates when water levels are low.

Your browser does not support the video tag.

Video: An overview of the humidifier's key features and operational modes.

## 6. Maintenance

Regular maintenance ensures optimal performance and longevity of your humidifier.

### Element Filter

- No replacement filter is needed. The element filter is designed to be self-cleaning when dry.




Image: A close-up view of the humidifier's element filter, highlighting its design.

### Cleaning the Sink and Atomizer

- Clean the sink (A) and atomizer monthly to prevent mineral buildup and ensure hygienic operation.
- Unplug the unit before cleaning.
- Use a soft cloth and mild detergent to wipe down the surfaces.
- A handy sponge is included for your convenience in cleaning.

## 7. Troubleshooting

If you encounter issues with your humidifier, refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
|---|---|---|
| Unit does not power on. | No power supply; loose connection. | Ensure the power cord is securely plugged into a working electrical outlet. Check if the outlet has power. |
| No mist output or reduced mist. | Low water level; mineral buildup on atomizer; blocked mist outlet. | Refill the water jug. Clean the atomizer and sink (A) as per maintenance instructions. Ensure the mist outlet is clear of obstructions. |
| Unusual noise during operation. | Unit not level; foreign object in water tank; fan obstruction. | Place the humidifier on a flat, stable surface. Check the water tank for any foreign objects. Ensure the fan area is clear. |
| Water leakage. | Improperly seated water jug; damaged hose/seal. | Ensure the main body is correctly and securely seated on the water jug. Check the hose connections and seals for any damage. |

Your browser does not support the video tag.

Video: A comprehensive guide covering common issues and troubleshooting steps for the humidifier.

## 8. Specifications

| Feature | Specification |
|---|---|
| Brand | AILINKE |
| Model Name | Cool Mist Humidifier |
| Operation Mode | Ultrasonic |
| Mist Output | 800 ml/h (Maximum) |
| Floor Area Coverage | Up to 1000 Square Feet |
| Control Method | Touch, Remote Control |
| Special Features | Auto Shut Off, Humidistat, Timer |
| Timer Settings | 1-12 Hours |
| Noise Level | ≤35dB (Sleep Mode) |
| Product Dimensions | 10.28 x 13.89 x 10.28 inches |
| Item Weight | 4.4 pounds (2 Kilograms) |
| Included Components | Hose, Element Filter |
| Batteries | 1 Lithium Ion battery required (included for remote) |

## 9. Warranty and Support

For warranty information, please refer to the documentation included with your purchase or contact AILINKE customer service directly.

For technical support or further assistance, please contact AILINKE customer service through their official website or the contact information provided in your product packaging.

© 2023 AILINKE. All rights reserved.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**