

[Manuals.plus](#) /

› [XP-Pen](#) /

› XP-PEN ACJ01 Protective Case User Manual for Artist 15.6 Pro, Artist 13.3 Pro, Innovator 16

XP-Pen ACJ01

XP-PEN ACJ01 Protective Case User Manual

For Artist 15.6 Pro, Artist 13.3 Pro, and Innovator 16 Graphic Displays

1. INTRODUCTION

The XP-PEN ACJ01 Protective Case is designed to provide secure and convenient transport for your graphic display tablet and accessories. This manual outlines the features, usage, and care instructions for your ACJ01 case.

2. PRODUCT FEATURES

- **Durable Material:** Constructed from waterproof Oxford fabric for exterior protection.
- **Soft Interior:** Features a flocked interior lining to prevent scratches and provide cushioning.
- **Secure Closure:** Equipped with a double top-loading zipper for easy access and secure storage.
- **Accessory Compartment:** Includes an exterior pocket for convenient storage of pens, cables, and other small accessories.
- **Compatibility:** Designed to fit graphic displays up to 15.6 inches.



Image: The ACJ01 case showing the exterior pocket filled with a pen and cables.

3. COMPATIBILITY

The ACJ01 Protective Case is compatible with the following XP-PEN graphic display models:

- XP-Pen Artist 15.6 Pro
- XP-Pen Artist 13.3 Pro
- XP-Pen Innovator 16

It is also suitable for other laptops, Ultrabooks, or tablets with screen sizes up to 15.6 inches, provided their dimensions fit within the case's internal measurements.

4. USAGE INSTRUCTIONS

4.1 Inserting Your Device

1. Unzip the main compartment of the ACJ01 case using the double zippers.
2. Carefully slide your graphic display tablet or compatible device into the main compartment. Ensure the device is centered and fully enclosed by the soft interior lining.
3. Close the zippers completely to secure your device.



Image: A user carefully placing a graphic tablet into the main compartment of the ACJ01 case.

4.2 Using the Accessory Pocket

- The front pocket is designed for smaller items such as styluses, USB cables, power adapters, or cleaning cloths.
- Place accessories gently into the pocket. Avoid overfilling to prevent strain on the case material or potential damage to your main device.

5. CARE AND MAINTENANCE

- **Cleaning:** Wipe the exterior with a damp cloth and mild soap if necessary. Do not machine wash or tumble dry.
- **Drying:** Air dry the case completely before storing any electronic devices inside.
- **Storage:** Store the case in a cool, dry place away from direct sunlight when not in use.
- **Water Resistance:** While the Oxford fabric is waterproof, avoid submerging the case in water or exposing it to heavy rain for extended periods.




Image: Water droplets on the case demonstrating its waterproof feature.

6. SPECIFICATIONS

Model	ACJ01
Dimensions (L x W x H)	475 x 290 x 25 mm (18.7 x 11.4 x 1.0 inches)
Weight	390 grams
Material	Waterproof Oxford Fabric (Exterior), Flocking Fabric (Interior)
Color	Grey
Maximum Compatible Device Size	16 Inches
Special Feature	Waterproof
Manufacturer Part Number	DEYZACJ01




Image: Front view of the ACJ01 protective case.

7. TROUBLESHOOTING

This product is a protective case and typically does not require troubleshooting. However, consider the following if you encounter issues:

- **Device Not Fitting:** Ensure your device's dimensions (length, width, thickness) are within the case's specifications (475 x 290 x 25 mm).
- **Zipper Issues:** Avoid forcing the zippers. If they become stiff, ensure no fabric is caught.
- **Stains:** Refer to the 'Care and Maintenance' section for cleaning instructions.

8. WARRANTY AND SUPPORT

For warranty information or product support, please refer to the official XP-PEN website or contact their customer service directly.
Keep your purchase receipt for warranty claims.
Official XP-PEN Website: www.xp-pen.com

