

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Fastrack](#) /

› [Fastrack Fastfit Analog Gray Dial Men's Watch \(Model NT3227SM01\) Instruction Manual](#)

### Fastrack NT3227SM01

## Fastrack Fastfit Analog Gray Dial Men's Watch (Model NT3227SM01) Instruction Manual

**Brand:** Fastrack

**Model:** NT3227SM01

### PRODUCT OVERVIEW

The Fastrack Fastfit watch is designed to enhance your everyday style. It features a bold anthracite grey dial with dynamic red and grey subdials, combining ruggedness with modern aesthetics. Encased in sleek stainless steel with a matching metallic strap, this timepiece offers reliable functionality with 24-hour, day, and date subdials. The textured links on the robust silver-tone bracelet add a sporty touch, making it an ideal accessory for individuals who appreciate bold confidence and purposeful design.



Front view of the Fastrack Fastfit Analog Gray Dial Men's Watch, showcasing the anthracite dial and silver-tone stainless steel strap.

## SETUP AND TIME SETTING

---

### Initial Setup

Your Fastrack Fastfit watch is designed for immediate use. Before wearing, ensure the crown is pushed in to start the movement. If the watch is not running, it may require a gentle shake or the battery may need to be activated or replaced.

### Setting the Time

1. Pull the crown out to the **second click position** (farthest out).
2. Rotate the crown to move the hour and minute hands to the desired time.
3. Push the crown back in to the normal position to start the watch movement.

### Setting the Date and Day

1. Pull the crown out to the **first click position**.

2. Rotate the crown clockwise or counter-clockwise to adjust the date and day subdials. (Note: The direction for each adjustment may vary; rotate gently until the correct date and day are displayed).
3. Push the crown back in to the normal position.



Side view of the watch, illustrating the crown and pushers used for time and subdial adjustments.

## OPERATING THE WATCH

This Fastrack Fastfit watch features a multifunction dial with dedicated subdials for 24-hour time, day of the week, and date.

### Reading the Multifunction Dial

- **24-Hour Subdial:** This subdial indicates the current hour in a 24-hour format, useful for distinguishing between AM and PM.
- **Day Subdial:** This subdial displays the current day of the week.
- **Date Subdial:** This subdial shows the current date.



Close-up of the watch dial, highlighting the 24-hour, day, and date subdials for easy reading.

## Using the Pushers

The watch features two pushers on the side of the case. These pushers are typically used in conjunction with the crown for independent adjustment of the day and date subdials. Refer to the "Setting the Date and Day" section for detailed adjustment instructions.

## MAINTENANCE AND CARE

---

### Water Resistance

This Fastrack Fastfit watch is water resistant up to **50 meters (5 ATM)**. This rating indicates that the watch is suitable for everyday use and can withstand splashes, rain, and brief immersion in water. It is *not* designed for swimming, diving, or showering. To maintain water resistance, avoid operating the crown or pushers when the watch is wet or submerged.

### Cleaning

To clean your watch, gently wipe the case and strap with a soft, dry cloth. For the stainless steel strap, a slightly damp cloth can be used to remove dirt, followed immediately by a dry cloth to prevent water spots. Avoid using harsh chemical cleaners, solvents, or abrasive materials, as these can damage the watch's finish.

## Battery Replacement

The watch is powered by a Silver Oxide battery. When the watch stops or the second hand begins to skip, it indicates that the battery is low and requires replacement. Battery replacement should always be performed by a qualified watch technician or an authorized service center to ensure the watch's integrity and water resistance are maintained.



Rear view of the watch, displaying the stainless steel case back with model and water resistance information.

## TROUBLESHOOTING

- **Watch not running:** Ensure the crown is fully pushed in to the normal operating position. If the watch still does not run, the battery may need replacement.
- **Incorrect time or date:** Follow the instructions in the "Setting the Time" and "Setting the Date and Day" sections to reset the watch.
- **Condensation inside the watch:** The presence of condensation under the crystal may indicate a loss of water resistance. Have the watch inspected by a service professional immediately to prevent further damage.

For any issues not covered here, or for professional assistance, please contact Fastrack customer support or

an authorized service center.

## SPECIFICATIONS

Feature	Detail
Brand	Fastrack
Model	NT3227SM01
Model Name	Fastfit
Display Type	Analog
Power Source	Battery Powered
Battery Cell Composition	Silver Oxide
Special Features	Arabic Numerals, Second Hand, 24-hour, Day, and Date Subdials
Water Resistance	50 Meters (5 ATM)
Item Weight	200 g
Product Dimensions	14 x 10 x 7 cm
Country of Origin	India
Manufacturer	Titan Company Limited

## WARRANTY AND SUPPORT

This Fastrack watch comes with a standard manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions regarding coverage duration and service procedures. It is recommended to retain your proof of purchase for warranty claims.

For service, repairs, or further assistance, please visit the official Fastrack website or locate an authorized Fastrack service center near you. Contact information for customer support can typically be found on the Fastrack website or in the documentation provided with your watch.

**Manufacturer:** Titan Company Limited, Sipcot Industrial Complex, Hosur, Tamil Nadu - 635129, India.