

TOPMB HT8008-JC

TOPMB LED Reading Lamp HT8008-JC User Manual

Model: HT8008-JC

1. INTRODUCTION

Thank you for choosing the TOPMB LED Reading Lamp, Model HT8008-JC. This eye-care desk lamp is designed to provide versatile and comfortable lighting for various tasks, including reading, studying, and working. Featuring a high CRI of 95+, dimmable brightness, 3 color modes, and a flexible 360° swivel head, this lamp ensures optimal illumination while protecting your eyes.

2. SAFETY INSTRUCTIONS

- Ensure the power source matches the lamp's voltage (120V AC).
- Do not disassemble or modify the lamp. Refer all servicing to qualified personnel.
- Avoid exposing the lamp to water or high humidity. This product is not waterproof.
- Keep the lamp away from heat sources and direct sunlight.
- Do not look directly into the LED light source for extended periods to prevent eye strain.
- Ensure the clamp is securely fastened to a stable surface before use.
- Unplug the lamp from the power outlet before cleaning or when not in use for a long time.

3. PACKAGE CONTENTS

Upon unpacking, please verify that all the following items are included:




- TOPMB LED Reading Lamp (Model HT8008-JC)
- Power Cable
- User Manual (this document)


4. PRODUCT OVERVIEW

The TOPMB LED Reading Lamp features a sleek design with intuitive touch controls and a flexible gooseneck for versatile positioning.

WYH CHOOSE TOPMB?


High Level LED Light Source Bring You a Ture Color Vision





Most spectrum output

LED light's peaks and valleys strain your eyes with uneven wavelengths.



TOPMB CRI > 95+ Healthier Lighting

Eye-friendly technology matches the sun's spectrum, providing a balanced and smooth illumination.

Figure 4.1: Product Dimensions and Components. This image illustrates the key components of the TOPMB LED Reading Lamp, including the 7.9-inch lamp head, 22.5-inch gooseneck, and the clamp with a maximum opening of 2 inches. It also shows the power adapter and the 360° flexible gooseneck capability.

- **Lamp Head:** Contains 40 high-quality LED light beads, providing up to 700 lumens of brightness.
- **Control Panel:** Touch-sensitive buttons for power, mode selection, and brightness adjustment.
- **Flexible Gooseneck:** Allows 360° rotation and adjustment of the lamp head for optimal positioning.
- **Sturdy Clamp:** Attaches securely to desks or tables up to 2 inches thick, featuring silicone pads to protect surfaces.
- **Power Adapter:** Connects the lamp to a standard electrical outlet.

5. SETUP

Follow these steps to set up your TOPMB LED Reading Lamp:

1. **Choose a Location:** Select a stable desk or table surface where you intend to use the lamp. Ensure the surface thickness is within the clamp's maximum opening of 2 inches.
2. **Attach the Clamp:**
 - Unscrew the clamp knob until the opening is wide enough to fit over your desired surface.
 - Position the clamp on the edge of your desk or table.
 - Tighten the clamp knob clockwise until it is firmly secured. Ensure the lamp is stable and does not wobble. The silicone pads on the clamp will protect your furniture.
3. **Connect Power:** Insert the power cable into the lamp's power port, then plug the adapter into a standard 120V AC electrical outlet.
4. **Adjust Lamp Position:** Gently bend and rotate the flexible gooseneck to position the lamp head as desired. The 360° swivel head allows for precise light direction.



Figure 5.1: Attaching the Clamp. This image demonstrates the process of securing the lamp's clamp to a desk edge. The screw mechanism allows for easy adjustment and a firm grip, ensuring stability.

Your browser does not support the video tag.

Video 5.1: Installation and Features Overview. This video provides a comprehensive guide on how to install the TOPMB LED Reading Lamp and highlights its key features, including the flexible gooseneck and touch controls. It also demonstrates the different light modes and brightness levels.

6. OPERATING INSTRUCTIONS

The TOPMB LED Reading Lamp features a touch-sensitive control panel located on the lamp head.

SENSITIVE TOUCH CONTROL



Figure 6.1: Sensitive Touch Control Panel. This image shows the touch control panel on the lamp head, indicating the power button, brightness adjustment buttons (up/down arrows), and the mode button (M). It also illustrates the three color modes (Warm Light, Warm White Light, Cool White Light) and three brightness levels (20%, 50%, 100%).

1. Power On/Off:

- Tap the **Power button** () once to turn the lamp on or off.

2. Adjust Brightness:

- **Stepless Dimming:** Press and hold the **Up** () or **Down** () arrow buttons to smoothly increase or decrease brightness (20% to 100%).
- **5 Dimmable Levels:** Tap the **Up** or **Down** arrow buttons to cycle through 5 preset brightness levels.

3. Change Color Mode:

- **Stepless Color Temperature:** Press and hold the **Mode button** (M) to smoothly adjust the color temperature from warm (3000K) to cool (6000K) light.
- **3 Color Modes:** Tap the **Mode button** (M) to cycle through 3 preset color modes: Warm Light (3000K), Warm White Light (4000K), and Cool White Light (6000K).

4. 4-Hour Auto-Off Timer:

- The lamp features an automatic 4-hour shut-off timer for energy saving. This function is activated automatically.

5. Memory Function:

- The lamp remembers your last brightness and color mode settings when turned off and on again.

Your browser does not support the video tag.

Video 6.1: Touch Control Demonstration. This video demonstrates the touch controls for the TOPMB LED Reading Lamp, showing how to power on/off, adjust brightness, and switch between different color modes. It highlights the ease of use and responsiveness of the touch panel.

7. MAINTENANCE

- **Cleaning:** Disconnect the power before cleaning. Use a soft, dry cloth to wipe the lamp. Do not use abrasive cleaners or solvents.
- **Storage:** If storing the lamp for an extended period, unplug it and store it in a cool, dry place.

8. TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|--|---|---|
| Lamp does not turn on. | <ul style="list-style-type: none">◦ Power cable not properly connected.◦ No power from the outlet.◦ Touch control unresponsive. | <ul style="list-style-type: none">◦ Check if the power cable is securely plugged into both the lamp and the outlet.◦ Test the outlet with another device.◦ Ensure your finger is making full contact with the touch button. |
| Brightness or color mode cannot be adjusted. | <ul style="list-style-type: none">◦ Incorrect touch gesture. | <ul style="list-style-type: none">◦ For stepless adjustment, press and hold the respective button. For cycling through presets, tap the button. |
| Lamp turns off unexpectedly. | <ul style="list-style-type: none">◦ 4-hour auto-off timer activated. | <ul style="list-style-type: none">◦ This is a normal function. Simply turn the lamp back on if you wish to continue using it. |

9. SPECIFICATIONS

| Feature | Detail |
|------------|-----------|
| Model Name | HT8008-JC |
| Brand | TOPMB |

| Feature | Detail |
|-----------------------------|--|
| Light Source Type | LED |
| Wattage | 10 Watts |
| Brightness | 700 Lumens (Max) |
| Color Modes | 3 (3000K Warm, 4000K Warm White, 6000K Cool White) |
| Dimmable Levels | 5 preset levels, stepless adjustment |
| Color Rendering Index (CRI) | >95 |
| Gooseneck Flexibility | 360° Swivel Lamp Head |
| Switch Type | Touch Control |
| Auto-Off Timer | 4 Hours |
| Power Source | Corded Electric (120 Volts AC) |
| Material | Plastic, Metal (Base) |
| Product Dimensions | 2"D x 7.9"W x 16"H (approximate, flexible) |
| Item Weight | 1.98 Pounds |
| UPC | 791598584736 |

10. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the product packaging or contact TOPMB customer service directly. Keep your purchase receipt for any warranty claims.

TOPMB is committed to providing quality products and excellent customer service. For further assistance, please visit the [TOPMB Store on Amazon](#).