

SelfieShow L02S

SelfieShow Selfie Stick with Fill Light (Model L02S) Instruction Manual

INTRODUCTION


Thank you for choosing the SelfieShow L02S Selfie Stick with Fill Light. This versatile device combines a selfie stick, tripod, and fill light to enhance your photography and videography experience. Designed for portability and ease of use, it features an extendable rod, a detachable wireless remote, and adjustable lighting to suit various environments and creative needs.

Key features include:

- **Integrated Fill Light:** Offers 3 color temperature options and 6 brightness levels for optimal lighting.
- **Adjustable Angle:** 360° clamp rotation for horizontal or vertical phone orientation and 225° neck rotation for diverse shooting angles.
- **Portable Design:** Lightweight (6.7oz) and compact (7.6" folded size) for easy transport. Extends up to 40.3 inches (104cm).
- **Detachable Wireless Remote:** Control your phone's camera from up to 10m/33ft away.
- **Wide Compatibility:** Supports most iOS and Android devices (4-6.5 inches) without requiring additional apps.

6 Brightness Levels

3 Color Temperature Options



The SelfieShow L02S Selfie Stick with Fill Light in its compact, portable state.

SETUP INSTRUCTIONS

1. **Unfold the Selfie Stick:** Gently unfold the phone clamp from the main body of the stick.
2. **Extend the Rod:** Pull the telescopic rod upwards to extend it to your desired length. The rod can extend up to 104cm (40.3 inches).
3. **Open Tripod Legs:** If using as a tripod, push the bottom part of the handle upwards to release and spread the three tripod legs for stability. Ensure the legs are fully extended on a flat surface.
4. **Mount Your Phone:** Open the phone clamp and carefully place your smartphone inside. The clamp is designed to securely hold devices between 4 and 6.5 inches.
5. **Adjust Phone Angle:** Rotate the phone clamp 360° to switch between horizontal (landscape) and vertical (portrait) modes. The neck also rotates 225° for fine-tuning your shooting angle.
6. **Detachable Remote:** The wireless remote control is located on the handle. Slide it out to detach for remote operation.



Detailed diagram illustrating the components and setup steps of the SelfieShow L02S Selfie Stick.

OPERATING INSTRUCTIONS

Pairing the Wireless Remote

1. Ensure the remote is charged (if applicable, use the provided USB cable).
2. Press and hold the button on the remote control until a blue indicator light starts flashing, indicating it's in pairing mode.
3. On your smartphone, go to Bluetooth settings and search for available devices.
4. Select "SelfieShow" or a similar device name from the list to connect. The blue light will become solid once paired.
5. For Android smartphones, you may need to set the volume button as the camera button in your phone's camera settings for the remote to function correctly.

Using the Remote Control

Once paired, open your smartphone's camera app. Press the button on the remote to take photos or start/stop video recording. The remote has a control range of up to 10m/33ft.



The detachable wireless remote control allows for convenient photo and video capture from a distance.

Activating and Adjusting the Fill Light


1. Locate the fill light on the phone clamp.
2. Press the dedicated button on the fill light to turn it on.
3. Press the button repeatedly to cycle through 3 light modes (White, Natural, Warm) and 6 brightness levels.
4. Hold the button to turn the fill light off.



The fill light offers White, Natural, and Warm color temperatures with multiple brightness settings.

Using as a Selfie Stick or Tripod

The device can be used handheld as an extendable selfie stick or placed on a flat surface as a stable tripod. The 360° rotating clamp and 225° neck rotation allow for versatile shooting angles, whether for full-body photos, live streaming, or group shots.



The selfie stick allows for 360° clamp rotation and 270° neck rotation for multi-angle shooting.

MEDIA DEMONSTRATIONS

Product Overview and Usage

Video demonstrating the SelfieShow L02S Selfie Stick's features, including its tripod function and integrated lights. This video provides a general overview of the product's capabilities and how it can be used for various content creation needs.

Detailed Review and Setup

A comprehensive review of the Anti-Shake Selfie Stick Tripod with LED Light, covering unboxing, setup, and various operational aspects. This video is useful for understanding the product's components and how to assemble and use them effectively.

Key Features and Portability

This video highlights the great features of the SelfieShow L02S tripod, emphasizing its portability, ease of use, and various functionalities for capturing photos and videos.

MAINTENANCE

- **Cleaning:** Wipe the selfie stick and light with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures.

Ensure it is fully collapsed and the remote is securely placed in its slot.

- **Battery Care:** For the remote control, ensure the battery is properly installed. If not in use for extended periods, consider removing the battery to prevent leakage.

TROUBLESHOOTING

- **Remote Not Pairing:**

- Ensure the remote is charged and powered on (blue light flashing).
- Check your phone's Bluetooth settings to ensure it's discoverable and try re-pairing.
- Verify the remote's battery is not depleted.

- **Light Not Turning On/Adjusting:**

- Ensure the fill light is charged.
- Press the light button firmly to activate and cycle through modes.

- **Phone Not Stable in Clamp:**

- Ensure your phone size is within the supported 4-6.5 inch range.
- Remove bulky phone cases if they prevent a secure fit.

- **Tripod Instability:**

- Ensure the tripod legs are fully extended and placed on a flat, stable surface.
- Avoid extending the telescopic rod to its maximum length in windy conditions or on uneven ground.

SPECIFICATIONS

Product Dimensions	1.77"D x 1.38"W x 40.31"H
Folded Size	7.6 inches
Maximum Height	100 Centimeters (40.3 inches)
Item Weight	6.7 Ounces
Material	Aluminum, Plastic
Compatible Devices	Camera, Cellphone (4-6.5 inches)
Special Features	Adjustable, Lightweight, Portable, Fill Light, Wireless Remote
Batteries	1 C battery required (included)

WARRANTY AND SUPPORT

The SelfieShow L02S Selfie Stick with Fill Light comes with a worry-free 1-year warranty. Our dedicated customer service team is available to assist you 7 days a week, 24 hours a day. For any inquiries or support needs, please refer to the contact information provided with your product packaging or visit the official SelfieShow website.

