

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Lenoxx](#) /
- › [Lenoxx MY Rose Hair Straightener PPA765 - User Manual](#)

Lenoxx PPA765

User Manual

LENOXX MY ROSE HAIR STRAIGHTENER - MODEL PPA765

Model: PPA765 | Brand: Lenoxx

1. INTRODUCTION

Thank you for choosing the Lenoxx MY Rose Hair Straightener, Model PPA765. This appliance is designed to provide efficient and effective hair straightening and styling, featuring advanced tourmaline technology for smooth, shiny results. Please read this manual carefully before use to ensure safe and optimal performance.



Image 1.1: The Lenoxx MY Rose Hair Straightener in its closed position, showcasing its sleek black and rose gold design.

2. IMPORTANT SAFETY INFORMATION

WARNING: To reduce the risk of burns, electrocution, fire, or injury to persons:

- **Burn Hazard:** Surfaces become extremely hot during use. Avoid contact with skin.
- **Electric Shock Risk:** Keep away from water. Do not use near bathtubs, sinks, or other water sources.
- **Fire Risk:** Unplug when not in use. Do not leave unattended when plugged in.
- Keep out of reach of children.
- Do not use this appliance with a voltage converter.
- Always inspect the appliance for damage before use. Do not use if the cord or plug is damaged.

3. PRODUCT COMPONENTS AND FEATURES

Familiarize yourself with the different parts of your Lenoxx MY Rose Hair Straightener:



Image 3.1: Diagram illustrating key components of the straightener, including ceramic plates, on/off button, and swivel cord.

- **Ceramic Tourmaline Plates:** These plates heat up quickly and evenly, providing a smooth glide and helping to reduce frizz. The ceramic coating ensures even heat distribution for consistent results.
- **On/Off Button:** Located on the handle for easy power control.
- **Pilot Indicator Light:** Illuminates when the straightener is powered on and heating.
- **360° Swivel Cord:** Allows for flexible movement and prevents tangling during use.
- **Lock Mechanism:** For safe storage and travel, keeping the plates closed.



Image 3.2: Close-up view of the ceramic tourmaline plates, highlighting the smooth surface and branding.

4. SETUP AND FIRST USE

1. **Unpack:** Carefully remove the straightener from its packaging. Ensure all components are present.
2. **Placement:** Place the straightener on a heat-resistant, flat surface.

3. **Plug In:** Insert the power plug into a suitable electrical outlet. The straightener is bivolt (automatic dual voltage), making it suitable for various power supplies.
4. **Power On:** Press the On/Off button. The pilot indicator light will illuminate, indicating that the straightener is heating up.
5. **Heat Up:** Allow the straightener to heat for approximately 30-60 seconds until it reaches its optimal temperature (up to 250°C).

5. OPERATING INSTRUCTIONS

For best results, ensure your hair is clean, dry, and free of tangles before styling.

5.1. Straightening Hair

1. Divide your hair into small, manageable sections.
2. Take one section and place it between the ceramic plates, close to the roots.
3. Gently close the plates and glide the straightener slowly down the section of hair, from root to tip. Do not hold the straightener in one place for too long to avoid heat damage.
4. Repeat for all sections until desired straightness is achieved.

5.2. Creating Curls or Waves

The rounded design of the Lenoxx MY Rose straightener allows for versatile styling, including creating curls and waves.



Image 5.1: The straightener's rounded design enables both straightening and curling, offering styling versatility.

1. Take a section of hair and clamp it between the plates.
2. Rotate the straightener 180 degrees away from your face.
3. Slowly pull the straightener down the hair shaft, maintaining the rotation. The hair will wrap around the barrel, forming a curl.
4. Release the hair and allow the curl to cool before touching it.

After use, press the On/Off button to turn off the appliance and unplug it from the power outlet. Allow it to cool completely before storing.

6. MAINTENANCE AND CARE

- **Cleaning:** Ensure the straightener is unplugged and completely cool before cleaning. Wipe the plates and

exterior with a soft, damp cloth. Do not use abrasive cleaners or immerse the appliance in water.

- **Storage:** Store the straightener in a dry, safe place, away from moisture and extreme temperatures. Use the lock mechanism to keep the plates closed for compact storage.
- **Cord Care:** Do not wrap the power cord around the appliance, as this can damage the cord. Store the cord loosely.

7. TROUBLESHOOTING

If you encounter any issues with your Lenoxx MY Rose Hair Straightener, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Straightener does not turn on.	Not plugged in correctly; power outlet issue; damaged cord.	Ensure the plug is fully inserted. Test the outlet with another appliance. If the cord is damaged, do not use and contact customer support.
Straightener is not heating up.	Not turned on; internal malfunction.	Press the On/Off button. If the pilot light does not illuminate, there may be an internal issue. Unplug and contact customer support.
Hair is not straightening effectively.	Hair is too wet; sections are too large; plates are dirty.	Ensure hair is completely dry. Work with smaller sections of hair. Clean the plates as per maintenance instructions.

8. SPECIFICATIONS






Feature	Detail
Model	PPA765
Brand	Lenoxx
Manufacturer	LENOXX
Color	Rosé
Material	Tourmaline
Plate Type	Ceramic Tourmaline
Power Source	Electric
Voltage	Bivolt (Automatic Dual Voltage)
Max Temperature	Up to 250°C
Dimensions (L x W x H)	3 x 31 x 4.5 cm (Product)
Weight	370 g
Included Components	01 Straightener
Hair Type Compatibility	All Hair Types


9. WARRANTY AND SUPPORT

Specific warranty details and direct support contact information are not provided in this manual. For warranty claims, technical support, or service inquiries, please refer to the product packaging or contact the retailer where the product was purchased. You may also visit the official Lenoxx website for further assistance.

© 2024 Lenoxx. All rights reserved.

Related Documents - PPA765

	<p>Lenoxx PDVD1500 15.4" Swivel Portable DVD Player Instruction Manual</p> <p>Comprehensive instruction manual for the Lenoxx PDVD1500 15.4" Swivel Portable DVD Player, covering features, safety precautions, installation, playback, remote control functions, and troubleshooting.</p>
	<p>Lenoxx PFF330 Smart Pet Food Feeder User Manual</p> <p>Comprehensive user manual for the Lenoxx PFF330 Smart Pet Food Feeder, detailing setup, operation via the Smart Life app, safety warnings, and troubleshooting.</p>
	<p>Magivaac RV4500 Robot Vacuum & Mop User Manual</p> <p>User manual for the Magivaac RV4500 Laser 360 Robot Vacuum & Mop with auto disposal station, covering setup, operation, maintenance, and troubleshooting.</p>
	<p>Lenoxx Hacienda Laptop Desk LD90 Installation Instructions</p> <p>Step-by-step installation guide for the Lenoxx Hacienda Laptop Desk LD90, including a list of parts and assembly diagrams.</p>
	<p>Lenoxx ES40 Smart E-Scooter User Manual</p> <p>Comprehensive user manual for the Lenoxx ES40 Smart E-Scooter, covering operation, safety guidelines, maintenance, and troubleshooting. Learn how to use the smartphone app and understand the product's features.</p>

<div data-bbox="124 100 295 347"><p><i>Ready, Set, Go!</i></p><p>ICE CUBE MAKER</p><p>10 KILOGRAMS OF ICE IN 24 HOURS</p><p>Model no. ICM18 Power no. 1000W</p><p>INSTRUCTION MANUAL</p><p>Please read and retain instructions for future reference. This appliance is intended for household use only.</p><p>1</p></div>	<div data-bbox="339 152 914 185"><p>Lenoxx ICM18 Ice Cube Maker Instruction Manual</p></div> <div data-bbox="339 194 1461 306"><p>Comprehensive instruction manual for the Lenoxx ICM18 Ice Cube Maker, detailing setup, operation, cleaning, troubleshooting, and specifications. Learn how to make up to 10kg of ice in 24 hours with this household appliance.</p></div>
--	---