

[manuals.plus](#) /

- › [Tivoli Audio](#) /
- › [Tivoli Audio Model One Digital Gen 2 Smart Radio User Manual](#)

Tivoli Audio M1D2BLK

Tivoli Audio Model One Digital Gen 2 Smart Radio User Manual

Model: M1D2BLK

INTRODUCTION

The Tivoli Audio Model One Digital Generation 2 is a versatile smart radio designed to deliver high-quality audio through various sources. It integrates modern streaming technologies like AirPlay 2 and Chromecast via Wi-Fi, alongside traditional Bluetooth, DAB+, and FM radio capabilities. This manual will guide you through the setup, operation, and maintenance of your device to ensure optimal performance and enjoyment.



Image: The Tivoli Audio Model One Digital Gen 2 Smart Radio positioned on a side table in a modern living room, demonstrating its compact design and aesthetic integration.

SETUP

1. Unpacking and Component Check

Carefully remove all components from the packaging. Ensure the following items are present:

- (1) Model One Digital Generation 2 Unit
- (1) Antenna
- (1) Remote Control (with battery)
- (1) Power Supply
- Quick Start Guide

2. Power Connection

Connect the power supply to the DC input on the back of the Model One Digital. Plug the power supply into a suitable wall outlet.

3. Antenna Connection

Attach the included antenna to the FM antenna input on the rear of the unit. Adjust the antenna for optimal reception.

4. Initial Power-On and Network Setup

Press the power button to turn on the unit. Follow the on-screen prompts to connect the device to your Wi-Fi

network. This is essential for using AirPlay 2, Chromecast, and other internet-based streaming features.



Image: A side view of the Tivoli Audio Model One Digital Gen 2 Smart Radio, showcasing its compact form factor and wood finish.

OPERATING INSTRUCTIONS

1. Basic Controls

The main dial on the front of the unit controls playback, pausing, track skipping, and station changes. Rotate the dial to navigate menus and press to select.



Image: A close-up of the Model One Digital Gen 2's display, showing Wi-Fi status, time, and current track information, with the control dial prominently featured.

2. Switching Audio Sources

Use the mode button or the remote control to cycle through available audio sources: Wi-Fi (AirPlay 2, Chromecast), Bluetooth, DAB+, and FM radio.

3. Wi-Fi Streaming (AirPlay 2 & Chromecast)

Once connected to Wi-Fi, you can stream audio directly from compatible apps on your smartphone or tablet using AirPlay 2 (for Apple devices) or Chromecast (for Android and other compatible devices). Select the Model One

Digital as your output device within the app.

4. Bluetooth Pairing

1. Switch the Model One Digital to Bluetooth mode.
2. On your mobile device, go to Bluetooth settings and search for available devices.
3. Select "Tivoli Audio M1D2" (or similar) from the list to pair.
4. Once paired, you can stream audio from your device to the radio.

5. FM Radio Tuning

In FM mode, use the main dial to tune to desired radio stations. The display will show the current frequency. For DAB+ radio, the process is similar, allowing you to browse available digital stations.



Image: The Tivoli Audio Model One Digital Gen 2 Smart Radio placed on a kitchen counter, illustrating its suitability for various home environments.

MAINTENANCE

Cleaning

To clean the unit, use a soft, dry cloth. Avoid abrasive cleaners, waxes, or solvents as they may damage the finish. Do not spray liquids directly onto the unit.

Software Updates

Periodically check for software updates through the device's settings menu or the companion app (if available). Keeping the software updated ensures optimal performance and access to new features.

TROUBLESHOOTING

- **No Power:** Ensure the power cord is securely connected to both the unit and the wall outlet. Verify the outlet is functional.
- **No Sound:** Check the volume level on the unit and your source device. Ensure the correct audio source is selected. For Wi-Fi streaming, confirm the device is selected as the output.
- **Wi-Fi Connection Issues:** Ensure your Wi-Fi network is active and the password is correct. Try restarting your router and the Model One Digital.
- **Bluetooth Pairing Failure:** Make sure the Model One Digital is in Bluetooth pairing mode. Ensure your source device's Bluetooth is enabled and within range. Try unpairing and re-pairing the device.
- **Poor Radio Reception:** Adjust the position of the FM antenna. If possible, try moving the unit to a location with better signal.

If you encounter persistent issues not covered here, please refer to the official Tivoli Audio support website or contact customer service.

SPECIFICATIONS

Feature	Detail
Model Number	M1D2BLK
Connectivity Technology	AUX, Bluetooth, Wi-Fi
Special Features	Bluetooth, Wi-Fi, Built-in Microphone
Tuner Technology	FM (DAB+ also supported)
Power Source	Corded Electric
Speaker Type	Active
Compatible Devices	Smartphones
Interface	Bluetooth 5
Item Weight	3.4 pounds (approx. 1.54 kg)
Included Components	(1) Model One Digital Gen 2, (1) Antenna, (1) Remote (with battery), (1) Power Supply, Quick Start Guide

WARRANTY AND SUPPORT

This product typically comes with a manufacturer's warranty. For specific warranty details and duration, please refer to the documentation included with your purchase or visit the official Tivoli Audio website.

A 30-day operational guarantee may be provided by sellers for used items. For new products, standard manufacturer warranty terms apply.

For technical support, product registration, or further assistance, please visit the Tivoli Audio support portal or contact their customer service department directly. Keep your purchase receipt and product serial number handy when seeking support.

© 2024 Tivoli Audio. All rights reserved. Information in this manual is subject to change without notice.