Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Nokia TA-1274

Nokia 2.4 Smartphone User Manual

Brand: Nokia | Model: TA-1274

Introduction

The Nokia 2.4 is an unlocked smartphone designed for reliable performance and an immersive user experience. It features a long-lasting 4500mAh AI-assisted Adaptive Battery, providing up to 2 days of usage on a single charge. Capture stunning photos, even in low light, with its AI imaging capabilities, including a dedicated Night Mode. The device offers convenient and secure unlocking options with both fingerprint and face recognition.
Enjoy your content on the impressive 6.5-inch HD+ 20:9 screen. The Nokia 2.4 is built to stay current, being ready for Android 11 and beyond, ensuring you receive two years of Android upgrades and three years of monthly security updates.



Front view of the Nokia 2.4 Smartphone, showcasing its large display.

What's in the Box

- Nokia 2.4 Android Smartphone
- Charger
- Micro USB Cable
- Quick start guide

Initial Setup

Inserting SIM and Memory Cards

The Nokia 2.4 uses a nano SIM card. Locate the SIM card tray on the side of the device. Use the provided SIM ejector tool to open the tray. Carefully place your nano SIM card(s) and an optional microSD card (for expanded storage) into their respective slots. Ensure the tray is reinserted correctly and securely.

Charging the Device

Before first use, fully charge your Nokia 2.4. Connect the provided Micro USB cable to the charging port at the bottom of the phone and the other end to the charger. Plug the charger into a power outlet. The battery icon on the screen will indicate charging status. A full charge typically takes approximately 3 hours.

Powering On and Initial Configuration

Press and hold the Power button (located on the right side) until the Nokia logo appears. Follow the on-screen prompts to select your language, connect to a Wi-Fi network, sign in with your Google account, and set up security features like fingerprint or face unlock. This process will guide you through the essential steps to get your phone ready for use.

Operating Your Nokia 2.4

Display and Navigation

The Nokia 2.4 features a large 6.5-inch HD+ display with a 20:9 aspect ratio, ideal for viewing content. Navigate the Android 10 operating system (upgradable to Android 11 and beyond) using intuitive gestures or traditional navigation buttons. Swipe down from the top of the screen to access quick settings and notifications.

Camera Features

The rear camera system includes a 13MP main sensor and a 2MP depth sensor, allowing for detailed photos and portrait mode effects. The front-facing camera is 5MP, perfect for selfies and video calls. Utilize Night Mode for enhanced low-light photography and record videos in up to 1080p resolution.



Back view of the Nokia 2.4 Smartphone, highlighting the dual camera setup and fingerprint sensor.

Security Features

Unlock your device quickly and securely using the rear-mounted fingerprint sensor or the facial recognition feature. These biometric options provide convenient access while keeping your data protected.

Battery Life

The 4500mAh AI-assisted Adaptive Battery intelligently optimizes power usage, providing up to two days of battery life depending on usage patterns. This ensures your phone keeps up with your daily activities without constant recharging.

Physical Buttons and Ports

The device features a dedicated Google Assistant button for quick access to voice commands. A 3.5mm audio jack is available for headphones, and the Micro USB port is used for charging and data transfer.



Side view of the Nokia 2.4 Smartphone, showing the power and volume buttons.

Product Overview Video

An official video showcasing the key features and design of the Nokia 2.4 Smartphone.

Maintenance and Care

Software Updates

Keep your device updated to ensure optimal performance and security. The Nokia 2.4 is guaranteed to receive two

years of Android operating system upgrades and three years of monthly security updates. You will be notified when updates are available.

Battery Care

To prolong battery life, avoid exposing your phone to extreme temperatures. It is recommended to charge the battery when it drops below 20% and avoid leaving it fully charged for extended periods.

General Device Care

Clean your phone regularly with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials. Protect your screen with a screen protector and use a protective case to prevent physical damage from drops or impacts.

Troubleshooting Common Issues

Network Connectivity

The Nokia 2.4 is compatible with GSM mobile networks only and will not work with Verizon. If you experience issues connecting to your mobile network or receiving calls, ensure your nano SIM card is correctly inserted. If problems persist, contact your mobile carrier for assistance.

Software Freezing or Power Issues

If your product experiences software issues such as freezing or power problems, first connect your device to a charger. Then, perform a software reset by pressing and holding the Power button and Volume Up button simultaneously for about 10-15 seconds until the device restarts. If the issue continues, consult the full user guide or contact customer support.

Technical Specifications

Feature	Specification
Product Dimensions	7 x 6 x 1 inches
Item Weight	6.9 ounces
Item Model Number	TA-1274
OS	Android 10.0 (Upgradeable)
RAM	2 GB
Memory Storage Capacity	32 GB
Wireless Communication Technologies	Cellular
Connectivity Technologies	Bluetooth, Wi-Fi
Special Features	Touchscreen, Text/Messaging, Camera, Fingerprint Sensor, Smartphone
Scanner Resolution	1600 x 720
Other Camera Features	Rear, Front
Audio Jack	3.5 mm

Feature	Specification
Form Factor	Smartphone
Color	Charcoal
Battery Power Rating	4500 mAh
Phone Talk Time	48 Hours
Manufacturer	HMD Global
Date First Available	September 22, 2020
Standing Screen Display Size	6.5 Inches
Charging Time	3 Hours
Wireless Carrier	Unlocked
Cellular Technology	GSM, LTE, WCDMA, HSPA, HSDPA

Warranty and Support

For detailed warranty information and comprehensive support, please refer to the official user guide provided by Nokia. You can access the PDF version of the user guide here.
For further assistance or specific inquiries not covered in this manual, please visit the Nokia support website or contact their customer service directly.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08JRF9L15

More documents and user manuals: **https://manuals.plus/**