

YORTOT 56

YORTOT 16-Inch LED Wall Clock (Model 56) Instruction Manual

Brand: YORTOT

1. INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, and maintenance of your YORTOT 16-Inch LED Wall Clock, Model 56. This digital clock features a large, easy-to-read display showing time, date, day of the week, and indoor temperature. It includes adjustable brightness, a customizable 7-color night light, and convenient remote control operation. Designed for versatility, it can be wall-mounted or placed on a tabletop.



Figure 1: YORTOT 16-Inch LED Wall Clock (Model 56)

2. PACKAGE CONTENTS

Please verify that all items listed below are included in your package:

- 1 x YORTOT 16-Inch LED Wall Clock (Model 56)
- 1 x Remote Control
- 1 x Power Adapter
- 1 x Mounting Template
- 2 x Screws
- 2 x Drywall Anchors

Note: 2 x AAA batteries for the memory backup function are not included and must be purchased separately.



Figure 2: Package Contents and Rear View of Clock

3. PRODUCT FEATURES

- **Large LED Display:** A 16-inch display provides clear visibility of time, date, day of the week, and indoor temperature from a distance.
- **Adjustable Brightness:** Features 4 levels of display brightness, including a full dark option, controllable via the remote.
- **7-Color Night Light:** An integrated night light offers 7 color options and 4 brightness levels, allowing for ambient customization.
- **Versatile Mounting:** Equipped with three keyholes for wall mounting and a foldable stand for tabletop placement.
- **Remote Control Operation:** All clock functions and settings are easily accessible through the included remote control.
- **Memory Function:** While primarily outlet-powered, a 2x AAA battery backup (not included) preserves time and settings during power interruptions. The display will be blank during battery backup.
- **Automatic Daylight Saving Time (DST):** Supports automatic adjustment for Daylight Saving Time.
- **12/24 Hour Format:** Easily switch between 12-hour and 24-hour time display formats.
- **Temperature Display:** Shows indoor temperature in either Celsius or Fahrenheit.

4. SETUP

4.1 Power Connection

1. Connect the provided power adapter to the DC input port on the back of the clock.
2. Plug the power adapter into a standard electrical outlet. The clock display will illuminate.

4.2 Battery Backup Installation

The clock requires 2 x AAA batteries (not included) for its memory backup function. These batteries ensure that your time and settings are retained in the event of a power outage. The display will not remain lit when operating on battery backup alone.

1. Locate the battery compartment on the back of the clock.
2. Open the battery compartment cover.
3. Insert 2 new AAA batteries, observing the correct polarity (+ and -) as indicated inside the compartment.
4. Close the battery compartment cover securely.

5. OPERATING INSTRUCTIONS

All primary functions of the YORTOT LED Wall Clock are controlled using the included remote control. Ensure there is a clear line of sight between the remote and the clock for optimal operation.




Figure 3: Remote Control Operation

5.1 Remote Control Button Functions

Button	Function
SET	Enter setting mode for time, date, etc. Press repeatedly to cycle through settings.
+ / -	Adjust values (e.g., hour, minute, year, month, day) in setting mode.
12/24H	Toggle between 12-hour and 24-hour time display formats.
C/F	Switch the temperature display between Celsius (°C) and Fahrenheit (°F).
LED Dimmer	Adjust the brightness of the main time display (4 levels, including off).
Night Light ON/OFF	Turn the 7-color night light on or off.
Night Light Dimmer	Adjust the brightness of the night light (4 levels).
CLR	Change the color of the night light (cycles through 7 colors).
DST	Activate or deactivate Daylight Saving Time (DST) automatic adjustment.

5.2 Setting Time and Date

1. Press the **SET** button on the remote control. The hour digits will begin to flash.
2. Use the **+** or **-** buttons to adjust the hour.
3. Press **SET** again to move to the minute digits. Use **+** or **-** to adjust the minutes.
4. Continue pressing **SET** to cycle through year, month, and day settings, adjusting each with the **+** or **-** buttons.
5. After setting the day, press **SET** one last time to exit setting mode.

5.3 Adjusting Display Brightness

The main LED display has 4 brightness levels. Press the **LED Dimmer** button on the remote to cycle through the brightness settings: Full, Medium, Low, and Dark (display off).

2 Set-up Modes

Remote control & the button of the clock



Figure 4: 4-Level Dimmer Function

5.4 Controlling the Night Light

The clock features a 7-color night light with adjustable brightness.

- Press the **Night Light ON/OFF** button to turn the night light on or off.
- While the night light is on, press the **CLR** button to cycle through the 7 available colors.
- Use the **Night Light Dimmer** button to adjust the brightness of the night light (4 levels).



Figure 5: 7-Color Night Light Options

6. MOUNTING OPTIONS

Your YORTOT LED Wall Clock offers flexible placement options:

6.1 Wall Mounting

The clock is designed for easy wall mounting using the three keyholes on its back.

1. Choose a suitable location on a wall.
2. Use the provided mounting template to mark the positions for the screws.
3. Drill pilot holes and insert the drywall anchors if necessary.
4. Insert the screws, leaving a small portion protruding to hang the clock.
5. Align the keyholes on the back of the clock with the screws and carefully hang the clock.

6.2 Tabletop Placement

For tabletop use, simply extend the foldable stand located on the back of the clock. Place the clock on a flat, stable surface.

7. MAINTENANCE

- **Cleaning:** To clean the clock, gently wipe the display and casing with a soft, dry, lint-free cloth. Avoid using abrasive cleaners, solvents, or spray cleaners directly on the clock.
- **Battery Replacement:** Replace the 2 x AAA backup batteries annually or when you notice settings are not retained during power outages.
- **Power Cord:** Ensure the power cord is not kinked, pinched, or placed under heavy objects to prevent damage.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Clock display is blank.	No power from the outlet; power outage.	Ensure the power adapter is securely plugged into a working outlet. The display requires AC power to operate. Battery backup only retains settings, not the display.
Remote control is not working.	Remote battery is dead; obstruction between remote and clock; remote out of range.	Replace the remote control battery. Ensure there is a clear line of sight to the clock's sensor. Move closer to the clock.
Time/Date is incorrect.	Not set correctly; power interruption without backup batteries.	Follow the "Setting Time and Date" instructions in Section 5.2. Ensure AAA backup batteries are installed and functional.
Temperature reading seems inaccurate.	Clock placed near a heat source or in direct sunlight.	Relocate the clock to an area with stable ambient temperature, away from direct heat or cold sources. Allow time for the sensor to stabilize.

9. SPECIFICATIONS

Feature	Detail
Brand	YORTOT
Model Number	56
Product Dimensions	16"W x 6.5"H (16 inches wide x 6.5 inches high)
Display Type	Digital LED
Power Source	Corded Electric (with 2x AAA battery backup for memory)

Feature	Detail
Special Features	Remote Control, 7 Colors Night Light, Large Display, Adjustable Brightness, Indoor Temperature, Date, Auto DST, 12/24 Hour Format
Mounting Type	Wall Mount, Tabletop Stand
Frame Material	Plastic
Item Weight	2.33 pounds
ASIN	B08JSQNM8Q
UPC	783907301387



10. WARRANTY AND SUPPORT




For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official YORTOT website. Keep your purchase receipt as proof of purchase for any warranty claims.



© 2025 YORTOT. All rights reserved.

Related Documents - 56

<div><p>YORTOT CLOCK-AC191 User Manual New Version</p><p>Questions? Warranty? Contact Customer Support at: customer@kerwellai.com</p><p>SAVE THIS MANUAL FOR FUTURE REFERENCE</p></div>	<p>YORTOT CLOCK-AC191 User Manual</p> <p>User manual for the YORTOT CLOCK-AC191 digital clock, detailing its features, specifications, setup, and operation, including time setting, brightness control, and night light functions.</p>
<div><p>YORTOT Clock AC198-Black User Manual</p><p>12 Months Warranty If you have any questions, please feel free to contact us by email at: customer@kerwellai.com</p></div>	<p>YORTOT AC198-Black Clock and Wireless Charger User Manual</p> <p>Comprehensive user manual for the YORTOT AC198-Black, a 5-in-1 wireless charging station with an alarm clock, night light, and device charging capabilities. Learn setup, features, and troubleshooting.</p>

<div data-bbox="162 114 264 152">YORTOT W08 User Manual</div> <div data-bbox="156 165 271 259"></div> <div data-bbox="143 277 284 304"><p>If faulty product is found when setting up, Please email our friendly after-sale team at: customer@yortot.com</p></div>	<div data-bbox="341 136 1366 165">YORTOT W08 White Noise Machine User Manual - Features, Setup, and Troubleshooting</div> <div data-bbox="341 176 1468 286"><p>Comprehensive user manual for the YORTOT W08 White Noise Machine. Learn about its features, how to set it up, adjust sounds, volume, night light, and understand power specifications and FCC requirements.</p></div>
<div data-bbox="137 378 165 394"></div> <div data-bbox="143 598 284 609"></div>	<div data-bbox="341 463 1139 492">YORTOT AC198 Wireless Charging Station RF Exposure Test Report</div> <div data-bbox="341 504 1477 613"><p>Test report for the YORTOT AC198 Wireless Charging Station, detailing RF exposure compliance with FCC CFR Title 47 Part 1.1310. Includes test summary, general information, instrument list, and measurement data.</p></div>