

FLEXISPOT EN2

FLEXISPOT EN2 Electric Height Adjustable Standing Desk Instruction Manual

Model: EN2 (40x24" Maple Top + White Frame)

Brand: FLEXISPOT

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your FLEXISPOT EN2 Electric Height Adjustable Standing Desk. Designed for a productive work environment, this desk features a whole-piece desktop, a motorized height-adjustable system, and integrated power solutions.

Key Features:

- **Removable Desktop Power Outlet:** Equipped with 3 power outlets and 2 USB charging ports, clip-on design for flexible placement. Includes cable management.
- **Ample Whole-Piece Desktop:** A single, eco-friendly desktop provides generous space for your computer setup and accessories.
- **4 Memory Buttons:** Program and recall your preferred sitting and standing heights with the 6-button digital controller (28.1" to 45.7"). Quiet motor operation (less than 50 dB).
- **Durable Construction:** Premium wood planks and a sturdy industrial-grade steel frame support up to 154 pounds.

IMPORTANT SAFETY INFORMATION

To ensure safe operation and prevent damage, please adhere to the following guidelines:

- Do not exceed the maximum weight limit of 154 pounds (70 kg).
- Ensure proper assembly using an electric drill as specified in the instructions.
- Follow all assembly and operating instructions carefully to avoid injury or damage to the product.
- Keep children and pets away from the desk during operation.
- Avoid placing liquids directly on the control panel or near electrical components.

SETUP AND ASSEMBLY

The FLEXISPOT EN2 desk is designed for straightforward assembly. An electric drill (not included) may be required for certain steps. Please follow the detailed instructions provided in the packaging for optimal setup.

Assembly Overview:

- Unpack all components and verify against the parts list.
- Assemble the desk frame, ensuring all screws are securely tightened.
- Attach the desktop to the assembled frame.
- Connect all electrical cables and organize them using the provided cable management system.
- Install the removable desktop power outlet as desired.



Figure 1: Fully assembled FLEXISPOT EN2 Standing Desk, showcasing the maple top and white frame.


DIMENSIONS



Table

Size: 40"-24"

Suggest Putting One 27" Monitor




Leg

Adjustable Height
28.1"-45.7"

Can Support Your Daily Work

Power Strip

Up To 1.7" Desk Edge



Cable Manager

Size: 15.75"-7.09"-4.72"




Figure 2: Diagram illustrating the dimensions of the 40x24" desk and its key components, including the adjustable legs, power strip, and cable manager.

Assembly Videos:

Your browser does not support the video tag.

Video 1: Official Standing Desk Assembly Video by ErGear Direct. This video provides a visual guide to the assembly process for the desk frame and desktop.

Your browser does not support the video tag.

Video 2: FLEXISPOT Standing Desk Installation Guide. This official video demonstrates the step-by-step installation process for the FLEXISPOT standing desk.

OPERATING INSTRUCTIONS

Your FLEXISPOT EN2 desk features an intuitive 6-button digital controller for easy height adjustment and memory presets.

Controller Functions:

- **Up/Down Arrows:** Manually adjust the desk height.
- **Memory Presets (1, 2, 3, 4):** Program and recall your preferred sitting and standing heights.
- **Motorized Adjustment:** Smoothly adjusts height from 28.1" to 45.7" with low noise operation.



Figure 3: Close-up of the multifunctional digital controller, highlighting the LED display, up/down arrows, and height setting buttons.



Figure 4: Image detailing the convenient keypad with 4 preset heights, up/down controls, and a digital LED display.

Operation Video:

Your browser does not support the video tag.

Video 3: Flexispot Classic Height Adjustable Standing Desk Series. This video demonstrates the smooth and quiet operation of the desk's height adjustment mechanism.

MAINTENANCE

To ensure the longevity and optimal performance of your FLEXISPOT EN2 standing desk, regular maintenance is recommended:

- Regularly check all screws and bolts to ensure they are tight. Retighten if necessary.
- Clean the desktop surface with a soft, damp cloth and mild detergent. Avoid abrasive cleaners.
- Keep the motor and electrical components free from dust and debris.
- Inspect cables periodically for any signs of wear or damage. Replace if needed.

TROUBLESHOOTING

If you encounter any issues with your FLEXISPOT EN2 standing desk, refer to the following common troubleshooting tips:

- **Desk not moving:** Check all power connections. Ensure the power outlet is functional.
- **Uneven height:** Perform a reset procedure (refer to the full manual for specific steps, usually involves holding down certain buttons).
- **Motor noise:** A slight hum is normal during operation. Excessive or unusual noise may indicate an issue; contact support.
- **Anti-collision activated:** If the desk stops unexpectedly, check for obstructions beneath or above the desktop. Remove any obstacles and try again.

For more complex issues or if troubleshooting steps do not resolve the problem, please contact FLEXISPOT customer support.

PRODUCT SPECIFICATIONS







Brand	FLEXISPOT
Model	EN2
Product Dimensions	24"D x 40"W x 28"H
Color	Maple Top + White Frame
Style	Industrial
Base Material	Alloy Steel
Top Material Type	Maple Wood
Special Feature	Electric Height Adjustment
Minimum Height	28.1 Inches
Maximum Height	45.7 Inches
Maximum Weight Recommendation	154 Pounds (70 kg)
Included Components	6-button digital controller, integrated desk clamp power strip, cable management system
Required Assembly	Yes

WARRANTY AND SUPPORT

FLEXISPOT provides comprehensive warranty coverage for your peace of mind:

- **5-Year Warranty:** Covers frames, motors, and other mechanical devices.
- **2-Year Warranty:** Covers controllers, switches, and electronics.

For warranty claims, technical assistance, or any product-related inquiries, please contact FLEXISPOT customer support directly. You can find contact information on the official FLEXISPOT website or through your purchase platform.

	<p>FlexiSpot EH1-EU Electric Standing Desk Frame User Manual</p> <p>Comprehensive user manual for the FlexiSpot EH1-EU electric standing desk frame, detailing specifications, assembly instructions, wiring, operation, and troubleshooting for optimal use.</p>
	<p>FlexiSpot E7QB Standing Desk User Manual</p> <p>Comprehensive user manual for the FlexiSpot E7QB standing desk, covering components, installation, usage, troubleshooting, and warranty information.</p>
	<p>FlexiSpot EC1 Electric Height Adjustable Standing Desk Assembly Guide</p> <p>This assembly guide provides step-by-step instructions for setting up the FlexiSpot EC1 electric height-adjustable standing desk. It includes specifications, parts list, assembly procedures, keypad operation, troubleshooting tips, and warranty information.</p>
	<p>FlexiSpot E7-Flow Electric Height Adjustable Desk Frame - User Manual</p> <p>Comprehensive user manual for the FlexiSpot E7-Flow electric height-adjustable desk frame, covering specifications, power consumption, installation, operation, and troubleshooting.</p>
	<p>FlexiSpot E7B/E7W/E7S-Plus Height Adjustable Desk User Manual & Installation Guide</p> <p>Detailed user manual for FlexiSpot E7B-Plus, E7W-Plus, and E7S-Plus height adjustable desks. Includes technical specifications, step-by-step installation instructions, handset operation, troubleshooting guide, and warranty information.</p>
	<p>FlexiSpot E5B/E5S Installation Guide: Step-by-Step Assembly Instructions</p> <p>Comprehensive installation guide for the FlexiSpot E5B and E5S height-adjustable desk frames. Learn how to assemble your new desk with clear steps, specifications, and troubleshooting tips.</p>