

## Cata V 6000X (02002399)

# Cata V 6000X Wall-Mounted Decorative Extractor Hood User Manual

Model: V 6000X (02002399), 60 cm Inox

## 1. INTRODUCTION

This manual provides essential information for the safe and efficient installation, operation, and maintenance of your Cata V 6000X wall-mounted decorative extractor hood. Please read these instructions carefully before using the appliance and retain them for future reference.

### Key Features

- **Efficient Extraction:** Effectively removes steam, grease, and odors from your kitchen. Energy efficiency class B.
- **Optimal Suction:** 60 cm wide with a powerful extraction rate of 310 m³/h, suitable for medium-sized kitchens.
- **Adjustable Power:** Three selectable speed levels to suit various cooking needs.
- **LED Lighting:** High-efficiency LED lights provide clear illumination of your cooking area.
- **Convenient Controls:** Mechanical push-button control panel for easy operation.
- **Quiet Operation:** Low operating noise level, less than 66 dB at maximum power.
- **Easy Maintenance:** Features dishwasher-safe metallic grease filters.



Figure 1: Cata V 6000X 60cm Inox Wall-Mounted Extractor Hood, front view.

## 2. SAFETY INFORMATION

For your safety and to prevent damage to the appliance or injury to persons, please observe the following precautions:

- Read all instructions before installation and use.
- Installation must be carried out by a qualified technician in accordance with local regulations.
- Ensure the power supply voltage matches the rating on the appliance label.
- Do not operate the hood without the grease filters properly installed.
- Never leave frying food unattended, as overheated oil can ignite.
- Do not flambé under the extractor hood.
- Ensure adequate ventilation in the room when the hood is used simultaneously with gas or other fuel-burning appliances.
- Regularly clean the grease filters to prevent fire hazards.
- Disconnect the appliance from the main power supply before any cleaning or maintenance.

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

### 3. SETUP AND INSTALLATION

#### Components Included

- Cata V 6000X Extractor Hood unit
- Dishwasher-safe metallic grease filters
- Installation hardware (screws, wall plugs - quantity may vary)
- Instruction Manual

#### Dimensions and Placement

The Cata V 6000X is a wall-mounted canopy hood designed for ducted ventilation. Ensure sufficient space above your cooking hob for proper installation and optimal performance.




Figure 2: Technical dimensions of the Cata V 6000X extractor hood. Minimum height 640mm, maximum 990mm. Width 595mm (for 60cm model).



Figure 3: The hood is 60 cm wide, suitable for standard kitchen hobs.

## Installation Steps (Summary)

1. Mark the drilling points on the wall according to the hood's dimensions and mounting brackets.
2. Drill holes and insert wall plugs.
3. Secure the mounting bracket(s) to the wall.
4. Mount the hood body onto the brackets.
5. Connect the exhaust ducting to the hood's outlet and route it to the exterior. Ensure proper sealing.
6. Connect the electrical supply, ensuring it is grounded and meets local electrical codes.
7. Install the decorative chimney sections (if applicable).
8. Insert the metallic grease filters.

For detailed installation instructions, refer to the diagrams and specific steps provided in the full printed manual.

## 4. OPERATING INSTRUCTIONS

---

### Control Panel

The hood is operated via a mechanical push-button control panel located on the front of the unit.



Figure 4: Mechanical push-button controls for fan speed and lighting.

### Fan Speed Selection

Press the corresponding buttons to select one of the three available extraction speeds:

- **Speed 1:** For light cooking, simmering, or minimal steam.
- **Speed 2:** For normal cooking with moderate steam and odors.
- **Speed 3:** For intensive cooking, frying, or when strong odors are present.

Press the 'Off' button (usually indicated by '0' or a power symbol) to turn off the fan.

### Lighting Control

The hood is equipped with energy-efficient LED lighting to illuminate your cooking surface.



Figure 5: The integrated LED lighting strip provides bright illumination.

Press the light button (usually indicated by a light bulb symbol) to turn the LED lights on or off independently of the fan speed.

## 5. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your extractor hood. Always disconnect the power supply before performing any maintenance.

### Cleaning the Grease Filters

The metallic grease filters capture airborne grease particles. They should be cleaned regularly (approximately every 2-4 weeks, depending on usage) to maintain extraction efficiency and prevent fire hazards.




Figure 6: Example of a metallic grease filter. These filters are dishwasher-safe.

1. To remove, locate the release latch on each filter and pull it down.
2. Carefully slide the filter out.
3. Clean the filters by hand using hot water and a mild detergent, or place them in a dishwasher on a low-temperature cycle.
4. Ensure filters are completely dry before re-installing.
5. Re-insert the filters by aligning them with the slots and pushing until the latch clicks into place.

### Exterior Cleaning

Clean the exterior surfaces of the hood with a soft cloth and a non-abrasive cleaner suitable for stainless steel. Avoid harsh chemicals or abrasive pads that could scratch the surface.

### Bulb Maintenance and Recycling

The hood uses LED lighting, which typically has a long lifespan. If a bulb needs replacement, consult a qualified technician. For recycling information regarding this and other bulb types, please refer to local recycling guidelines. More information on how to clean and dispose of broken or damaged bulbs can be found through your local waste

management services.

## 6. TROUBLESHOOTING

Before contacting customer service, please check the following common issues and solutions:

| Problem               | Possible Cause                                                                      | Solution                                                                                                      |
|-----------------------|-------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------|
| Hood does not start   | No power supply; Power cord disconnected; Fuse blown.                               | Check power connection; Check household fuse box; Ensure appliance is plugged in.                             |
| Low extraction power  | Grease filters are dirty; Ducting is blocked or too long/narrow; Fan speed too low. | Clean grease filters; Check ducting for obstructions; Select a higher fan speed.                              |
| Excessive noise       | Loose components; Improper installation; Obstruction in fan.                        | Check for loose parts; Ensure correct installation; Inspect fan for foreign objects (disconnect power first). |
| Lights not working    | Bulb failure; Electrical connection issue.                                          | If LED, contact service for replacement; Check power supply.                                                  |
| Condensation dripping | Insufficient ventilation; Cold air entering ducting; High humidity.                 | Ensure proper room ventilation; Check ducting for insulation; Increase fan speed.                             |

## 7. TECHNICAL SPECIFICATIONS

The following table outlines the technical specifications for the Cata V 6000X extractor hood:

| Specification                  | Value                  |
|--------------------------------|------------------------|
| Model Number                   | 02002399               |
| Brand                          | Cata                   |
| Product Dimensions (L x W x H) | 64.5 x 29.5 x 52.5 cm  |
| Product Weight                 | 10.5 Kilograms         |
| Color                          | Stainless Steel (Inox) |
| Material                       | ABS, Metal             |
| Mounting Type                  | Wall-mounted           |
| Ventilation Type               | Ducted                 |
| Control Type                   | Push-button            |
| Airflow Capacity (Max)         | 310 m³/hour            |
| Noise Level (Max)              | 66 dB                  |
| Energy Efficiency Class        | B                      |
| Annual Energy Consumption      | 43.6 kWh/year          |

| Specification               | Value                  |
|-----------------------------|------------------------|
| Light Source Type           | LED                    |
| Wattage (Motor Max)         | 120 W                  |
| Filter Type                 | Mesh (Dishwasher-safe) |
| Voltage                     | 220 Volts              |
| Compliance                  | TUV certified          |
| EU Spare Parts Availability | 2 Years                |




Figure 7: EU Energy Label for Cata V-6000 X, indicating Energy Efficiency Class B.



Figure 8: Product Fiche providing detailed technical data. For more information, visit the [EPREL database](#) (EPREL-registrationnumber: 1934937).

## 8. WARRANTY AND SUPPORT

### Warranty Information

This product is covered by a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions. EU regulations ensure spare parts availability for a minimum of 2 years from the product's market introduction.

## Customer Support

For technical assistance, spare parts, or warranty claims, please contact Cata customer service:

- **Manufacturer:** CATA ELECTRODOMÉSTICOS, S.L.
- **Websites:** [www.cnagroup.com](http://www.cnagroup.com), [www.cata.es](http://www.cata.es)
- **Email:** [cna@cnagroup.es](mailto:cna@cnagroup.es)
- **Telephone:** +34938594100
- **Address:** Anabel Segura 11, 28108 Alcobendas, Spain

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

#### Name

Anonymous

#### Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

#### Question

Example: How do I reset this device or fix this error?

#### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question