hOmeLabs HME030286N

hOmeLabs 18 Inch Built-In Dishwasher User Manual

Model: HME030286N

1. Important Safety Information

Read all instructions before using the dishwasher to reduce the risk of fire, electric shock, or injury. Keep this manual for future reference.

- This appliance is intended for household use only.
- Do not operate the dishwasher unless all enclosure panels are properly in place.
- Do not tamper with controls.
- Use only detergents and rinse agents recommended for automatic dishwashers.
- Keep children away from detergent and rinse aid.
- Do not allow children to play in or on the appliance.
- Always disconnect the appliance from the power supply before cleaning or maintenance.
- Ensure the dishwasher is properly grounded.

2. Product Overview

The hOmeLabs 18 Inch Built-In Dishwasher (Model HME030286N) is designed for efficient and quiet dishwashing in compact spaces. It features a stainless steel front door, 6 wash cycles, and a capacity for 9 place settings.



The hOmeLabs 18 Inch Built-In Dishwasher features a durable stainless steel front door, designed to integrate seamlessly into your kitchen cabinetry.

Key Features:

- **Compact Design:** 18-inch width, ideal for smaller kitchens or apartments.
- **Capacity:** Accommodates up to 9 place settings.
- **Quiet Operation:** Operates at a low noise level of 49 dBA.
- **Energy Efficient:** Energy Star certified, with an estimated annual energy consumption of 255 kWh.
- **Wash Cycles:** Includes Heavy, Normal, Delicate, Light, Express (50 min), and Rinse.
- **User-Friendly Controls:** Easy-to-use control panel with an LED display showing time remaining.
- **Adjustable Upper Basket:** Provides flexibility for loading various dish sizes.
- **Rinse Aid Dispenser:** Ensures spot-free drying.
- **Safety Features:** Includes flood protection and delayed start options (1-24 hours).



Useful Features

- Delayed Start (1–24)
- Flood Protection
- Multi-Zone Washing

The dishwasher operates quietly at 49 dB and includes useful features such as Delayed Start (1-24 hours), Flood Protection, and Multi-Zone Washing for enhanced convenience and safety.



The interior is designed to hold 9 place settings and features an adjustable upper basket to accommodate taller items.

3. Setup and Installation

This dishwasher is designed for built-in installation. Professional installation is recommended to ensure proper function and safety. Installation tools are not included.

Dimensions for Installation:

- **Height:** 31.4 inches
- **Width:** 24.4 inches
- **Length (Depth):** 17.7 inches
- **Front Panel Height:** 5.7 inches
- **Side Width:** 3.7 inches
- **Door Size:** 25.9 x 17.7 inches



Refer to this diagram for precise measurements required for built-in installation. The unit comes with a pre-installed outlet hose.

Water Connection:

It is crucial to connect the dishwasher to the**COLD water inlet**. Connecting to a hot water inlet, especially if the water temperature exceeds 150°F, can trigger an E4 error and cause the dishwasher to shut off. The dishwasher has an internal heating element to heat water to the appropriate temperature for washing.

4. Operating Instructions

The hOmeLabs dishwasher features an intuitive control panel for easy operation.

Control Panel:



The control panel features an LED display and concealed buttons for selecting wash programs, setting delays, and initiating/pausing cycles.

Wash Programs:

Select the appropriate wash program based on the soil level of your dishes:

- **Heavy:** For heavily soiled dishes and pots.
- **Normal:** Standard program for daily soiled dishes.
- **Delicate:** For lightly soiled or fragile items.
- **Light:** For lightly soiled dishes.
- **Express - 50 min:** A quick wash cycle for lightly soiled dishes that do not require drying.
- **Rinse:** For rinsing dishes that will be washed later.

Loading the Dishwasher:

Proper loading ensures optimal cleaning performance. Utilize the adjustable upper basket for taller items and arrange

dishes to allow water to reach all surfaces.

Rinse Aid Dispenser:

The rinse aid dispenser helps to dry dishes without streaks or water spots. Only use rinse aids specifically designed for automatic dishwashers. An indicator light on the control panel will signal when to refill the dispenser.

5. Maintenance and Care

Regular maintenance helps prolong the life and efficiency of your dishwasher.

Cleaning the Exterior:

Wipe the exterior surfaces, including the stainless steel door, with a soft, damp cloth. Avoid abrasive cleaners or scouring pads that can scratch the finish.

Cleaning the Interior:

Periodically clean the interior of the dishwasher, including the spray arms and filters, to remove food particles and mineral buildup. Consult the full manual for detailed instructions on filter removal and cleaning.

Rinse Aid Refill:

Check the rinse aid indicator regularly and refill the dispenser as needed to ensure effective drying.

6. Troubleshooting

If you encounter issues with your dishwasher, refer to the following common solutions:

- **E4 Error:** This error code typically indicates a temperature sensor issue. Ensure the dishwasher is connected to the **cold water inlet**. If the incoming water temperature exceeds approximately 150°F, the dishwasher may display an E4 error and shut off.
- **Dishes Not Drying:** This model may have a limited drying cycle. For completely dry dishes, manual towel drying may be necessary after the cycle completes. Ensure the rinse aid dispenser is filled.
- **Dishwasher Not Starting:** Check if the door is fully closed and latched. Ensure the power cord is securely plugged in and the circuit breaker has not tripped.
- **Poor Cleaning Results:** Verify that dishes are loaded correctly, not blocking spray arms. Ensure filters are clean and not clogged. Use the appropriate wash cycle for the soil level.

For other error codes or persistent issues, please contact customer support.


7. Specifications

Specification	Detail
Model Name	HME030286N
Brand	hOmeLabs
Finish Type	Stainless Steel
Form Factor	Built-In

Product Dimensions (D x W x H)	17.7 x 24.4 x 31.4 inches
Item Weight	73 pounds
Voltage	120 Volts
Wattage	1000 watts
Cycle Options	6 (Heavy, Normal, Delicate, Light, Express, Rinse)
Display Type	LED
Capacity	9 Place Settings, 5.9 Gallons
Noise Level	49 Decibels
Certification	Energy Star
Annual Energy Consumption	255 Kilowatt Hours Per Year
Special Feature	Time Remaining Indicator
UPC	810049720179



The dishwasher is Energy Star rated, consuming only 255 kWh per year, contributing to water and electricity savings.



The EnergyGuide label provides estimated yearly energy costs and consumption for the hOmeLabs HME030286N dishwasher.

8. Warranty and Support

Warranty Information:

This hOmeLabs dishwasher typically comes with a**1-year limited warranty** from the date of purchase. Please retain your proof of purchase for warranty claims. The warranty covers defects in materials and workmanship under normal use.

Customer Support:

For technical assistance, warranty service, or to order replacement parts, please contact hOmeLabs customer support. Refer to the contact information provided in your product packaging or visit the official hOmeLabs website.
When contacting support, please have your model number (HME030286N) and purchase date readily available.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question