

[Manuals.plus](#) /

› [THERMOS](#) /

› THERMOS Stainless King 40 Ounce Beverage Bottle User Manual

THERMOS SK2010

THERMOS Stainless King Vacuum-Insulated Beverage Bottle

Model: SK2010 | Brand: THERMOS

INTRODUCTION

The THERMOS Stainless King 40oz Beverage Bottle is designed for maximum temperature retention, keeping your beverages hot or cold for up to 24 hours. Its durable 18/8 stainless steel construction makes it ideal for various outdoor activities and daily use. This bottle features a convenient twist and pour stopper and a serving cup that doubles as a lid, ensuring easy and mess-free pouring.

The exterior remains cool to the touch with hot liquids and sweat-proof with cold, enhancing user comfort and safety. This product is a reliable companion for maintaining beverage temperature on long treks, road trips, or family outings.

SETUP

Initial Cleaning

Before first use, wash all parts with warm water and mild dish soap. Rinse thoroughly. For best results, it is recommended to wash the bottle on the top rack of a dishwasher. Ensure all components are completely dry before assembly.

Pre-heating or Pre-cooling

To maximize temperature retention, pre-heat the bottle with hot water for hot beverages or pre-cool with cold water for cold beverages for approximately 5-10 minutes before filling. Empty the pre-heating/pre-cooling water before adding your desired beverage.





Image: The THERMOS Stainless King 40 Ounce Beverage Bottle in Midnight Blue, showcasing its sleek design and integrated handle.

OPERATING INSTRUCTIONS

Filling the Bottle

Unscrew the serving cup and then the twist and pour stopper. Fill the bottle with your desired hot or cold beverage, leaving approximately one inch of space from the top to allow for the stopper and cup. Securely re-attach the stopper and then the serving cup.

Using the Twist and Pour Stopper

To pour, simply twist the stopper counter-clockwise a few turns. This allows liquid to flow out without fully removing the stopper, minimizing heat loss or gain. Once pouring is complete, twist the stopper clockwise until it is securely tightened to prevent leaks and maintain temperature.



Image: A close-up view demonstrating the twist and pour stopper, with coffee being poured into the serving cup.

Using the Serving Cup

The insulated serving cup is integrated into the lid of the bottle. Simply unscrew it from the top to use it for drinking. After

use, screw it back onto the bottle to seal and protect the stopper.



**VACUUM
INSULATED**



**BUILT-IN
CARRY HANDLE**

Image: Two THERMOS bottles illustrating key features: vacuum insulation for temperature retention and a built-in carry handle for portability.



LEAK-PROOF (WHEN CLOSED)

Image: A detailed view of the bottle's cap, emphasizing its leak-proof design when properly closed.

MAINTENANCE AND CARE

Cleaning

The THERMOS Stainless King Beverage Bottle is dishwasher safe, with the top rack recommended for optimal cleaning. For hand washing, use warm water and mild dish soap. A bottle brush may be helpful for thorough cleaning of the interior. Ensure all parts, including the stopper and serving cup, are cleaned and dried completely to prevent odor or residue buildup.

Do not use abrasive cleaners or scrubbers as they may damage the finish. Do not use bleach or cleaners containing chlorine.



**DISHWASHER
SAFE**



BPA-FREE



**HIGH QUALITY
STAINLESS STEEL**

Image: The THERMOS bottle accompanied by icons highlighting its dishwasher-safe nature, BPA-free materials, and construction from high-quality 18/8 stainless steel.

Storage

When not in use, store the bottle with the stopper and serving cup removed to allow for air circulation and prevent odors.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Beverage not staying hot/cold	Bottle not pre-heated/pre-cooled; Stopper not sealed properly; Damaged vacuum insulation.	Ensure proper pre-heating/pre-cooling. Check stopper for secure seal and any damage. If insulation is damaged, product may need replacement.
Leaking	Stopper not tightened; Gasket missing or damaged; Overfilling.	Ensure stopper is twisted clockwise until fully tight. Check for presence and condition of stopper gasket. Do not overfill the bottle.
Unpleasant odor	Improper cleaning; Stored with lid on.	Clean thoroughly with warm soapy water and rinse well. Store with stopper and cup removed to allow air circulation.

SPECIFICATIONS

- **Brand:** THERMOS
- **Model Name:** Stainless King 40 Ounce Beverage Bottle
- **Capacity:** 40 Ounces (approx. 1.18 Liters)
- **Color:** Midnight Blue
- **Material:** 18/8 Stainless Steel
- **Product Dimensions:** 4.3"W x 12.3"H
- **Item Weight:** 16 ounces (1 pound)
- **Special Feature:** Dishwasher Safe (Top Rack Recommended)
- **Cap Type:** Screw Cap with Twist and Pour Stopper
- **Included Components:** Beverage Bottle, Serving Cup
- **Country of Origin:** China
- **UPC:** 041205747550



KEEPS HOT
24 HOURS



KEEPS COLD
24 HOURS



12.3 in



4.3 in

Image: The THERMOS bottle displaying its dimensions (4.3 inches width, 12.3 inches height) and highlighting its ability to keep contents hot or cold for 24 hours.

OFFICIAL PRODUCT VIDEO

Your browser does not support the video tag.

Video: A short preview video demonstrating the THERMOS 40 oz Stainless King Vacuum-Insulated Bottle. This video highlights key features and usage in a concise format.

WARRANTY AND SUPPORT

THERMOS products are built with over a century of expertise, ensuring quality and durability. For specific warranty information or support inquiries, please refer to the official THERMOS website or contact their customer service directly. Keep your purchase receipt as proof of purchase for any warranty claims. For more information, visit the official [THERMOS Store on Amazon](#).

© 2025 THERMOS. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question