

[Manuals.plus](#) /

› [Donerton](#) /

› Donerton Wireless Earbuds I09 User Manual

Donerton I09

Donerton Wireless Earbuds User Manual

BRAND: DONERTON

Model: I09

INTRODUCTION

Thank you for choosing Donerton Wireless Earbuds Model I09. These earbuds are designed to provide a high-quality audio experience with advanced features such as Bluetooth 5.3 connectivity, IP7 waterproofing, and an extended playtime of up to 140 hours with the charging case. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your device.

WHAT'S IN THE BOX

- Donerton Wireless Earbuds (Left and Right)
- Charging Case
- Charging Cable
- Earplugs (various sizes)
- Instruction Manual

PRODUCT OVERVIEW

The Donerton I09 Wireless Earbuds feature a sleek design with an LED digital display on the charging case to show battery levels. They are equipped with 6mm composite diaphragm and HiFi drivers for premium stereo sound.



Image: Donerton Wireless Earbuds I09 with their charging case, showing the earbuds charging inside.



Image: Close-up of Donerton I09 earbuds in their charging case, illustrating the charging process with a visual lightning effect.




Image: Diagram showing the internal components of a Donerton earbud, highlighting the 6mm composite diaphragm and HiFi driver.

SETUP

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. Place the earbuds into the charging case. Connect the charging cable to the USB-C port on the case and a power source. The LED digital display on the case will show the charging status and battery percentage.

- A single charge provides 5-6 hours of playtime for the earbuds.
- The charging case extends total playtime up to 140 hours, providing up to 23 full charges for the earbuds.
- The charging case takes approximately 2 hours to fully charge.
- A quick 10-minute charge can provide up to 1 hour of playtime.




Image: Donerton earbuds and charging case on a wooden surface with vinyl records, illustrating the 140-hour extended playtime capability.

2. Pairing with Your Device

1. Open the charging case. The earbuds will automatically power on and enter pairing mode.
2. On your Bluetooth-enabled device (smartphone, tablet, laptop), go to the Bluetooth settings.
3. Search for "I09" in the list of available devices and select it to connect.

4. Once connected, you will hear a confirmation tone, and the earbuds will be ready for use.



Image: Donerton earbuds and charging case positioned next to a laptop and smartphone, demonstrating seamless connectivity.

3. Fitting the Earbuds

Select the earplug size that provides the most comfortable and secure fit for your ears. A proper fit ensures optimal sound quality and noise isolation.



Image: A man wearing a Donerton earbud, with an inset showing different ear tip sizes and how they fit into the ear canal.

OPERATING INSTRUCTIONS

Smart Touch Control

The Donerton I09 earbuds feature intuitive touch controls for various functions. The controls are located on the outer surface of each earbud.

Smart Touch Control

Features with touch control sensors, all the functions with just a gentle touch on the earbuds.
x1 : Press once x2: Press twice x3: press three times 1S: Press and hold for 1 second




Image: Detailed diagram illustrating the touch control functions for both the left (L) and right (R) Donerton earbuds.

Touch Control Functions

Action	Left Earbud (L)	Right Earbud (R)
Play/Pause Music	Press once (x1)	Press once (x1)
Previous Song	Press twice (x2)	N/A
Next Song	N/A	Press twice (x2)
Volume Down	Press three times (x3)	N/A
Volume Up	N/A	Press three times (x3)
Answer Call	Press once (x1)	Press once (x1)
Hang Up Call	Press and hold for 1 second (1S)	Press and hold for 1 second (1S)
Reject Call	Press and hold for 1 second (1S)	Press and hold for 1 second (1S)
Activate Voice Assistant	Press three times (x3)	Press three times (x3)

Power On/Off

- **Power On:** Open the charging case, and the earbuds will automatically power on. Alternatively, press and hold the touch area on both earbuds for a few seconds until you hear a power-on prompt.
- **Power Off:** Place the earbuds back into the charging case and close the lid. They will automatically power off and begin charging. Alternatively, press and hold the touch area on both earbuds for a few seconds until you hear a power-off prompt.

Using the Charging Case as a Power Bank

The Donerton I09 charging case can also function as a power bank to charge other devices. It features a USB-A "OUT" port for this purpose.

- Locate the USB-A port labeled "OUT" on the charging case.
- Connect your device's charging cable to this port.
- The charging case will begin to supply power to your device.

Note: The charging case has a capacity of 2600mAh. While it can charge your phone, its primary function is to charge the earbuds.

MAINTENANCE

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. For earwax or debris, use a small, soft brush or cotton swab. Do not use abrasive cleaners or solvents.
- **Water Resistance:** The earbuds are IP7 waterproof, meaning they can withstand heavy rains or sweat during exercise. However, they are not designed for swimming or prolonged submersion. Ensure the earbuds are dry before placing them back into the charging case to prevent damage.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged. Store in a cool, dry place away from extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the earbuds and charging case frequently. Charge them regularly, even if not in constant use.



Image: Donerton earbuds partially submerged in water, demonstrating their IP7 waterproof rating.

TROUBLESHOOTING

Common Issues and Solutions

Problem	Possible Cause	Solution
Earbuds not pairing/connecting	Bluetooth off, earbuds not in pairing mode, interference, previously paired device.	Ensure Bluetooth is on. Place earbuds in case, close, then open to re-enter pairing mode. Forget "I09" on your device and re-pair. Move closer to your device.
Only one earbud working	Low battery, earbud not properly seated in case, pairing issue.	Ensure both earbuds are charged. Place both earbuds in the case, close the lid, then open it again. Try resetting the earbuds (refer to manual for specific reset steps if available, otherwise re-pair).
Low volume or poor sound quality	Improper fit, earwax buildup, device volume too low.	Adjust earbud position and try different ear tip sizes. Clean earbuds. Increase volume on both your device and the earbuds.
Charging case not charging	Faulty cable/adaptor, dirty charging port.	Try a different charging cable and power adapter. Clean the charging port on the case.

Problem	Possible Cause	Solution
Touch controls not responding	Earbuds not powered on, dirty touch sensor.	Ensure earbuds are powered on. Clean the touch sensor area on the earbuds.

SPECIFICATIONS

Feature	Detail
Model Name	I09
Connectivity Technology	Wireless
Wireless Communication Technology	Bluetooth, True Wireless
Bluetooth Version	5.3
Bluetooth Range	10 Meters
Audio Driver Size	6 Millimeters
Frequency Range	20 Hz - 20 kHz
Battery Life (Earbuds)	5-6 hours (single charge)
Total Playtime (with Charging Case)	Up to 140 Hours
Charging Case Battery Charging Time	2 Hours
Water Resistance Level	IP7 Waterproof
Control Type	Touch Control, Media Control
Material	Polycarbonate (PC), Acrylonitrile Butadiene Styrene (ABS)
Item Weight	0.12 Kilograms (Earbuds + Case)
Product Dimensions	3.94 x 3.15 x 1.57 inches
Special Features	Waterproof, Touch Control, One Step Pairing, LED Power Display, Microphone, 140 hour playtime



Image: Visual representation of the Bluetooth 5.3 chip, highlighting the advanced connectivity technology.

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official Donerton website. Keep your proof of purchase for any warranty claims.

For further assistance, you may contact Donerton customer service through their official channels.

© 2023 Donerton. All rights reserved.
This manual is subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

Open the live page

<https://manuals.plus/asin/B08JYZ38P7>

More documents and user manuals: <https://manuals.plus/>