

## Braun 70-N1000

# Braun Series 7 70-N1000 Electric Shaver

## User Manual

### 1. INTRODUCTION

Thank you for choosing the Braun Series 7 70-N1000 Electric Shaver. This device is engineered for a smooth and efficient shave, featuring 360° Flex adaptation and AutoSense technology. Designed for both wet and dry use, it offers convenience and performance. Please read this manual thoroughly before first use to ensure safe operation and optimal results. Keep this manual for future reference.

### 2. IMPORTANT SAFETY INSTRUCTIONS

When using an electrical appliance, basic precautions should always be followed, including the following:

- **Water and Electricity:** This appliance is suitable for use in a bath or shower. For safety reasons, the shaver can only be operated cordless. Do not immerse the charging stand or power cord in water.
- **Power Supply:** Use only the special cord set provided with your appliance. Do not use with a damaged foil or cord.
- **Children:** This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning the use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children unless they are older than 8 and supervised.
- **Temperature:** Do not expose the shaver to temperatures above 50°C (122°F) for extended periods.
- **Damage:** If the appliance is damaged, do not use it. Contact an authorized Braun service center for repair.

### 3. PRODUCT OVERVIEW AND COMPONENTS

Your Braun Series 7 70-N1000 electric shaver comes with several components designed for a complete shaving experience.

#### 3.1 Box Contents

- Braun Series 7 Electric Shaver (Model 70-N1000)
- Travel Case
- Smart Plug (for automatic 100-240 voltage adjustment)
- Cleaning Brush

### 3.2 Shaver Components

Familiarize yourself with the main parts of your shaver:

- **Flexible Shaving Head:** Adapts 360° to facial contours.
- **Foil and Cutter Block:** The shaving elements that capture and cut hair.
- **Power Button:** To turn the shaver on and off.
- **LED Display:** Shows battery status, cleaning indicator, and travel lock.
- **Precision Trimmer:** (If included as an attachment or integrated) For shaping sideburns and mustaches.





*Figure 1: Front view of the Braun Series 7 electric shaver. This image displays the Braun Series 7 electric shaver from the front. Visible features include the flexible shaving head with foil and cutter block, the power button, and LED indicators for battery status and cleaning.*



Figure 2: Braun Series 7 shaver with its retail box and travel case. This image shows the complete package: the Braun Series 7 electric shaver, its original retail packaging, and a protective travel case. These are the primary components included with your purchase.

## 4. SETUP

### 4.1 Initial Charging

1. Before using your shaver for the first time, connect it to the power outlet using the provided Smart Plug.
2. Charge the shaver for approximately 1 hour to ensure a full charge. The LED display will indicate charging progress and a full battery. A full charge provides up to 50 minutes of cordless shaving.
3. A 5-minute quick charge is sufficient for one shave.

### 4.2 Attaching/Detaching Attachments (if applicable)

If your model includes a precision trimmer attachment or other EasyClick accessories, ensure the shaver is turned off before attaching or detaching them. Simply click the attachment onto the shaver head until it locks into place. To remove, pull the attachment off.

## 5. OPERATING INSTRUCTIONS

---

### 5.1 Powering On/Off

- To turn the shaver on, press the power button once.
- To turn the shaver off, press the power button again.

### 5.2 Shaving Tips

For best results, follow these guidelines:

- **Dry Shaving:** Ensure your face is dry before shaving. Hold the shaver at a right angle (90°) to your skin and shave against the direction of hair growth.
- **Wet Shaving:** You can use the shaver with foam or gel for a refreshing shave. Apply shaving foam/gel to your face, then shave as usual. Rinse the shaver head under running water during and after use.
- **360° Flex Adaptation:** The shaver head automatically adapts to your facial contours, ensuring maximum skin contact for a close shave. Apply gentle pressure.
- **AutoSense Technology:** The shaver reads your beard density and adjusts its power accordingly, removing more hairs in every stroke, even with dense beards.



Figure 3: Illustration of the 360° Flex head movement. This image illustrates the 360 Flex adaptation feature of the Braun Series 7 shaver, showing how the head pivots to maintain contact with facial contours. The travel case is also visible.

### 5.3 Using the Precision Trimmer

If your shaver has an integrated precision trimmer, slide it upwards to activate. Use it for precise shaping of sideburns, mustaches, or for pre-trimming longer hairs before shaving.

## 6. CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and hygiene for your shaver.

### 6.1 Daily Cleaning (Rinsing)

1. After each shave, turn off the shaver.
2. Hold the shaver head under warm running water until all residue is rinsed away. You can use liquid soap for a more thorough clean.
3. Shake off excess water and let the shaver head air dry.

### 6.2 Thorough Cleaning (Brush)

1. Ensure the shaver is turned off and disconnected from the power supply.
2. Remove the foil and cutter block.
3. Use the provided cleaning brush to remove any loose hairs from the shaver head and the inner housing. Do not use the brush on the foil as it may damage it.
4. Reattach the foil and cutter block.

### 6.3 SmartCare Center (if applicable)

If your Series 7 model includes a SmartCare Center, refer to its separate instruction manual for detailed cleaning and charging procedures. The SmartCare Center automatically cleans, lubricates, dries, and charges your shaver at the touch of a button.

### 6.4 Replacing Shaver Parts

To maintain 100% shaving performance, replace the foil and cutter block every 18 months, or when worn. Replacement parts are available from Braun retailers or service centers. The shaver's LED display may indicate when replacement is due.

## 7. TROUBLESHOOTING

If you encounter issues with your Braun Series 7 shaver, consult the following table:

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is empty; Travel lock is activated.	Charge the shaver; Deactivate travel lock by pressing the power button for 3 seconds.
Shaver does not charge.	Smart Plug not properly connected; Faulty power outlet.	Ensure the Smart Plug is securely connected to both the shaver and the power outlet; Try a different power outlet.
Poor shaving performance.	Foil and cutter block are worn; Shaver head is dirty; Incorrect shaving technique.	Replace foil and cutter block; Clean the shaver head thoroughly; Ensure shaving against hair growth with gentle pressure.
Skin irritation after shaving.	Skin not accustomed to electric shaving; Excessive pressure; Worn shaving parts.	Allow a few weeks for skin to adapt; Use gentle pressure; Replace foil and cutter block if worn.

## 8. TECHNICAL SPECIFICATIONS

- **Brand:** Braun
- **Model Name:** Series 7

- **Model Number:** 70-N1000S
- **Power Source:** Battery Powered (Li-Ion)
- **Battery Life:** Up to 50 minutes of shaving
- **Quick Charge:** 5 minutes for one shave
- **Waterproof:** 100% waterproof for Wet & Dry use
- **Special Features:** 360° Flex Adaptation, AutoSense Technology
- **Item Weight:** 353 Grams
- **Blade Material:** Stainless Steel
- **Head Type:** Foil (Testine a lamina)

## 9. WARRANTY AND CUSTOMER SUPPORT

---

Your Braun Series 7 shaver comes with a manufacturer's warranty. For detailed warranty information, terms, and conditions, please refer to the warranty card included in your product packaging or visit the official Braun website. For customer support, service, or to purchase replacement parts, please contact Braun customer service or visit their official website:

**Braun Official Website:** [www.braun.com](http://www.braun.com)

Please have your model number (70-N1000S) and proof of purchase ready when contacting support.