NutriChef NCONYX

NutriChef NCONYX 11-Piece Non-Stick Cookware Set Instruction Manual

1. Product Overview

This manual provides essential information for the safe and effective use of your NutriChef NCONYX 11-Piece Non-Stick Cookware Set. Please read these instructions thoroughly before first use and retain them for future reference.



Image 1.1: The NutriChef NCONYX 11-Piece Non-Stick Cookware Set, featuring various pots, pans, and kitchen tools with golden handles.

1.1 Package Contents

Your NutriChef NCONYX 11-Piece Cookware Set includes the following items:

- 1 x Saucepan Pot with Lid (2 qt)
- 1 x Saucepan Pot with Lid (3 qt)
- 1 x Casserole with Lid (6 qt)
- 1 x Open Fry Pan (8-inch)
- 1 x Open Fry Pan (10-inch)
- 1 x Soup Ladle
- 1 x Slotted Spoon
- 1 x Spatula



Image 1.2: Visual representation of the included items: 5 QT Casserole with Lid, 3 QT Saute Pan Pot with Lid, 2 QT Saute Pan Pot with Lid, 8-inch Open Fry Pan, 10-inch Open Fry Pan, and Kitchen Tools (Soup Ladle, Slotted Spoon, Spatula).

2. Safety Instructions

Adhere to the following safety guidelines to prevent injury or damage to your cookware:

- **Heat Safety:** Do not leave cookware unattended on a hot stovetop. Overheating can damage the non-stick coating and potentially cause fire.
- **Handle Safety:** While handles are designed to be cool-touch, always use oven mitts or pot holders when handling hot cookware, especially after prolonged cooking or oven use.
- **Oven Use:** Cookware is oven safe up to 400°F (232°C). Glass lids are not designed for oven use at this temperature; remove lids before placing pots or pans in the oven.
- **Utensil Use:** Use only heat-resistant nylon, silicone, or wooden utensils to protect the non-stick surface. Metal utensils can scratch and damage the coating.
- **Children:** Keep hot cookware out of reach of children.
- **Lid Vents:** Tempered glass lids include vent holes to allow steam to escape, reducing pressure buildup.

3. Before First Use

Before using your new NutriChef cookware set for the first time:

1. Remove all packaging materials, labels, and tags.
2. Wash each piece of cookware and all utensils thoroughly with warm, soapy water.
3. Rinse well and dry completely with a soft cloth.

4. Setup and Assembly

Your NutriChef cookware set requires minimal assembly. Simply place the appropriate tempered glass lid onto the corresponding pot or casserole. The included kitchen tools are ready for immediate use.

5. Operating Instructions

5.1 Heat Source Compatibility

This cookware set is designed for use on a variety of cooktops:

- Gas Cooktops
- Electric Cooktops
- Ceramic Cooktops
- Induction Cooktops



Image 5.1: A NutriChef fry pan in use on an induction compatible cooktop, demonstrating its versatility.

5.2 Cooking Guidelines

Follow these guidelines for optimal cooking performance and to maintain your cookware:

1. **Preheating:** Preheat your pan on low to medium heat for a few minutes before adding food. This allows the aluminum encapsulated base to heat quickly and spread heat evenly.
2. **Heat Settings:** Use low to medium heat for most cooking tasks. High heat is generally not necessary with non-stick cookware and can damage the coating over time.
3. **Oil/Butter:** While the non-stick coating allows for cooking with minimal oil, a small amount of cooking oil or butter can enhance flavor and further protect the surface.
4. **Oven Temperature:** The cookware (excluding glass lids) is oven safe up to 400°F (232°C).
5. **Non-Stick Surface:** The interior features a durable non-stick coating for easy food release and cleaning. This coating is PFOA, PFAS, Cadmium, Lead, PTFE, PFOS, APEO, Nickel, and Bisphenol-A (BPA) free.



Image 5.2: Close-up of the long-lasting, easy-to-clean non-stick interior surface, highlighting its PFOA, Cadmium, and Lead-free composition.

5.3 Cookware Construction

The cookware features a multi-layered construction for durability and even heating:

- **18/8 Stainless Steel Interior:** Provides a durable cooking surface.
- **Pure Aluminum Layer:** Ensures rapid and even heat distribution.
- **Hard Anodized Layer:** Adds strength and corrosion resistance.
- **Heat Resistance Coating:** Protects the exterior.



Image 5.3: Cross-section diagram illustrating the multi-layered construction of the cookware, including 18/8 Stainless Steel Interior, Pure Aluminum Layer, Hard Anodized Layer, and Heat Resistance Coating.

The tri-ply bond construction, incorporating 18/10 stainless steel, aluminum, and magnetic stainless steel, ensures durability, ease of maintenance, and even heat distribution. The magnetic stainless steel exterior makes the cookware induction compatible.




Image 5.4: Explanation of the benefits of stainless steel cookware, detailing the tri-ply bond construction for durability, even heating, and induction compatibility.

6. Care and Maintenance

6.1 Cleaning

1. **Dishwasher Safe:** All cookware pieces (pots, pans, and lids) are dishwasher safe. However, the included kitchen utensils are not dishwasher safe and should be hand washed.
2. **Hand Washing:** For best results and to prolong the life of the non-stick coating, hand washing with warm, soapy water and a soft sponge is recommended.
3. **Stubborn Food:** If food is stuck, soak the cookware in warm, soapy water for a few minutes before cleaning. Avoid using abrasive cleaners, steel wool, or harsh scouring pads, as these can damage the non-stick surface and exterior finish.
4. **Drying:** Dry all pieces thoroughly after washing to prevent water spots.

6.2 Storage

- Store cookware in a dry place.
- To prevent scratching the non-stick surface when stacking, place a soft cloth or paper towel between pans.

7. Troubleshooting

This section addresses common issues you might encounter with your cookware.

Issue	Possible Cause	Solution
Food sticks to the non-stick surface.	Excessive heat; insufficient oil; damaged coating.	Use low to medium heat. Ensure a small amount of oil or butter is used. Avoid metal utensils.
Stains appear on the interior or exterior.	Food residue not fully removed; mineral deposits from water; high heat discoloration.	Clean thoroughly after each use. For stubborn stains, soak in warm soapy water. A non-abrasive cleaner designed for stainless steel may help for exterior stains.
Handles become hot during cooking.	Prolonged cooking at high temperatures; oven use.	Always use oven mitts or pot holders, especially during extended cooking or when removing from the oven.

8. Technical Specifications

Feature	Specification
Model Number	NCONYX
Max Temperature (Cookware)	400°F (232°C)
Construction Material	Stainless Steel, Engineered Nylon, Tempered Glass
Interior Coating	Fine Brush Interior with Non-Stick Coating
Exterior Coating	Non-Stick Coating for Easy Clean
Base	Aluminum Encapsulated Base for Quick & Even Heating
Handle Material	Cast Stainless Steel
Cooktop Compatibility	Gas, Electric, Ceramic, Induction
Dishwasher Safe	Yes (Cookware only, not utensils)
PFOA/PFAS Free	Yes
Item Weight	19.56 lbs (8.87 kg)
UPC	842893126630

9. Warranty and Support

For warranty information or technical support regarding your NutriChef NCONYX 11-Piece Non-Stick Cookware Set, please refer to the documentation provided at the time of purchase or contact NutriChef customer service directly. Contact details can typically be found on the manufacturer's official website or product packaging.