Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DigiPower DP-VLR3

DigiPower DP-VLR3 Live Streaming Light Kit User Manual

Model: DP-VLR3

Introduction

The DigiPower DP-VLR3 Live Streaming Light Kit is designed to enhance your video recording and live streaming experiences. This kit provides adjustable lighting and a secure holder for your smartphone, allowing for optimal positioning and illumination. Please read this manual thoroughly to ensure proper setup and operation of your device.

Safety Information

- Do not expose the device to water or excessive moisture.
- Avoid disassembling or modifying the product, as this may void the warranty and pose safety risks.
- Keep out of reach of children.
- Use only with compatible USB power sources.
- Ensure the clip is securely fastened to a stable surface before attaching your smartphone.

Package Contents

Verify that all items are present in your package:

- 1 x DigiPower DP-VLR3 Live Streaming Light Kit (Integrated Ring Light, Phone Holder, and Clip)
- 1 x Bluetooth Remote Control



Figure 1: Overview of the DigiPower DP-VLR3 Live Streaming Light Kit, showing the ring light, phone holder, flexible arms, clip, and wired control.

Setup

1. **Attach the Clip:** Securely fasten the heavy-duty clip to a stable surface such as a desk, table, or shelf. Ensure the surface thickness is within the clip's capacity for a firm grip.
2. **Insert Smartphone:** Gently extend the spring-loaded phone holder and insert your smartphone. The holder is designed to accommodate most smartphone sizes.
3. **Connect Power:** Plug the USB connector into any standard USB wall charger (not included) or a powered USB port. The wired remote control will illuminate to indicate power.
4. **Position Flexible Arms:** Adjust the gooseneck arms for both the ring light and the phone holder to achieve your desired angle and height. The arms are flexible for 360-degree positioning.



Figure 2: Detail of the robust clip and adjustable phone holder, demonstrating how a smartphone is secured.

Operating Instructions

The DP-VLR3 kit features an inline wired remote for controlling the ring light and a separate Bluetooth remote for camera activation.

Ring Light Control (Wired Remote)

- **Power On/Off:** Press the power button on the wired remote to turn the ring light on or off.
- **Adjust Brightness:** Use the '+' and '-' buttons to increase or decrease the light intensity. There are multiple brightness levels available.
- **Change Color Temperature:** Press the cycle button (often indicated by a sun or color icon) to switch between the three available color temperatures: cool white, warm yellow, and mixed light.

Bluetooth Remote Control

1. **Pairing:** Turn on the Bluetooth remote. On your smartphone, go to Bluetooth settings and select the remote (usually named 'AB Shutter3' or similar) to pair.
2. **Capture Photos/Videos:** Once paired, open your smartphone's camera app. Press the corresponding button on the remote (iOS or Android) to remotely trigger photo capture or start/stop video recording.



Figure 3: The Live Streaming Light Kit shown with its wired light control and the separate Bluetooth remote for camera operation.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the surfaces of the ring light and phone holder. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, store the kit in a cool, dry place away from direct sunlight and extreme temperatures.
- **Cable Care:** Avoid sharp bends or kinks in the USB cable to prevent damage.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Ring light does not turn on.	No power or faulty connection.	Ensure USB is securely plugged into a working power source. Try a different USB port or adapter.
Bluetooth remote does not pair.	Remote not in pairing mode or smartphone Bluetooth off.	Ensure remote is on and in pairing mode. Turn smartphone Bluetooth off and on again. Restart both devices.
Phone holder is not stable.	Clip not securely fastened or surface is too thin/thick.	Re-secure the clip to a stable surface. Ensure the surface is within the clip's recommended thickness.

Specifications

- **Model:** DP-VLR3
- **Product Dimensions:** 2.75 x 5 x 9 inches
- **Item Weight:** 1.28 pounds
- **Connectivity Technology:** USB (for light), Bluetooth (for remote)
- **Light Settings:** 3 adjustable light temperatures, multiple brightness levels
- **Motion:** 360-degree flexible arms

Warranty and Support

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official DigiPower website. You may also visit the DigiPower Store on Amazon for additional product details and contact options.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08JZGZ487

More documents and user manuals: **https://manuals.plus/**