

xdoobo X8

XDOBO X8 Portable Bluetooth Speaker User Manual

Model: X8

1. INTRODUCTION

Thank you for choosing the XDOBO X8 Portable Bluetooth Speaker. This manual provides detailed instructions for setting up, operating, and maintaining your speaker to ensure optimal performance and longevity. Please read this manual thoroughly before using the product.

The XDOBO X8 is a versatile 60W outdoor speaker designed to deliver 360° HD surround sound with rich stereo bass. It features Bluetooth 5.0 connectivity, a 6600mAh battery for extended playtime, and is waterproof for outdoor use.

2. SAFETY INFORMATION

- Do not expose the speaker to extreme temperatures (hot or cold).
- Keep the speaker away from direct sunlight and heat sources.
- Ensure the port cover is securely closed when using the speaker near water to maintain its waterproof rating.
- Do not attempt to disassemble, repair, or modify the speaker yourself. This will void the warranty and may cause damage or injury.
- Use only the provided charging cable and a certified power adapter.
- Avoid dropping or subjecting the speaker to strong impacts.

3. PACKAGE CONTENTS

Upon opening the package, please verify that all items listed below are included:

- XDOBO X8 Speaker x1
- User Manual x1
- Audio Line x1
- Type-C Data Line x1
- Carrying strap x1

What is in the box?



Figure 3.1: XDOBO X8 Package Contents

4. SETUP

4.1 Charging the Speaker

Before first use, fully charge the speaker. Connect the provided Type-C data cable to the speaker's charging port and the other end to a USB power adapter (not included). The charging indicator light will show the charging status.



Figure 4.1: XDOBO X8 Battery and Power Information

The speaker is equipped with a 6600mAh rechargeable battery, providing up to 15 hours of playtime at 50% volume. Full charging typically takes 3 hours.

4.2 Powering On/Off

To power on the speaker, press and hold the power button () located on the top panel until you hear an audible prompt. To power off, press and hold the power button again.

Your browser does not support the video tag.

Video 4.2: Demonstrating the power on/off and basic operation of the XDOBO X8 Bluetooth Speaker.

4.3 Bluetooth Pairing

Once powered on, the speaker will automatically enter Bluetooth pairing mode. On your device (smartphone, tablet, etc.), enable Bluetooth and search for "X8" in the list of available devices. Select "X8" to connect. A voice prompt will confirm successful pairing.

Your browser does not support the video tag.

Video 4.3: A short demonstration of connecting a device to the XDOBO X8 Bluetooth Speaker.

4.4 True Wireless Stereo (TWS) Pairing

For an enhanced stereo experience, you can pair two XDOBO X8 speakers together:

1. Ensure both X8 speakers are powered off and not connected to any Bluetooth device.
2. Power on both speakers.
3. On one of the speakers (this will become the main speaker), double-press the power button. The speaker will enter TWS pairing mode.
4. The speakers will automatically connect to each other. You will hear a "beep beep" sound from the main speaker once TWS pairing is successful.
5. Now, connect your device to the main speaker via Bluetooth. Both speakers will play audio in stereo.



Figure 4.4: TWS Interconnection Operation Steps

Your browser does not support the video tag.

5. OPERATING THE SPEAKER

5.1 Button Functions

The top panel of the XDOBO X8 speaker features several control buttons:

- **Power Button ()**: Press and hold to power on/off.
- **Mode Button (M)**: Short press to switch between Bluetooth, TF Card, and AUX modes.
- **Play/Pause Button (▶||)**: Short press to play or pause music.
- **Volume Down (-)**: Short press to decrease volume. Press and hold for previous track.
- **Volume Up (+)**: Short press to increase volume. Press and hold for next track.
- **Voice Assistant Button ()**: Short press to activate your device's voice assistant.

Voice Assistant

Short press the mic button to activate voice assistant of bluetooth device and talk through speaker. Bluetooth 5.0 connection.



Built-in high-definition call microphone that allows you to answer calls hands-free without delay.

Figure 5.1: XDOBO X8 Control Buttons

5.2 Connectivity Options

The XDOBO X8 offers multiple ways to connect your audio sources:

- **Bluetooth 5.0:** Provides a stable and fast wireless connection with a range of up to 10 meters.
- **TF Card Slot:** Insert a micro SD card (up to 16GB) directly into the speaker to play audio files.
- **3.5mm AUX Input:** Connect devices without Bluetooth using the provided audio line.
- **Type-C USB Port:** Used for charging the speaker.



Figure 5.2: XDOBO X8 Connectivity Ports

5.3 Voice Assistant

Activate your Bluetooth device's voice assistant (e.g., Siri, Google Assistant) by short pressing the microphone button (M) on the speaker. You can then speak commands through the speaker's built-in high-definition microphone.

60W Subwoofer Speaker



Figure 5.3: Voice Assistant Activation

5.4 Hands-Free Calling

When connected via Bluetooth, the built-in microphone allows you to answer incoming calls hands-free. Press the Play/Pause button (▶||) to answer or end a call.

5.5 Sound Modes

The XDOBO X8 features a Tri-bass effect for an enhanced listening experience, including Extra Bass, 3D Deep Bass, and Vocal modes. Use the Mode button (M) to cycle through these sound profiles.

6. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the speaker's surface. Do not use abrasive cleaners or solvents.
- **Waterproof Feature:** The XDOBO X8 is IPX7 waterproof, meaning it can withstand splashes and water jets. Ensure the rubber cover for the ports is tightly sealed before exposing the speaker to water. Do not submerge the speaker for extended periods.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures when not in

use. If storing for a long period, charge the battery every 3 months to prolong its lifespan.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery.	Charge the speaker fully.
Cannot pair via Bluetooth.	Speaker is not in pairing mode; device Bluetooth is off; too far from device.	Ensure speaker is in pairing mode (blinking blue light). Turn on device Bluetooth. Move speaker closer to device (within 10m). Forget "X8" on your device and try pairing again.
No sound or low volume.	Volume too low on speaker or device; incorrect mode selected.	Increase volume on both speaker and connected device. Press 'M' button to ensure correct input mode (Bluetooth, TF, AUX).
TWS pairing fails.	Speakers already connected to a device; incorrect pairing steps.	Ensure both speakers are disconnected from any Bluetooth devices. Follow TWS pairing steps precisely (Section 4.4).
Sound distortion.	Volume too high; low battery.	Decrease volume. Charge the speaker.

8. SPECIFICATIONS

Feature	Detail
Brand	xdobo
Model Name	X8 Speaker
Speaker Type	Outdoor, Surround Sound
Connectivity Technology	Bluetooth 5.0
Wireless Communication Technology	Bluetooth
Speaker Maximum Output Power	60 Watts (2*30W speakers)
Audio Output Mode	Surround, Stereo
Frequency Response	20 KHz
Battery Life	Up to 15 Hours (at 50% volume)
Battery Capacity	6600mAh Lithium Ion
Charging Time	3 Hours
Is Waterproof	True (IPX7)
Bluetooth Range	10 Meters
Control Method	Voice, Button

Feature	Detail
Compatible Devices	Laptop, Personal Computer, Tablet, Mobile Phones
Product Dimensions	10.63 x 5.91 x 4.72 inches
Item Weight	4 pounds

9. WARRANTY AND SUPPORT

The XDOBO X8 Portable Bluetooth Speaker comes with a limited warranty. For detailed warranty information, please refer to the warranty card included in your product packaging or contact XDOBO customer support.

For technical support, troubleshooting assistance, or any inquiries regarding your XDOBO product, please visit the official XDOBO website or contact their customer service team through the contact information provided in your product documentation.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How can I connect my guitar wirelessly to the XDOBO X8 speaker?

To connect a guitar to the XDOBO X8 speaker, you should be aware that the speaker itself does not have a built-in wireless guitar receiver; it primarily uses standard Bluetooth 5.0 for devices like...

[Read full answer](#)

How can I connect my guitar to the XDOBO X8 speaker wirelessly?

To play your guitar through the XDOBO X8 speaker wirelessly, you will need a separate third-party guitar wireless

transmitter/receiver system, as the speaker does not have a built-in wireless guitar input. Here are the...

[Read full answer](#)