Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

xdobo X8 II

XDOBO X8 II Bluetooth Speaker User Manual

Model: X8 II | Brand: xdobo

Introduction

This manual provides detailed instructions for the operation and maintenance of your xdobo X8 II Portable Wireless Bluetooth Speaker. Designed for outdoor use, this 60W speaker delivers 360 HD surround sound and rich stereo bass, featuring a voice assistant, TWS connectivity, and robust waterproof capabilities.

Key Features:

- **7-in-1 Multifunction:** Powerful Bluetooth speaker, DSP for stronger sound, TWS connectivity, 6600mAh battery, Aux and TF Card support, Waterproof design, and Voice assistant.
- **Extraordinary HiFi Sound Quality:** Shocking rich bass with Tri-bass effect (Extra bass, 3D Deep Bass, Vocal) and 360° all-around sound. Equipped with 30W*2 high-quality speakers.
- **Excellent Battery:** 6600mAh rechargeable battery provides up to 15 hours of playtime at 50% volume.
- **Voice Assistant:** Short press the mic button to activate your Bluetooth device's voice assistant. Built-in high-definition call microphone for hands-free calls.
- **Universal Connectivity:** Bluetooth 5.0, Type-C USB port, TF Card slot, and 3.5mm AUX input for wide compatibility.

Package Contents

Upon unboxing your xdobo X8 II speaker, please ensure all items are present:

- XDOBO X8 II Portable Wireless Bluetooth Speaker
- Carrying strap
- USB Type-C Charging Cable
- 3.5mm AUX Cable
- User Manual

Image: The xdobo X8 II Portable Wireless Bluetooth Speaker in blue, showcasing its compact and rugged design.

Setup

1. Initial Charge

Before first use, fully charge the speaker using the provided USB Type-C cable. Connect the Type-C end to the speaker's charging port and the USB-A end to a compatible power adapter (not included).

Image: Close-up view of the speaker's side panel revealing the Type-C charging port, TF card slot, and AUX port, protected by a rubber cover.

2. Power On/Off

- To power on: Press and hold the power button ( ) for 2-3 seconds. You will hear an audible prompt.
- To power off: Press and hold the power button ( ) again for 2-3 seconds.

Your browser does not support the video tag.

Video: Demonstrates the unboxing, physical features, and power-on sequence of the Xdobo X8 II Bluetooth Speaker.

3. Bluetooth Pairing

Once powered on, the speaker will automatically enter Bluetooth pairing mode, indicated by a blinking blue LED light.

1. Enable Bluetooth on your device (smartphone, tablet, etc.).
2. Search for "X8" in the list of available Bluetooth devices.
3. Select "X8" to connect. A confirmation tone will sound upon successful pairing.

Operating Instructions

Button Functions:

Button	Function (Short Press)	Function (Long Press)
Power ( )	N/A	Power On/Off
Mode (M)	Switch input mode (Bluetooth/TF Card/AUX)	N/A
Play/Pause ( )	Play/Pause music; Answer/End call	Reject call
Volume Down (-)	Volume down	Previous track
Volume Up (+)	Volume up	Next track
Microphone ( )	Activate Voice Assistant	N/A

True Wireless Stereo (TWS) Pairing:

To achieve a room-filling stereo sound, you can connect two X8 II speakers together.

1. Ensure both X8 II speakers are powered off.
2. Power on both speakers simultaneously.
3. Double-click the power button on either speaker. The speakers will enter pairing mode, indicated by blinking yellow lights.
4. Once successfully paired, the main speaker will emit a "beep beep" sound, and the yellow lights will stop blinking.
5. Connect your device via Bluetooth to the main speaker (the one that said "beep beep").

Image: Step-by-step visual guide for True Wireless Stereo (TWS) pairing of two XDOBO X8 II speakers.

Your browser does not support the video tag.

Video: Official demonstration of how to perform TWS (True Wireless Stereo) pairing with Xdobo Bluetooth Speakers.

Voice Assistant:

The X8 II speaker supports voice assistant functionality. Short press the microphone button () to activate the voice assistant on your connected Bluetooth device. You can then speak commands through the speaker's built-in high-definition microphone.

Image: A hand pressing the microphone button on the speaker to activate the voice assistant feature.

Alternative Playback Modes:

- **TF Card Playback:** Insert a Micro SD (TF) card into the designated slot. The speaker will automatically switch to TF card mode and begin playing audio files.
- **AUX Input:** Connect an audio device using the provided 3.5mm AUX cable to the AUX port. The speaker will automatically switch to AUX mode.

Maintenance

To ensure the longevity and optimal performance of your xdobo X8 II speaker, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the speaker's surface. For stubborn dirt, a slightly damp cloth can be used, but

ensure no water enters the ports.

- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Water Resistance:** While waterproof, ensure the rubber cover for the ports is securely closed before exposing the speaker to water or moisture. Avoid submerging the speaker for extended periods.
- **Battery Care:** To preserve battery life, avoid fully discharging the speaker frequently. Charge it regularly, even if not in use for long periods.

Troubleshooting

If you encounter issues with your xdobo X8 II speaker, refer to the following common solutions:

Problem	Possible Solution
Speaker does not power on.	Ensure the speaker is fully charged. Connect to a power source and try again.
Cannot pair via Bluetooth.	Ensure the speaker is in pairing mode (blinking blue LED). Disable and re-enable Bluetooth on your device. Move your device closer to the speaker (within 10 meters). Forget "X8" from your device's Bluetooth list and try pairing again. Ensure no other devices are currently connected to the speaker.
No sound or low volume.	Adjust the volume on both the speaker and your connected device. Ensure the correct input mode (Bluetooth, TF Card, AUX) is selected. Check if the audio cable (for AUX) or TF card is properly inserted.
TWS pairing fails.	Ensure both speakers are X8 II models. Power off both speakers, then power them on and double-click the power button on one speaker to initiate TWS pairing. Ensure no devices are connected via Bluetooth to either speaker before initiating TWS pairing.

Specifications

Feature	Detail
Brand	xdobo
Model Name	X8 II
Speaker Type	Surround Sound, Subwoofer, 3D, Computer, Outdoor
Connectivity Technology	Bluetooth, USB
Wireless Communication Technology	Bluetooth
Bluetooth Range	10 Meters

Feature	Detail
Speaker Maximum Output Power	60 Watts
Battery Capacity	6600 Milliamp Hours
Battery Life	15 Hours (at 50% volume)
Frequency Response	20 KHz
Signal-to-Noise Ratio	90 dB
Is Waterproof	True
Item Weight	2.57 pounds
Package Dimensions	9.61 x 4.88 x 4.17 inches

Warranty and Support

For warranty information or technical support regarding your xdobo X8 II Portable Wireless Bluetooth Speaker, please contact the manufacturer, XDOBO, directly through their official channels or the retailer where the product was purchased.
You can visit the official XDOBO store on Amazon for more information: XDOBO Store

© 2024 xdobo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08K2NZJGD

More documents and user manuals: **https://manuals.plus/**