

Nutale F6X

Nutale Ultra Slim Key Finder F6X Instruction Manual

Model: F6X

Your guide to setting up and using your Nutale Key Finder.

1. PRODUCT OVERVIEW

The Nutale Ultra Slim Key Finder (Model F6X) is a compact Bluetooth device designed to help you locate misplaced items quickly. It connects to your smartphone via the Findthing App and features an 80dB sound alarm.



Image: The Nutale Ultra Slim Key Finder, a small, black, oval-shaped device with a subtle speaker grille pattern.





Image: A diagram showing the dimensions of the Nutale Key Finder: Length 36mm, Width 24mm, Thickness 5mm.

2. SETUP GUIDE

Follow these steps to set up your Nutale Key Finder:

1. **Power On:** Long press the device's button for 5 seconds until you hear a sound, indicating it's powered on.
2. **Download App:** Download and open the "Findthing" App from your device's app store. This version is compatible with both iOS and Android devices.
3. **Add Device:** Tap the "+" icon within the Findthing App to add a new device.
4. **Select Category:** Choose a category for your item (e.g., keys, wallet, remote).
5. **Finish Setup:** Tap "Done" to complete the pairing process. You can then tap "Call" in the app to test the device's ring function.



Findthing APP



Download on the
App Store



GET IT ON
Google Play

Image: A smartphone screen displaying the Findthing App interface with options for location history, sharing, firmware update, and device information. App Store and Google Play icons are visible for download.

3. OPERATING INSTRUCTIONS

One-Touch Find

To quickly locate a misplaced item, open the Findthing App on your smartphone and click the "CALL" button. Your Nutale Key Finder will emit an 80dB sound, guiding you to its location.

Ring Your Things




Image: A Nutale Key Finder icon with sound waves emanating from it, superimposed on a living room setting, indicating the device is ringing. A smartphone screen shows the 'Call' button in the app.

Attaching the Key Finder

The Nutale Key Finder is designed to be attached to various items:

- **Keys:** Use the integrated loop to attach it to your keychain.
- **Wallet:** Its ultra-slim design allows it to fit easily into wallet compartments.
- **Remote Controls:** Attach it to your TV remote or other frequently misplaced remotes.
- **Bags/Backpacks:** Secure it to zippers or internal loops of bags.



Image: A Nutale Key Finder attached to a set of house keys on a keyring, resting on a grey tray.



Image: A hand sliding the slim Nutale Key Finder into a compartment of a blue wallet.



Image: A Nutale Key Finder attached to a white TV remote control, resting on a textured fabric surface.

Official Product Videos

Your browser does not support the video tag.

Video: An official Nutale video demonstrating the features and usage of the Nutale Key Finder Mini Bluetooth Tracker. It shows how to connect the device to items and use the app to locate them.

Your browser does not support the video tag.

Video: An official Nutale video showcasing the Nutale Findthing key Finder. It highlights its compact design and ease of use for tracking various personal belongings.

4. MAINTENANCE

Battery Replacement

The Nutale Key Finder uses CR2032 coin cell batteries. When the battery is low, the device's performance may be affected. To replace the battery:

1. Carefully open the device casing.

- 2. Remove the old CR2032 battery.
- 3. Insert a new CR2032 battery with the positive (+) side facing up.
- 4. Close the device casing securely.

Note: 4 CR2032 batteries are required for operation. Batteries are not included with the product.

5. TROUBLESHOOTING

- **Device not connecting to App:** Ensure Bluetooth is enabled on your smartphone and the Nutale Key Finder is powered on and within range. Try restarting both the device and the app.
- **Device not beeping:** Check the battery level in the app. If the battery is low, replace it. Ensure the volume on your smartphone is not muted.
- **Short range:** Bluetooth range can be affected by obstacles and interference. Ensure there are no major obstructions between your phone and the key finder.

6. SPECIFICATIONS

Feature	Detail
Model Number	F6X
Connectivity	Bluetooth
Dimensions	1.4 x 0.96 x 0.2 inches (36 x 24 x 5 mm)
Item Weight	1.76 ounces
Batteries Required	4 x CR2032 (not included)
Compatible Devices	iOS and Android Smartphones
Material	Plastic

7. WARRANTY & SUPPORT

Nutale is dedicated to providing premium products and impeccable customer care. For any questions, concerns, or support needs, please contact our customer service team.

Contact Information:

- **Website:** www.nutale.com

- **Email:** support@nutale.com (example)