

[manuals.plus](#) /

› [AEEZO](#) /

› [AEEZO 10.1 Inch WiFi Digital Picture Frame User Manual](#)

AEEZO Portrait 01 Black

AEEZO 10.1 Inch WiFi Digital Picture Frame User Manual

Model: Portrait 01 Black

1. INTRODUCTION

This manual provides comprehensive instructions for setting up, operating, and maintaining your AEEZO 10.1 Inch WiFi Digital Picture Frame. This device is designed to allow instant sharing of photos and short videos with loved ones via the AiMOR app, providing a convenient way to stay connected.

2. WHAT'S IN THE Box

- AEEZO 10.1 Inch WiFi Digital Picture Frame
- Power Adapter
- User Manual
- Frame Stand (pre-attached or separate)

3. PRODUCT OVERVIEW

3.1 Front View



Figure 3.1: Front view of the AEEZO Digital Picture Frame alongside a smartphone displaying the AiMOR app interface.

- **10.1" IPS HD Touch Screen:** Displays photos and videos with 1280*800 resolution. Supports touch gestures for navigation.

3.2 Rear and Side Views

Auto-Rotate Function

Place the frame how you like



Figure 3.2: Rear view of the AEEZO Digital Picture Frame, illustrating its auto-rotate capability and key features.

- **Power Port:** Connects to the included power adapter.
- **USB Port:** For importing photos/videos from a USB drive (supports up to 64GB).
- **SD Card Slot:** For importing photos/videos from an SD card (supports up to 64GB).
- **Reset Button:** Used to reset the device (requires a pin).
- **Stand:** Detachable stand for horizontal or vertical placement.

4. SETUP

1. **Power On:** Connect the power adapter to the frame and a power outlet. The frame will automatically power on.
2. **Initial Setup:** Follow the on-screen instructions to select your language, time zone, and connect to a Wi-Fi network.
3. **AiMOR App Installation:** Download the "AiMOR" app from the App Store (iOS) or Google Play Store (Android) on your smartphone.
4. **Connect Frame to App:**
 - Open the AiMOR app and create an account or log in.
 - On the frame, navigate to "Settings" and find the unique frame ID.
 - In the AiMOR app, add your frame using the provided frame ID.

- Once connected, you can invite friends and family to share photos and videos to your frame.

Figure 4.1: Steps for downloading and connecting the AiMOR app to your digital picture frame.

5. OPERATING INSTRUCTIONS

5.1 Sharing Photos and Videos

- Via AiMOR App:** Open the AiMOR app, select photos or videos (up to 15 seconds for videos) from your phone's gallery, add a caption, and send them directly to the connected frame.
- Via USB/SD Card:** Insert a USB drive or SD card (max 64GB) containing your media into the respective port on the frame. Use the frame's interface to import files to the internal 32GB storage.



Figure 5.1: Wireless sharing of photos and videos to the digital picture frame using the AiMOR app.

5.2 Touch Screen Navigation

- Swipe:** Swipe left or right to navigate through photos and videos in the slideshow.
- Tap:** Tap the screen to bring up options such as hiding a photo, accessing the gallery, fitting to frame, or adjusting the photo.
- Pinch-to-Zoom:** Use two fingers to zoom in or out on a photo.

5.3 Auto-Rotate Function

The frame automatically adjusts the orientation of photos and videos based on whether it is placed in portrait or landscape mode. It can also be wall-mounted.




Figure 5.3: The auto-rotate feature allows flexible placement of the frame.

5.4 Settings and Customization

- **Display Settings:** Adjust brightness and activate sleep mode for energy saving.
- **Slideshow Settings:** Customize the speed and transition effects of the photo slideshow.
- **Manage Photos:** Access the gallery to view, hide, or delete photos and videos stored on the frame.

6. MAINTENANCE

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the screen and frame. Avoid abrasive cleaners or sprays.
- **Placement:** Place the frame on a stable surface or mount it securely on a wall. Avoid direct sunlight or extreme temperatures.
- **Software Updates:** Ensure the frame's software is updated regularly via Wi-Fi for optimal performance and new features.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Frame not powering on.	Power adapter not connected or faulty.	Ensure power adapter is securely connected to the frame and a working power outlet. Try a different outlet.
Cannot connect to Wi-Fi.	Incorrect Wi-Fi password or weak signal.	Double-check Wi-Fi password. Move the frame closer to the router. Restart the router.
Photos not appearing on frame.	Incorrect frame ID in AiMOR app or network issue.	Verify the frame ID in the AiMOR app. Ensure both phone and frame are connected to the internet.
Touch screen unresponsive.	Temporary software glitch.	Restart the frame by unplugging and re-plugging the power adapter. If issue persists, perform a factory reset (refer to advanced settings).

8. SPECIFICATIONS

- **Product Dimensions:** 10.71 x 7.28 x 0.99 inches
- **Item Weight:** 2.2 pounds
- **Model Number:** Portrait 01 Black
- **Brand:** AEEZO
- **Color:** Black
- **Resolution:** 1280*800 IPS HD Display
- **Compatible Devices:** Smartphone
- **Screen Size:** 10 Inches
- **Internal Storage:** 32GB
- **External Storage Support:** Max 64GB SD card or USB driver
- **Connectivity:** WiFi

9. WARRANTY AND SUPPORT

AEEZO provides a one-year limited warranty for this digital picture frame. Our factory adheres to strict standards for raw materials and conducts a 200-hour machine aging test on all WIFI digital picture frames before shipment to ensure quality.

We offer lifetime support and aim for a prompt response within 24 hours for any inquiries or issues.

For support, please refer to the contact information provided on the product packaging or the official AEEZO website.

Related Documents - Portrait 01 Black

	<p>AEEZO SKYLINE 13 13.3" Smart Wifi Digital Photo Frame User Manual</p> <p>User manual for the AEEZO SKYLINE 13, a 13.3-inch Smart Wifi Digital Photo Frame. Learn about initial setup, connecting to the AiMOR app, sharing photos and videos, frame overview, and settings.</p>
 User Manual	<p>AEEZO Digital Photo Frame User Manual - Setup, Features, and Sharing</p> <p>Comprehensive user manual for the AEEZO Digital Photo Frame. Learn how to set up your frame, connect with the Frameo app, share photos and videos, manage settings, and troubleshoot common issues.</p>
 User Manual	<p>AEEZO Memory 01 Digital Photo Frame User Manual and Setup Guide</p> <p>Comprehensive user manual for the AEEZO Memory 01 Digital Photo Frame by Shenzhen Efercro Electronic Technology Co., Ltd. Learn how to set up, connect, and share photos using the Frameo app. Includes hardware specifications and operational guidance.</p>
 User Manual	<p>AEEZO Tronpad Kid 7-TK701 User Guide</p> <p>Comprehensive user guide for the AEEZO Tronpad Kid 7-TK701 tablet, covering setup, specifications, features, settings, connectivity, app management, multimedia, and troubleshooting.</p>