

Roku 9102R

Roku Streambar 4K Streaming Media Player User Manual

Model: 9102R

Brand: Roku

INTRODUCTION

The Roku Streambar is a compact 2-in-1 entertainment device that integrates a 4K streaming media player with a premium soundbar. It is designed to upgrade your television's audio and provide access to a vast selection of streaming content in vibrant 4K HDR picture quality. The Streambar enhances dialogue clarity, automatically levels loud commercials, and supports Bluetooth streaming for music.

The powerful 2-in-1 entertainment upgrade

Le divertissement ultime dans un format 2 en 1



4K picture &
HDR color

Images 4K &
couleurs HDR



Long-range
Wi-Fi®

Wi-Fi® longue
portée




Crisp, clear
dialogue

Dialogues
clairs et nets



Quiets loud
commercials

Diminution du volume
des publicités
bruyantes



Bluetooth®
streaming

Audio
Bluetooth®



Channel shortcut buttons may vary

Le touches de raccourci vers les chaînes peuvent varier

Image: Roku Streambar showcasing its core features including 4K HDR, long-range Wi-Fi, crisp dialogue, automatic commercial leveling, and Bluetooth streaming capabilities.


WHAT'S IN THE BOX

Verify that all components are present in the packaging:

- Roku Streambar
- Voice Remote with TV controls
- Premium High Speed HDMI Cable
- Power Adaptor
- Two AAA Duracell batteries

What's in the box

Qu'y a-t-il dans la boîte




Roku® Streambar®



Voice remote

Télécommande vocale




Premium High Speed
HDMI® Cable

Câble HDMI®
High Speed Premium




Two AAA batteries

Deux piles AAA



Power adaptor and cable

Adaptateur secteur et câble



Optical cable (optional)

Only use if your TV does not have an HDMI-ARC port

Câble optique (en option)

À utiliser uniquement si le téléviseur ne possède pas de port HDMI ARC

Image: All items included in the Roku Streambar package, laid out for identification.

SETUP GUIDE

1. Connect to TV

Connect the Roku Streambar to your TV using the included Premium High Speed HDMI Cable. For optimal audio, connect to an HDMI port labeled **ARC** (Audio Return Channel) on your TV. If your TV does not have an HDMI ARC port, you may use the optical audio cable (sold separately) for sound, in addition to the HDMI cable for video.

2. Power On

Connect the power adaptor to the Streambar and then plug it into a wall outlet. The Streambar will begin to power on automatically.

3. Remote Setup

Insert the two included AAA batteries into the voice remote. The remote should automatically pair with your

Streambar. If not, press and hold the pairing button inside the battery compartment for 5 seconds.

4. Network Connection

Follow the on-screen instructions to connect your Roku Streambar to your home Wi-Fi network. You will need your network name and password.




Image: Rear panel connections of the Roku Streambar, indicating ports for power, optical audio, HDMI, USB, and the reset button.



Channel shortcut buttons may vary
Le touches de raccourci vers les chaînes peuvent varier

Image: Detailed view of the Roku voice remote, highlighting its various control buttons.

OPERATING INSTRUCTIONS

Using the Remote Control

The Roku voice remote provides comprehensive control over your Streambar and TV:

- **TV Power:** Turns your TV on or off.
- **Voice Button:** Press and hold to activate voice search or commands.
- **Directional Pad (Up, Down, Left, Right):** Navigates menus and content.
- **OK Button:** Selects items.
- **Home Button:** Returns to the Roku home screen.
- **Back Button:** Returns to the previous screen.

- **Volume Up/Down:** Adjusts the Streambar's volume.
- **Mute Button:** Mutes or unmutes the sound.
- **Options Button (*):** Accesses additional settings or options within apps.
- **Instant Replay:** Jumps back a few seconds in video playback.
- **Channel Shortcut Buttons:** Direct access to popular streaming services.





Streaming Content









From the Roku home screen, you can browse and launch various streaming channels. The customizable home screen allows you to arrange your favorite apps for quick access.

Roku





Stream what you love Regardez ce que vous aimez

Enjoy a massive selection of free, live and premium TV.
Profitez d'une foule de chaînes de TV en direct gratuites
et de chaînes premium.

Stream a massive selection of free, live, and premium TV across thousands of channels
Profitez de la streaming en continu d'une vaste sélection de chaînes de télé gratuites, en direct et payantes sur es milliers de chaînes

A paid subscription or other payments may be required to access some channel content. Channels are subject to change and vary by country.
Certaines chaînes nécessitent un abonnement payant. Les chaînes proposées peuvent varier d'un pays à un autre.

Image: The Roku interface showing a selection of available streaming channels.

Sound Settings

Access sound settings through the Options button (*) on your remote while content is playing. You can adjust settings such as:

- **Volume Mode:** Options like Leveling (to quiet loud commercials) or Night Mode (to reduce sudden loud sounds).
- **Speech Clarity:** Enhances dialogue for easier listening.

Bluetooth Streaming

To stream audio from a Bluetooth device:

1. Go to the Roku home screen.
2. Navigate to **Settings > Remotes & devices > Pair Bluetooth device**
3. Follow the on-screen instructions to pair your device.

Voice Control

Press and hold the voice button on your remote to speak commands. You can search for movies, TV shows, actors, or launch channels. For example, say "Find action movies" or "Launch Netflix."

A perfect fit for any smart home



Works with
Apple AirPlay



Works with
Apple Home

works
with | alexa



works with
Google Home

Apple, Apple Home, AirPlay, HomeKit and Siri are trademarks of Apple Inc., registered in the U.S. and other countries and regions. Amazon, Alexa and all related logos are trademarks of Amazon.com, Inc. or its affiliates. Alexa enabled device is required to work with Alexa. Google and Google Home are trademarks of Google LLC. Third party features and services may be subject to change or removal without notice. Only supports English language.

Image: Roku Streambar's compatibility with various smart home ecosystems and casting technologies.

MAINTENANCE

Cleaning

To clean your Roku Streambar, gently wipe the exterior with a soft, dry, lint-free cloth. Do not use liquid cleaners or abrasive materials.

Software Updates

The Roku Streambar automatically receives software updates. Ensure your device is connected to the internet to receive the latest features and improvements.

TROUBLESHOOTING

No Power

- Ensure the power adapter is securely connected to the Streambar and a working wall outlet.
- Try plugging the power adapter into a different outlet.

No Sound

- Verify the HDMI cable is connected to an HDMI ARC port on your TV. If not, ensure the optical cable is also connected.
- Check that the Streambar's volume is not muted and is turned up.
- Ensure your TV's audio output is set to the HDMI ARC or optical input where the Streambar is connected.
- Restart both your TV and the Streambar.

No Picture / Streaming Issues

- Confirm the HDMI cable is securely connected to both the Streambar and your TV.
- Ensure your TV input is set to the correct HDMI port.
- Check your internet connection. Restart your router if necessary.
- Restart the Streambar by unplugging it from power for 10 seconds and plugging it back in.

Remote Not Responding

- Replace the AAA batteries in the remote.
- Ensure there are no obstructions between the remote and the Streambar.
- If the remote is still unresponsive, try re-pairing it by pressing the pairing button inside the battery compartment for 5 seconds.

Poor Audio Quality

- Check sound settings (Options button *) for Speech Clarity or Volume Mode adjustments.
- Ensure the Streambar is placed in an open area, not enclosed, for optimal sound dispersion.
- Verify that the audio source (streaming app, TV channel) is providing high-quality audio.

SPECIFICATIONS

Feature	Detail
Product Dimensions	14 x 4.2 x 2.4 inches
Item Weight	2.4 pounds
Model Number	9102R
Batteries Required	2 AAA (included)
Connectivity Technology	HDMI
Connector Type	HDMI, Micro USB
Special Feature	Dolby Audio
Resolution	4K
Supported Internet Services	Hulu, Netflix, Pandora, Prime Video, Vudu, YouTube
Controller Type	Remote Control, Voice Control
Form Factor	Soundbar
Color	Black
Manufacturer	Roku
First Available Date	October 15, 2020

WARRANTY AND SUPPORT


For warranty information and technical support, please refer to the official Roku website or the documentation included with your product. You can typically find detailed support resources, FAQs, and contact information for customer service on the manufacturer's website.






Online Support: Visit www.roku.com/support for assistance.



© 2023 Roku, Inc. All rights reserved.


Related Documents - 9102R

	<p>Roku Streambar: Quick Start Guide and Setup Instructions</p> <p>Get started with your Roku Streambar. This guide covers unboxing, connecting to your TV, setup steps, common questions about HDMI-CEC and ARC, and tips for sound settings and voice commands.</p>
---	---

	<p>Roku Express Setup and Activation Guide</p> <p>Step-by-step instructions for setting up and activating your Roku Express streaming media player, including connecting to your network, downloading software, and creating a Roku account.</p>
	<p>Roku Wireless Speakers Quick Start Guide - Setup and Tips</p> <p>Get premium sound with Roku Wireless Speakers. This quick start guide provides setup instructions, tips for sound settings, voice commands, and Bluetooth pairing.</p>
	<p>Roku Wireless Bass Pro Quick Start Guide: Setup and Connection</p> <p>Get started quickly with the Roku Wireless Bass Pro subwoofer. This guide provides step-by-step instructions for setup, connection, and placement.</p>
	<p>Roku Express HD Streaming Media Player Quick Start Guide</p> <p>Get started with your Roku Express HD streaming media player. This guide covers unboxing, setup, connection, and basic troubleshooting for a seamless streaming experience.</p>
	<p>Roku Streaming Stick 4K Quick Start Guide: Setup and Usage</p> <p>Comprehensive guide for setting up your Roku Streaming Stick 4K. Learn how to connect, pair your remote, optimize Wi-Fi, and troubleshoot common questions. Includes product details and features.</p>

Documents - Roku – 9102R

[pdf] Quick Start Guide Guide



Roku Roku® Streambar® Wireless Bass 4K HDR Streaming Player Premium Audio All in One with Subwoofer and Voice Remote Quick Start Guide 9102R 9203R BDL1 0829610004907 187 49 files
bbystatic pl3TBKzgZxy9W5fWIEA7JQ |||

Just wait until you hear this Wireless Bass Quick Start Guide What s included Roku Streambar Remote Power adaptor Power cable x2 Two AAA batteries Premium High Speed HDMI Cable Optical cable optional Only use if your TV does not have an HDMI-ARC port. Roku Wireless Bass Details Remo...

lang:en score:29 filesize: 2 M page_count: 8 document date: 2022-08-26



[pdf]

Shanan Carney Roku Streambar m media amazon Streambar™ BrandsMartUSA Ask your Alexa or Google Assistant enabled device to launch channels search for entertainment turn TV on off and more

Set up Sheets Fall 2020 The free mobile app Turn iOS® Android™ into the ultimate streaming companion

Watch 100 word description is 2 in 1 upgrade with powerful premium sound any 71McEcn9AiL 20283489

images l brandsmartusa s manuals

Roku Set-up Sheets Fall 2020 Roku Streambar™ US Set-up Information SKU/Model **9102R** UPC 829610004020 UCC 90829610004061 MSRP 129.99 Great for Upgrading any TV Any room in the house Simplifying your setup Quick look Powerful 4K streaming premium audio Crisp, clear dialogue quiets...

lang:en score:22 filesize: 218.83 K page_count: 5 document date: 2020-09-15

