

[Manuals.plus](#) /

› [COURANT](#) /

› Courant CATCH:3 Classics Wireless Charging Station and Valet Tray User Manual

COURANT CATCH:3 Classics

Courant CATCH:3 Classics Wireless Charging Station and Valet Tray User Manual

INTRODUCTION

Thank you for choosing the Courant CATCH:3 Classics Wireless Charging Station and Valet Tray. This manual provides essential information for the proper setup, operation, and maintenance of your device. Please read these instructions carefully before use and retain them for future reference.



Image: The Courant CATCH:3 Classics in Saddle leather, showcasing its wireless charging pad and valet tray area.

SETUP INSTRUCTIONS

What's in the Box

Before you begin, ensure all components are present:


- Courant CATCH:3 Classics Wireless Charging Station and Valet Tray
- USB-C Charging Cable
- Power Adapter

WHAT'S IN THE BOX

Single-Device Wireless Charging Accessory Tray



Power Adapter



USB-C Charging Cable



* Charges Through Most Cases up to 3mm in Thickness

Image: Visual representation of the product contents, including the charging tray, USB-C cable, and power adapter.

Connecting the Power

1. Connect the USB-C end of the provided charging cable into the USB-C port on the back of the CATCH:3 Classics unit.
2. Plug the USB-A end of the charging cable into the provided power adapter.
3. Insert the power adapter into a standard wall outlet.

The device is now ready for use.

OPERATING INSTRUCTIONS

Wireless Charging

The CATCH:3 Classics features a large 3-coil charging area designed for effortless alignment. It provides up to 10W wireless output for Qi-certified devices.

- Place your Qi-certified smartphone (e.g., iPhone, Galaxy, Google Pixel) or AirPods on the designated charging area of the tray.
- Ensure the device is centered on the charging pad for optimal performance. A charging indicator on your device should confirm charging has begun.
- The CATCH:3 Classics is compatible with most phone cases up to 3mm in thickness.

FAST WIRELESS CHARGING

- ✓ Large 3-Coil Charging Area, Making Charging Alignment Effortless
- ✓ Up to 10W Wireless Output



Image: A smartphone actively charging on the wireless pad of the CATCH:3 Classics, demonstrating proper placement.

Additional USB-A Port

An additional USB-A port is integrated into the unit for charging other devices that require a wired connection. Simply plug your device's USB-A cable into this port.

Valet Tray Functionality

The integrated valet tray provides a convenient space to organize your everyday items such as keys, wallets, watches, or jewelry.

PREMIUM QUALITY ITALIAN LEATHER



Luxury
Materials



Blue Angel
Certified



Leather Working
Group's Gold-Rated

Image: Detailed diagram illustrating the charging area, additional USB-A port, durable braided nylon cable, and catch-all tray features of the CATCH:3 Classics.

Product Overview Videos

Your browser does not support the video tag.

Video: An official Courant video showcasing the CATCH:3 Premium Italian Leather Wireless Charging Station and its features.

Your browser does not support the video tag.

Video: An official Courant video demonstrating the Wireless Phone Charging Tray made with high-quality Italian leather.

MAINTENANCE

The CATCH:3 Classics is crafted with premium Italian leather. To maintain its appearance and longevity:

- Wipe the leather surface gently with a soft, dry cloth to remove dust.
- Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the leather.
- Keep the device away from direct sunlight and extreme temperatures to prevent discoloration or drying of the

leather.

- For deeper cleaning, consult a professional leather care specialist.

A STYLISH AND CONVENIENT WAY TO STAY CHARGED AT ALL TIMES



Image: Display of premium Italian leather swatches and environmental certifications, highlighting the quality of materials used.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device not charging wirelessly	Device not properly aligned on charging pad. Not a Qi-certified device. Phone case too thick. Power not connected.	Ensure device is centered on the charging area. Verify device is Qi-compatible. Remove phone case if thicker than 3mm. Check power cable connection and wall outlet.
Slow charging speed	Device not optimally placed. Background apps consuming power.	Adjust device placement for better coil alignment. Close unnecessary background applications.

Problem	Possible Cause	Solution
Additional USB-A port not working	Cable issue. Device issue.	Try a different USB-A cable. Test the device with another power source.
iPhone 12/13 models not charging reliably	These models can be more sensitive to placement.	Exercise extra care when aligning the iPhone 12 or 13 model on the charging pad to find the optimal charging position.

SPECIFICATIONS

Feature	Detail
Brand	COURANT
Model Number	101407
Connectivity Technology	Wireless
Wireless Charging Standard	Qi
Compatible Devices	Qi-certified devices (iPhones, AirPods, Android Phones, etc.)
Output Wattage	10 Watts
Input Voltage	5 Volts (DC)
Output Current	2 Amps
Total USB Ports	1 (USB-A for additional wired charging)
Material	Italian Leather
Form Factor	Tray/Valet
Power Plug Type	Type A - 2 pin (North American)
Certification	FCC

WARRANTY INFORMATION

Courant products are designed for durability and performance. For specific warranty details, including coverage and duration, please refer to the warranty card included with your product or visit the official Courant website. Keep your proof of purchase for any warranty claims.

CUSTOMER SUPPORT

Should you encounter any issues or have questions regarding your Courant CATCH:3 Classics, please contact Courant customer support. Contact information can typically be found on the product packaging or the official Courant website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question