

[Manuals.plus](#) /

› [MohMus](#) /

› MohMus Premium Universal Turbo Vacuum Brush Instruction Manual for DIRT DEVIL M 7060, Bagline, REBEL 74HFC DD7274-1

MohMus Universal Turbo Brush 30-38mm

MohMus Premium Universal Turbo Vacuum Brush Instruction Manual

For DIRT DEVIL M 7060, Bagline, REBEL 74HFC DD7274-1 and other compatible vacuum cleaners

1. INTRODUCTION

This manual provides instructions for the proper use and maintenance of your MohMus Premium Universal Turbo Vacuum Brush. This accessory is designed to enhance the cleaning performance of your vacuum cleaner, particularly for removing pet hair and deep cleaning various floor types.

The universal design ensures compatibility with a wide range of vacuum cleaner models, including DIRT DEVIL M 7060, Bagline, REBEL 74HFC DD7274-1, and others with a connection diameter between 30mm and 38mm. Manufacturer names and references are used for compatibility reference purposes only.


2. SETUP

Follow these steps to attach the turbo brush to your vacuum cleaner:

1. **Identify your vacuum cleaner's connection type:** The turbo brush is compatible with vacuum cleaner tubes or handles with a diameter between 30mm and 38mm.
2. **Unscrew the adapter:** Locate the threaded adapter on the turbo brush's connection port. Turn it counter-clockwise to loosen it.
3. **Insert the vacuum tube/handle:** Carefully insert the end of your vacuum cleaner's handle or telescopic tube into the turbo brush's connection port. Ensure a snug fit.
4. **Tighten the adapter:** Once the tube is inserted, turn the adapter clockwise to tighten it securely. This will create a firm connection between the brush and your vacuum cleaner.



Image 1: Connection to a vacuum cleaner handle (30-38mm diameter). The diagram illustrates unscrewing the adapter, inserting the handle, and then tightening the adapter.



Ø 30 - 38 mm
ANSCHLUSS
CONNECTION



1. ADAPTER AUFDREHEN
UNSCREW THE ADAPTER

2. HANDGRIFF/ANSCHLUSS (30-38mm) EINFÜHREN
INSERT THE HANDLE/CONNECTION (30-38mm)

3. ADAPTER ZUDREHEN
TIGHTEN THE ADAPTER

Image 2: Connection to a telescopic vacuum cleaner tube (30-37mm diameter). The diagram illustrates unscrewing the adapter, inserting the telescopic tube, and then tightening the adapter.



Image 3: Detailed view of the universal adapter, designed for secure attachment to various vacuum cleaner tubes.

3. OPERATING INSTRUCTIONS

The MohMus Premium Universal Turbo Vacuum Brush is designed for efficient cleaning on various surfaces:

- **Pet Hair Removal:** The integrated rotating roller is highly effective at lifting and removing pet hair (cat and dog hair) from carpets and upholstery.
- **Versatile Floor Cleaning:** This tool is suitable for all carpet types and hard floors, including wood, laminate, parquet, cork, tile, stone, floorboards, and vinyl.
- **Maneuverability:** The swivel joint allows for easy handling and comfortable vacuuming, enabling you to reach difficult areas.
- **Air Regulator:** Utilize the air regulator feature (if present on your vacuum or the brush itself) to adjust suction power for different surfaces and cleaning needs.



Image 4: The MohMus Premium Universal Turbo Vacuum Brush, showcasing its ergonomic design and swivel joint for easy maneuverability.

4. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your turbo brush:

- **Clean the Rotating Roller:** Periodically check the rotating roller for tangled hair, threads, or debris. Use scissors or a brush to carefully remove any obstructions.
- **Inspect Airflow Channels:** Ensure that the air intake and exhaust channels on the brush are free from blockages to maintain proper suction.
- **Wipe Down Exterior:** Use a damp cloth to wipe the exterior of the brush, removing dust and dirt. Do not immerse

the brush in water.

- **Check Connection:** Ensure the connection adapter remains securely tightened to your vacuum cleaner's tube.



Image 5: Underside view of the turbo brush, highlighting the rotating roller mechanism that requires periodic cleaning.



Image 6: Close-up of the rotating roller, illustrating how hair and fibers can accumulate and need to be removed for optimal performance.

5. TROUBLESHOOTING

If you encounter issues with your turbo brush, consider the following:

- **Reduced Suction:** Check for blockages in the brush head, the vacuum cleaner hose, or the dust bag/container. Ensure the connection to the vacuum is secure.
- **Roller Not Spinning:** Inspect the rotating roller for tangled hair or debris that might be preventing it from turning freely. Clean as described in the Maintenance section.
- **Brush Not Attaching Securely:** Verify that your vacuum cleaner's tube diameter is within the 30-38mm compatibility range. Ensure the adapter is fully tightened.
- **Unusual Noises:** This could indicate a blockage or an issue with the rotating mechanism. Disconnect the brush and inspect it thoroughly.

If problems persist after performing these checks, consult your vacuum cleaner's manual or contact the manufacturer of

the turbo brush for further assistance.

6. SPECIFICATIONS

Brand	MohMus
Material	Microfiber
Compatibility	Universal, for vacuum cleaners with 30-38 mm diameter connection
Features	Rotating roller for pet hair, swivel joint, air regulator
Model Number	Compatible with diameter 30-38 mm
Country of Origin	Germany

7. WARRANTY AND SUPPORT

Information regarding specific warranty terms or direct support contacts for this product is not provided within this manual. Please refer to your purchase documentation or contact the retailer for details on warranty coverage and customer support options.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B08K3SLJJC>

More documents and user manuals: <https://manuals.plus/>