Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Ariete 4169

Ariete 4169 Steam Mop 10 in 1 User Manual

Model: 4169

Introduction

The Ariete 4169 Steam Mop 10 in 1 is a lightweight and versatile steam cleaner designed for deep cleaning and sanitizing various surfaces in your home. It effectively eliminates germs and bacteria without the need for chemical detergents. By detaching the steam generator from the main body, it transforms into a practical handheld steam cleaner, ideal for reaching every corner of the house. It sanitizes floors and carpets, removes stubborn dirt and grease from stovetops, eliminates limescale from sanitary fixtures, and restores grout lines between tiles. Steam also sanitizes and refreshes fabrics and sofas. After cleaning, the Steam Mop 10 in 1 is easy to store thanks to its foldable handle, making it compact and storable in any corner.

Important Safety Instructions

Please read all instructions carefully before using the appliance. Keep this manual for future reference.

- Always ensure the appliance is unplugged before filling or emptying the water tank, or when not in use.
- Do not direct steam at people, animals, or electrical appliances. Steam is hot and can cause burns.
- Use only distilled or demineralized water to prevent mineral buildup and prolong the life of the appliance.
- Do not immerse the appliance in water or any other liquid.
- Keep the appliance out of reach of children.
- Do not use the appliance on unsealed hardwood floors, delicate fabrics, or surfaces that are sensitive to heat or moisture.
- Ensure all attachments are securely fitted before operation.
- Never leave the appliance unattended while it is plugged in or operating.

Product Components

The Ariete 4169 Steam Mop 10 in 1 comes with a variety of accessories to facilitate diverse cleaning tasks.



Image: Overview of all included accessories for the Ariete 4169 Steam Mop, including the floor brush, microfiber cloths, carpet glider, 90° nozzle, joint brush, crevice nozzle, scraper, fabric brush, squeegee, and round brushes.

Included Accessories:

- Floor brush
- 2 Microfiber cloths
- Carpet glider accessory
- 90° nozzle
- Joint brush
- Crevice nozzle
- Scraper
- Fabric brush
- Squeegee (for glass)
- Large round brush

- Small round brush

Setup

1. Assembling the Steam Mop

1. Attach the handle to the main body of the steam mop until it clicks into place.
2. Securely attach the desired cleaning head (e.g., floor brush) to the base of the unit.
3. If using for floor cleaning, attach a microfiber cloth to the floor brush.

2. Filling the Water Tank

1. Ensure the appliance is unplugged.
2. Locate the removable water tank.
3. Open the water tank cap and fill with clean, distilled or demineralized water using the provided measuring cup and funnel. Do not overfill. The tank capacity is 350 ml.
4. Close the water tank cap securely.



Image: Detail of the steam mop's control dial and the water tank cap, indicating where to fill water.

Operating Instructions

1. Powering On and Heating Up

1. Plug the power cord into a suitable electrical outlet.
2. Turn the power switch or dial to the "ON" position. The indicator light will illuminate.
3. Allow the appliance to heat up for a few seconds until steam is ready. The heating time is approximately 18 minutes for full autonomy, but steam generation starts quickly.

2. Using as a Steam Mop (for Floors and Carpets)

1. Ensure the floor brush and microfiber cloth are attached. For carpets, place the carpet glider over the floor brush.
2. Move the steam mop slowly and steadily over the surface to be cleaned. The steam will be released automatically.
3. For stubborn stains, hold the mop over the area for a few seconds to allow the steam to penetrate.



Image: The Ariete 4169 Steam Mop being used to clean and refresh a carpet, showing steam being emitted.

3. Using as a Handheld Steam Generator

1. Unplug the appliance.
2. Detach the main steam generator unit from the mop handle and base.
3. Attach the desired accessory (e.g., 90° nozzle, joint brush, fabric brush, squeegee) to the handheld unit.
4. Plug in the appliance and allow it to heat up.
5. Direct the steam towards the surface to be cleaned. Use appropriate accessories for specific tasks:
    - **Fabric Brush:** For refreshing and sanitizing fabrics, sofas, and upholstery.
    - **Squeegee:** For cleaning windows, mirrors, and other glass surfaces.
    - **Joint Brush/Crevice Nozzle:** For cleaning grout lines, tight corners, and hard-to-reach areas.
    - **Scraper:** For removing stubborn grease and grime from stovetops or ovens.



Image: The handheld steam unit with a fabric brush attachment being used to clean and sanitize a blue sofa.



Image: The handheld steam unit with a squeegee attachment cleaning a window, showing steam action.



Image: The handheld steam unit with a nozzle attachment cleaning a stainless steel stovetop, demonstrating grease removal.



Image: The handheld steam unit with a joint brush attachment cleaning grout lines between floor tiles.



Image: The handheld steam unit with a nozzle attachment cleaning between the fins of a radiator.



Image: The handheld steam unit with a scraper attachment cleaning baked-on residue from a baking tray.

Maintenance

1. After Each Use

- Unplug the appliance and allow it to cool completely.
- Empty any remaining water from the tank.
- Remove and wash microfiber cloths. They can typically be machine washed.
- Wipe down the exterior of the appliance and accessories with a damp cloth.

2. Storage

The Ariete 4169 features a foldable handle for compact storage.



Image: The Ariete 4169 Steam Mop with its handle folded down, demonstrating its compact storage capability.



Image: Side view of the Ariete 4169 Steam Mop showing the power cord neatly wrapped around integrated hooks for storage.

- Fold the handle for compact storage.
- Wrap the power cord neatly around the designated hooks.
- Store the appliance and its accessories in a dry, safe place.

Troubleshooting

Problem	Possible Cause	Solution
No steam or low steam output	Water tank is empty; Appliance not heated sufficiently; Blocked nozzle/attachment.	Refill water tank; Allow more time to heat up (up to 18 minutes for full autonomy); Clean or unblock the nozzle/attachment.

Problem	Possible Cause	Solution
Water leaking from the unit	Water tank cap not securely closed; Overfilled water tank; Incorrectly attached accessory.	Ensure water tank cap is tight; Do not overfill the tank; Reattach accessories correctly.
Appliance not turning on	Not plugged in; Power outlet malfunction; Appliance fault.	Check power connection; Try a different outlet; Contact customer support if problem persists.
Streaks on floor after cleaning	Microfiber cloth is dirty; Too much steam on delicate surfaces; Residue from previous cleaning products.	Replace or clean microfiber cloth; Reduce steam output if adjustable; Pre-clean floor to remove old residues.

Specifications

Feature	Detail
Brand	Ariete
Model Number	4169
Power	1500 Watts
Voltage	120 Volts
Water Tank Capacity	350 Centimeters cubes (ml)
Dimensions (L x W x H)	21 x 27 x 115 cm
Item Weight	2.7 Kilograms
Heat-up Time	Quick steam generation, 18 minutes autonomy
Special Features	Removable steam generator, Foldable handle
Recommended Surface	Carpet, sealed hard floors

Warranty and Support

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official Ariete website. Keep your proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08K8YKN1R

More documents and user manuals: **https://manuals.plus/**